

THEFT DETERRENT SYSTEM

■ DESCRIPTION

- The theft deterrent system sounds an alarm when any of the following activates are detected:
 - The vehicle being forcibly entered.
 - The engine hood or trunk lid being opened.
 - Any door or trunk lid being unlocked without key.
 - The battery terminals are removed and reconnected.
- The system consists of door lock control system parts, wireless door lock remote control system parts, smart key system parts, the security horn and the security indicator light.
- This system is controlled by the certification ECU on models with the smart key system and by the main body ECU on models without the smart key system.
- The warning methods and timing of the system are listed below.

Warning Method	Interior Light	Illuminates
	Hazard Light	Flashing
	Headlight	Flashing
	Taillight	Flashing
	Vehicle Horn	Sound (approx. 0.4 second cycles)
	Security Horn	Sound (approx. 0.4 second cycles)
	Door Lock Motor	Locking
Warning Time		60 seconds