

Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013 Page : 1 / 23

Title and contract N°	WP4 T4.4	C592
Author:	Brice Gombault	SYSTEREL
Diffusion :		
Object :	Safety analyse of Subset 026, Section 3.5, Mar Communication (MoRC).	nagement of Radio

1. MODIFICATION HISTORY

Issue Number Date	Section Number	Modification / Description	Author
1A 04-10-13	All	Creation	B. GombaultBGO
2A 15-10-13	All	Revised according to comments	B. GombaultBGO
3A 05-11-13	§3	Revised according to comments from M. Pokam (refers to safety_analyse_MORC-1_Aebt-comments.docx)	BGOB. Gombault M. Pokam
<u>4A</u> <u>14-11-13</u>	<u>All</u>	Revised according to comments from C. Cornu (refers to MoRC Systerel PoC comments A4T.xls) and M. Pokam (refers to openETCS-OI_open-Issues_131108.xls)	B. Gombault C. Cornu M. Pokam

2. CONTEXT

As defined in the SUBSET-088 v2.3.0, the role of ETCS is

To provide the Driver with information to allow him to drive the train safely and to enforce respect of this information.

Thus the Core Hazard is defined as

Exceedance of the safe speed or distance as advised to ETCS.

The refining of this Core Hazard to our system scope (here the MoRC) leads to a new core hazard to consider for our system considered in this study. Which results an "RADIO (INFILL) Transmission data consistency failure (safety related transmission function)"

3. SYSTEM MODEL DESCRIPTION FROM SRS

This chapter describes the MoRC function from the SRS subset-026-3, issue 3.3.0.

The traceability with the SRS section is performed using the notation {§x.y.z}.



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013 Page : 2 / 23

3.1. Functional decomposition

This chapter summarises the role of the different functions.

Function	Role
register mobile terminal	Used to register the Mobile Terminal to a Radio Network {(§3.5.6 of SRS)).
set-up safe connection	Used to set-up the safe connection according to EURORADIO specification ({part of-§3.5.3.7-a} of SRS).
establish communication	Used to establish a communication with trackside equipment (§(§3.5.3-of SRS)).
maintain communication	Used to maintain the communication with trackside equipment (\{\subseteq \lambda \lambda \subseteq \subseteq \lambda \lambda \lambda \subseteq \lambda \lambda \subseteq \lambda \lambda \subseteq \lambda \lambda \subseteq \lambda \lambda \lambda \subseteq \lambda \lambda \lambda \subseteq \lambda \lambda \lambda \subseteq \lambda \lambda \lambda \lambda \subseteq \lambda \lambda \lambda \subseteq \lambda \
terminate communication	Used to terminate the communication with trackside equipment ({part of §3.5.5-of SRS)}.
release safe connection	Used to release the safe connection according to EURORADIO specification (\{\s\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
notify driver	Used to notify the driver of the state of radio communication ({§3.5.7-of SRS}).

3.2. Interfaces of the MoRC function

3.2.1. Physical components

The **EVC** MoRC function interacts with 4 units:

- Mobile Terminal (§3.5.6.1)
- Radio Bloc Centre (§3.5.3.1)
- Radio Infill Unit {§3.5.3.2}
- Driver Module Interface (§3.5.3.8-b)

3.2.2. Data

This chapter describes data used by the MoRC function. These data are created from the information found in the SRS requirements.

Input data	Source	Description
start_of_mission	<u>EVC</u>	A start of mission occurs.
- train is rejected*		* If one of these events occurs during Start of Mission, the termination of the communication shall be performed.
- the driver closes the desk*		·
		{\subseteq3.5.3.4-a\} {\subseteq3.5.5.1-c\} {\subseteq3.5.5.1-d\}
end_of_mission	<u>EVC</u>	End of Mission is performed.
		{§3.5.3.7-a}
trackside_establishment_request -accepting RBC	<u>trackside</u>	The establishment of the communication is ordered from trackside (RBC, RIU or balise groups).
		{§3.5.3.4-b}
		{§3.5.3.7-a}



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **3 / 23**

Input data	Source	Description
trackside_terminating_request	trackside	The terminating of the communication is ordered from trackside.
		{§3.5.3.7-a} {§3.5.5.1-a}
trackside_terminating_ack	trackside	After reception of Termination_com_session_msg, the trackside considers the communication session terminated and sends an acknowledgement to the on-board. {§3.5.5.2-b}
mode_change	EVC	The change of mode has to be reported to the RBC. {§3.5.3.4-c}
manual_change_level	<u>DMI</u>	The driver has manually changed the level to 2 or 3. {§3.5.3.4-d}
front_end_change_level	EVC	The train passes a level transition border (from level 2/3 to level 0, NTC, 1) with its front end. {§3.5.3.7-a}
front_end_RBC_RBC_border	EVC	The train passes a RBC/RBC border with its front end. {§3.5.3.7-a}
end_of_radio_hole	EVC	The train front reaches the end of an announced radio hole. {§3.5.3.4-e}
start_of_radio_hole	EVC	The train front reaches the start of an announced radio hole. {§3.5.3.7-a}
trackside_system_version	trackside	The system version from the trackside. {\sum_{\subseteq 3.5.3.7-c} {\subseteq 3.5.3.8}}
init_com_session_msg_in - time-stamp - Last Relevant Balise Group	trackside	The message Initiation of communication session from the trackside. {§3.5.3.10-b} {§3.5.3.11}
radio_network_identity	trackside DMI	Radio Network identity. {§3.5.6.1-b}
power-up	EVC	The train is switch-on. {§3.5.6.1-a}
RBC_id	trackside	The identity of the RBC. This data is memorised. {§3.5.3.5-a} {§3.5.3.5.3-a} {§3.5.3.13} {§3.5.3.16}
RBC_phone_number	trackside	The telephone number of the RBC. This data is memorised. {\\$3.5.3.5-b} {\\$3.5.3.5.3-b} {\\$3.5.3.13} {\\$3.5.3.16}

Internal data	Description
communication_established	A communication is already established. {\\$3.5.3.5.2\} {\\$3.5.3.8\} {\\$3.5.4.1\}
communication_lost	Communication session is considered as terminated due to loss of safe radio connection. {§3.5.3.4-f} {§3.5.4.2}



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013
Page : 4 / 23

Internal data	Description				
communication_lost_delay	Maximum time to maintain a communication session in case of failed re- connection attempts				
	<u>{\$3.5.4.1}</u> <u>{\$3.5.4.2.1}</u>				
RBC_id	The identity of the RBC.				
RBC_phone_number	The telephone number of the RBC.				
communication_request	The action to be performed (establish/terminate the session). {§3.5.3.5-c} {§3.5.3.6-c}				
spleeping_units	Used in sleeping mode. {§3.5.3.5-d} {§3.5.3.5.3-c}				
RIU_id	The identity of the RIU. {§3.5.3.6-a}				
RIU_phone_number	The telephone number of the RIU. {§3.5.3.6-b}				
phone_number	The telephone number of the train. {§3.5.3.8-a}				
supported_versions	List of supported system versions. {§3.5.3.8}				
max_establishment_try	The number of times to try to establish a safe radio connection. {§3.5.3.7-a}				
max_repetition_msg	Repetition of radio messages (i.e. excluding the first sending) {§3.5.5.3.2}				
msg_repetition_delay	Waiting time before radio message repetition. {§3.5.5.3.1}				
radio_connection_status	Status of the connection from EURORADIO {§3.5.3.7-a}				
last_radio_network_identity	Last Radio Network identity. {§3.5.6.2}				

Output data	Destination	Description
init_com_session_msg_out - RBC_id	trackside	The message Initiation of communication session to the trackside.
- RBC_phone_number - spleeping_units		{§3.5.3.7-b}
termination_com_session_msg	trackside	Termination of communication session message to the trackside. {§3.5.5.2-a}
version_msg	trackside	The version independent message to the trackside indicates "No compatible version supported". {§3.5.3.8-b}



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **5 / 23**

Output data	<u>Destination</u>	Description
session_established_report_msg - phone_number	trackside	The session established report message to the trackside. The phone_number is only sent when the train establish the communication.
		{\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
radio_setup_request	trackside	Request the set-up of a safe radio connection with the trackside. {§3.5.3.7-a}
radio_release_request	trackside	Request the release of a safe radio connection with the trackside. {§3.5.5.2-c}
radio_network_registration	trackside	Order the registration of a Mobile Terminal. {§3.5.6.1}
connection_stat_msg - No Connection - Connection Lost / Set-Up failed - Connection Up	<u>DMI</u>	Information to the driver about the status of the safe radio connection. {§3.5.7}
version_error_flag	<u>DMI</u>	Error flag to inform the driver of a system version error. {§3.5.3.8-b}



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013

Page : 6 / 23

3.3. FMEA

The worksheet includes the following columns:

- #: Identification number of the raw of the table,
- Function: Function/sub-function to be analysed,
- Failure mode (and related outputs): The following failure modes are considered for the outputs of each function:
 - o Absence: the function is not carried out on request,
 - Loss: the function was carried out but it stops,
 - o Inadvertent: the function is performed when not requested,
 - Degraded: the function does not meet its requirements (<u>corrupted outputs analysis is performed if it is relevantit could be due delay, outputs corrupted, address error, ...),
 </u>

Note: for some functions, some of these modes can be not relevant. In this case, the mode is not considered.

- Effect: Direct effect of the failure mode on function outputs and at system level,
- Hazard: Indicate if the hazard identified could happen (Yes or No),
- **Detectability**: Indicate if the detectable/Undetectable,
- SIL: Deduced Safety Integrity Level of the function. SIL-4 if the Hazard is Yes, else SIL-0,
- Safety Criteria: Safety Criteria defining the need to eliminate or mitigate risks. The measures can be preventive, palliative or corrective,
- **Comments**: Free comments to clarify the content of the row.

Suppositions on analyse:

• The absence of communication is safety related at system level.



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **7 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
1	register mobile terminal	Absence	The Mobile Terminal is not registered to the radio network. Communication with trackside equipment is not possible.	yes	Detectable	SIL-4	REQ_FMEA_ID_001 The Mobile Terminal shall be safely registered to a Radio Network. REQ_FMEA_ID_001 The Mobile Terminal shall be safely registered to a Radio Network.	
2		Loss	The Mobile Terminal is not registered to the radio network. Communication with trackside equipment is not possible.	yes	Detectable	SIL-4	REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication). REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication).	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **8 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
თ		Inadvertent	The Mobile Terminal changes form a radio network to another during an active communication. The active communication with trackside equipment fails.	yes	Detectable	SIL-4	REQ_FMEA_ID_003 If a communication through a Radio Network is active, registration of the associated Mobile Terminal to another Radio Network mustn't be performed. REQ_FMEA_ID_003 If a communication through a Radio Network is active, registration of the associated Mobile Terminal to another Radio Network mustn't be performed.	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013 Page : 9 / 23

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
4		Degraded	The data radio_network_registration is corrupted and the radio network does not take it into account. The Mobile Terminal is not registered to the radio network. Communication with trackside equipment is not possible.	yes	Detectable	SIL-4	REQ_FMEA_ID_001 The Mobile Terminal shall be safely registered to a Radio Network. REQ_FMEA_ID_001 The Mobile Terminal shall be safely registered to a Radio Network. REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication). REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication).	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **10 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
<u>5</u>			The data radio_network_registration is not produced for the good Mobile Terminal. The Mobile Terminal changes form a radio network to another during an active communication. The active communication with trackside equipment fails.	yes	<u>Detectable</u>	SIL-4	REQ_FMEA_ID_001 The Mobile Terminal shall be safely registered to a Radio Network. REQ_FMEA_ID_001 The Mobile Terminal shall be safely registered to a Radio Network. REQ_FMEA_ID_003 If a communication through a Radio Network is active, registration of the associated Mobile Terminal to another Radio Network mustn't be performed. REQ_FMEA_ID_003 If a communication through a Radio Network is active, registration of the associated Mobile Terminal to another Radio Network registration of the associated Mobile Terminal to another Radio Network mustn't be performed.	
<u>56</u>	set-up safe connection	Absence / Loss-/ Degraded	The radio connection is not safe. Corruption of data may occur.	yes	Detectable	SIL-4	REQ FMEA ID 004 A safety protocol shall be used to performed communication between Mobile Terminal and Radio Network. REQ_FMEA_ID_004 A safety protocol shall be used to performed communication between Mobile Terminal and Radio Network.	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013 Page : 11 / 23

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
67		Inadvertent	An active communication with trackside equipment fails due to the set-up of the safe connection.	yes	Detectable	SIL-4	REQ_FMEA_ID_005 If a communication with trackside equipment is active, set-up of safe radio connection with another trackside equipment mustn't be performed. Exception in case of handover with RBC. REQ_FMEA_ID_005 If a communication with trackside equipment is active, set-up of safe radio connection with another trackside equipment mustn't be performed. Exception in case of handover with RBC.	
8		Degraded	The data radio_setup_request is corrupted. The safe connection configuration is not the same between On-Board and Trackside. The communication is not possible.	yes	Detectable	SIL-4	REQ_FMEA_ID_011 The compatibility and coherence of the safety protocol used to perform communication between Mobile Terminal and Radio Network shall be the verified. REQ_FMEA_ID_011 The compatibility and coherence of the safety protocol used to perform communication between Mobile Terminal and Radio Network shall be the verified.	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **12 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
79	establish communication	Absence	Communication with trackside equipment is not performed.	yes	Detectable	SIL-4	REQ_FMEA_ID_006 Communication session with trackside equipment shall be safely established. REQ_FMEA_ID_006 Communication session with trackside equipment shall be safely established.	
8 <u>3</u> 0		Loss	Establishment of communication is not complete.	yes	Detectable	SIL-4	REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication). REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication).	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **13 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
9 ¹ 1		Inadvertent	An active communication with trackside equipment fails due to the establishment of a new communication.	yes	Detectable	SIL-4	REQ_FMEA_ID_007 Establishment of communication session shall be performed when no communication is active. Exception in case of handover with RBC. REQ_FMEA_ID_007 Establishment of communication session shall be performed when no communication is active. Exception in case of handover with RBC.	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **14 / 23**

i	#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
	10 12		Degraded	The communication is not correctly established (wrong trackside equipment called, wrong system version used)	yes	Detectable	SIL-4	REQ_FMEA_ID_006 Communication session with trackside equipment shall be safely established. REQ_FMEA_ID_006 Communication session with trackside equipment shall be safely established. REQ_FMEA_ID_015 The compatibility and coherence of system version between On-Board and Trackside shall be verified. In case of error On-Board and Trackside shall be informed. REQ_FMEA_ID_015 The compatibility and coherence of system version between On-Board and Trackside shall be verified. In case of error On-Board and Trackside shall be verified. In case of error On-Board and Trackside shall be verified. In case of error On-Board and Trackside shall be informed.	
	<u>13</u>			The data init_com_session_msg_out doesn't identify the good trackside equipment to establish the communication. The communication is not possible if the equipment not exist. Or a communication is established with a wrong equipment.	<u>yes</u>	<u>Detectable</u>	SIL-4	REQ_FMEA_ID_012 The integrity and authenticity of the order message to contact a RBC or a RIU shall be guaranteed. REQ_FMEA_ID_012 The integrity and authenticity of the order message to contact a RBC or a RIU shall be guaranteed.	



Safety Analyse

Non Confidentiel

Ref. : C592_NOTT_01

Version: 4A

Date : **14/11/2013**Page : **15 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
1	1		The order to contact an RBC or RIU is performed too late and data are not received in time.	yes	Detectable	SIL-4	REQ_FMEA_ID_013 The freshness of the order message to contact a RBC or a RIU shall be guaranteed. REQ_FMEA_ID_013 The freshness of the order message to contact a RBC or a RIU shall be guaranteed. REQ_FMEA_ID_014 The order message to contact a RBC or a RIU shall be send in a safety defined time. REQ_FMEA_ID_014 The order message to contact a RBC or a RIU shall be send in a safety defined time. REQ_FMEA_ID_014 The order message to contact a RBC or a RIU shall be send in a safety defined time.	
1			The data session_established_report_ msg doesn't identify the good telephone numbers. The communication is not possible if the trackside is the initiator.	yes	Detectable	SIL-4	REQ FMEA ID 016 The integrity and authenticity of the session establishment report message sent to a RBC or a RIU shall be guaranteed. REQ FMEA ID 016 The integrity and authenticity of the session establishment report message sent to a RBC or a RIU shall be guaranteed.	



Safety Analyse

Non Confidentiel

Ref. : C592_NOTT_01

Version: 4A

Date : **14/11/2013**Page : **16 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
1 <u>6</u>	maintain communication	Absence / Loss / Inadvertent / Degraded	Communication is lost in case of loss of safe radio connection.	yes	Detectable	SIL-4	REQ_FMEA_ID_008 Communication session shall be safely maintained. REQ_FMEA_ID_008 Communication session shall be safely maintained.	
172	terminate communication	Absence / Loss-/ Degraded	Communication with another trackside equipment is not possible.	yes	Detectable	SIL-4	REQ_FMEA_ID_009 Terminate a communication session shall be safely defined. REQ_FMEA_ID_009 Terminate a communication session shall be safely defined.	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **17 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
1 <u>8</u> 3		Inadvertent	Transmission of data with trackside equipment fails.	yes	Detectable	SIL-4	REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication). REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication). REQ_FMEA_ID_009 Terminate a communication session shall be safely defined. REQ_FMEA_ID_009 Terminate a communication session shall be safely defined.	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **18 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
19		Degraded	The message termination_com_session_ms g is corrupted and the trackside does not take it into account. Another On-Board equipment may cannot initiate a communication session with the trackside due to the network congestion managed by the trackside.	yes	Detectable	SIL-4	REQ_FMEA_ID_009 Terminate a communication session shall be safely defined. REQ_FMEA_ID_009 Terminate a communication session shall be safely defined. REQ_FMEA_ID_017 The integrity and authenticity of the Termination of communication session message shall be guaranteed. REQ_FMEA_ID_017 The integrity and authenticity of the Termination of communication session message shall be guaranteed.	
<u>20</u> 14	release safe connection	Absence / Loss / Degraded	Safe connections are still active and new set-up of a safe connection fails due to the communications congestion. No safety impact as communication is terminated.	<u>yes</u> no	Detectable-	SIL- 4-	REQ_FMEA_ID_018 At the end of a communication session, the release of the safe connection shall be performed.REQ_FMEA_ID_018 At the end of a communication session, the release of the safe connection shall be performed.	



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **19 / 23**

#	Function	Failure mode	Effect	Hazard	Detectability	SIL	Safety Criteria	Comment
21 15		Inadvertent	Transmission of data with trackside equipment fails.	yes	Detectable	SIL-4	REQ_FMEA_ID_010 The release of the safe radio connection with trackside shall be performed only when the communication session is terminated. REQ_FMEA_ID_010 The release of the safe radio connection with trackside shall be performed only when the communication session is terminated.	
22 16	notify driver	Absence / Loss / Degraded	The driver is not informed of the state of the radio connection or the information is wrong because of the corruption of the data connection stat msg.	yes	Detectable	SIL-4	REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication). REQ_FMEA_ID_002 The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication).	
17 <u>23</u>		Inadvertent	NA	-	-	-	-	



Open ETCS - WP4 T4.4WP4 T4.4

Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013 Page : 20 / 23

4. SYSML MODEL

4.1. Functional decomposition

Function	Comment (equivalence with function defined in §3.1)
SessionStateManager	(notify driver)
EstablishingACommunicationSession	(establish communication)
MaintainingACommunicationSession	(maintain communication)
TerminatingACommunicationSession	(terminate communication)
RegisteringToTheRadioNetwork	(register mobile terminal) (set-up safe connection) (release safe connection)

4.2. Data

SysML Data	Comments (equivalence with data defined in §3.2.2)
Input flow	
OBU_Status	Inputs from onboard unit (OBU) components: Status, time
- powerAvailable	(power-up)
- M_Mode	(mode_change)
- M_Level	(manual_change_level) (front_end_change_level)
- systemVersionIsCompatible	(trackside_system_version)
- radioHoleStatus	(start_of_radio_hole) (end_of_radio_hole)
OrderToRM	Orders to MoRC from onboard or RBC
- orderFromOnboard	(start_of_mission) (end_of_mission)
- messageFromRBC	(trackside_establishment_request) (trackside_terminating_request) (trackside_terminating_ack) (init_com_session_msg_in)
- NID_RBC_ID	(RBC_id <mark>)</mark>



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : **14/11/2013**Page : **21 / 23**

RadioNetworkIDs	Radio network IDs memorized, from Driver, from Trackside (radio_network_identity)	
- radioNetworkID_memorized		
- radioNetworkID_fromDriver		
- radioNetworkID_fromTrackside		
SafeRadioComStatus	Status of the safe radio communication	
- setupEstablished	(communication_established) (communication_lost)	
- mobileHWConnectionStatus	(radio_connection_status)	
Output flow		
RM_Status	Actual status of the Management of Radio Communication	
- radioComSessionEstablished	(session_established_report_msg)	
- mobileSWStatus	(connection_stat_msg) (version_error_flag)	
OrderToRBC	Orders to RBC from MoRC	
- messageToRBC	(init_com_session_msg_out) (termination_com_session_msg) (version_msg)	
SafeRadioComCmd	Control commands to the safe radio communication and to the mobile	
- requestSetup	(radio_setup_request)	
- releaseSetup	(radio_release_request)	
- mobileHWCmd	<u>(radio network registration)</u>	
- actualRadioNetworkID	(radio_network_identity) (last_radio_network_identity)	
- memorizeTheLastRadioNetworkID	(last_radio_network_identity)	

4.3. FMEASEEA

Considering the similarities of the SysML Model and the safety model defined in section 3, no SEEA FMEA analyse will be performed on SysML Model for the moment.

5. SAFETY CRITERIA

REQ_FMEA_ID_001

The Mobile Terminal shall be safely registered to a Radio Network.

REQ_FMEA_ID_002

The driver shall be safely informed of the state of the radio communication (resulting of the different steps: registration of the Mobile Terminal to the Radio Network, establishment of the communication, end of communication).



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version : 4A

Date : **14/11/2013**Page : **22 / 23**

REQ_FMEA_ID_003

If a communication through a Radio Network is active, registration of the associated Mobile Terminal to another Radio Network mustn't be performed.

REQ_FMEA_ID_004

A safety protocol shall be used to performed communication between Mobile Terminal and Radio Network.

REQ FMEA_ID_005

If a communication with trackside equipment is active, set-up of safe radio connection with another trackside equipment mustn't be performed. Exception in case of handover with RBC.

REQ_FMEA_ID_006

Communication session with trackside equipment shall be safely established.

REQ_FMEA_ID_007

Establishment of communication session shall be performed when no communication is active. Exception in case of handover with RBC.

REQ_FMEA_ID_008

Communication session shall be safely maintained.

REQ_FMEA_ID_009

Terminate a communication session shall be safely defined.

REQ FMEA ID 010

The release of the safe radio connection with trackside shall be performed only when the communication session is terminated.

REQ_FMEA_ID_011

The compatibility and coherence of the safety protocol used to perform communication between Mobile Terminal and Radio Network shall be the verified.

REQ_FMEA_ID_012

The integrity and authenticity of the order message to contact a RBC or a RIU shall be guaranteed.

REQ_FMEA_ID_013

The freshness of the order message to contact a RBC or a RIU shall be guaranteed.

REQ FMEA ID 014

The order message to contact a RBC or a RIU shall be send in a safety defined time.

REQ FMEA ID 015

The compatibility and coherence of system version between On-Board and Trackside shall be verified. In case of error On-Board and Trackside shall be informed.

REQ FMEA ID 016

The integrity and authenticity of the session establishment report message sent to a RBC or a RIU shall be guaranteed.

REQ_FMEA_ID_017

The integrity and authenticity of the Termination of communication session message shall be guaranteed.



Safety Analyse

Non Confidentiel

Ref. : **C592_NOTT_01**

Version: 4A

Date : 14/11/2013 Page : 23 / 23

REQ_FMEA_ID_018

At the end of a communication session, the release of the safe connection shall be performed.

6. TRACEABILITY OF SAFETY CRITERIA WITH SRS

Safety criteria	SRS section
REQ_FMEA_ID_001	§3.5.6 ; §3.5.6.1; §3.5.6.3; §3.5.6.5; §3.5.6.6; §3.5.6.7
REQ_FMEA_ID_002	§3.5.3.8-b; §3.5.7 ; §3.5.7.1; §3.5.7.2;
REQ_FMEA_ID_003	§3.5.6.5
REQ_FMEA_ID_004	§3.5.1.1; §3.5.2.2
REQ_FMEA_ID_005	§3.5.3.5.2
REQ_FMEA_ID_006	§3.5.3 , §3.5.3.2, §3.5.3.4.1, §3.5.3.5.2, §3.5.3.7, §3.5.3.8
REQ_FMEA_ID_007	§3.5.3.5.2
REQ_FMEA_ID_008	§3.5.4
REQ_FMEA_ID_009	§3.5.5
REQ_FMEA_ID_010	§.3.5.5.2-c

END OF DOCUMENT