
## GEARBOX OUTPUT GEAR SUBASSEMBLY



ITEM NO	PART NUMBER	QTY	DESCRIPTION	NOTES
1	GEARBOX_OUTPUT_GEAR	1	GEARBOX OUTPUT GEAR	GEAR_BOX_OUTPUT_GEAR.STL
2	BEARING_608-2RS	1	BEARING 608-2RS	PRESS INTO CENTER OF OUTPUT GEAR
3	BHCS_M3_12MM	8	BUTTON HEAD CAP SCREW - M3 X 12mm	INSTALL AS SHOWN ABOVE
4	INSERT_M3	4	HEATSET INSERT - M3	INSTALL WITH SOLDERING IRON
5	NUT_M3	8	HEX NUT - M3	INSTALL AS SHOWN ABOVE