

# Disclaimer and Warnings

---

Warning! Jubilee requires 120V mains electricity. Working with mains electricity can be dangerous and we are in no way responsible for any form of injury or death related to use of or deviation from these source files and instructions. Also note that, depending on your country of operation, you may be in closer proximity to 220V mains electricity. While Jubilee can be readily adapted to this configuration, there are not instructions listing how to do so at this time.

---

Retrieved from "[https://jubilee3d.com/index.php?title=Disclaimer\\_and\\_Warnings&oldid=112](https://jubilee3d.com/index.php?title=Disclaimer_and_Warnings&oldid=112)"

---

This page was last edited on 7 May 2020, at 22:43.

Content is available under [Creative Commons Attribution](#) unless otherwise noted.