CALIFORNIA STATE POLYTECHNIC UNIVERSITY, POMONA COLLEGE OF ENGINEERING

ECE 3301L Spring 2024 Session 1 Microcontroller Lab

Felix Pinai

LAB3 Introduction to Assembly language

In this lab, we are going to write in Assembly language instead of C language.

We are going to use the same hardware connection as in Lab #2 with the exception that the connection to PORTE bit 0 (RE0) is connected to the Logic Analyzer 7

PART 1)

As you are familiar by now with the use of MPLAB X, you will need to do the same to compile an assembly program as follows:

- 1) Go to the Projects box.
- 2) Select the project Lab3p1
- 3) Right click and scroll down to 'Copy' and click on it
- 4) A box will appear with the name of the original project. Change the name of the Project to be 'lab3p1' to create part 1) of lab3
- 5) The project location should be with the new directory lab3\Part1
- 6) Select the button 'Copy' to create the new project
- 7) Once the new project is created, go to that project in the 'Projects' area and right click on that new project and scroll down to 'Set as Main Project' and click on that. After that, the project name should be in bold
- 8) Go back and select that project again and right click on it
- 9) Scroll all the way down to 'Properties'
- 10) A new window will pop up. On the right side under the 'Compiler Toolchain', instead of selecting the XC8 compiler, you will need to select the 'mpasm' option. select a version of the assembler under 'mpasm' and hit 'OK'
- 11) We are not going to use the C source code but instead the Assembly source code. Now you are at the step to add the new file, do File>New File. A new window will appear. Select 'Assembler' then 'AssemblyFile.asm' and hit Next. You will need to enter the new file name. In this case, I would call it 'Lab3p1'. Hit Finish.

The next phase is to create the assembly file. Copy the following text and paste into the file.

; THIS FIRST ASSEMBLY LANGUAGE PROGRAM WILL FLASH LEDS ; CONNECTED TO THE PINS 0 THROUGH 3 OF PORT B

#include<P18F4620.inc>

config	OSC = INTIO67
config	WDT = OFF
config	LVP = OFF
config	BOREN = OFF

; Constant declarations

Delay1	equ	0xFF
Delay2	equ	0XFF

Counter_L equ 0x20 Counter_H equ 0x21

ORG 0x0000

; CODE STARTS FROM THE NEXT LINE

START:

MOVLW	0x0F	;
MOVWF	ADCON1	;
MOVLW	0x00	;
MOVWF	TRISB	
MOVWF	TRISE	

MAIN_LOOP:

MOVLW	0x05	;
MOVWF	PORTB	;
MOVWF	PORTE	;

CALL DELAY_ONE_SEC ;

MOVLW 0x0A MOVWF PORTB MOVWF PORTE

CALL DELAY_ONE_SEC ;

```
MAIN LOOP
; the routine below is a subroutine and it is called 'DELAY_ONE_SEC'.
DELAY ONE SEC:
     MOVLW
                 Delay1
     MOVWF
                 Counter H
LOOP OUTER:
     NOP
     MOVLW
                 Delay2
     MOVWF
                 Counter_L
LOOP INNER:
     NOP
     DECF
                 Counter L,F
                 LOOP INNER
     BNZ
     DECF
                 Counter H,F
                 LOOP OUTER
     BNZ
     RETURN
; end of subroutine 'DELAY ONE SEC'
     END
```

Run and execute the program. Notice the 4 LEDs on PORT B blinking.

Start the Logic Analyzer and pay attention to channel 7 whereas it is connected to Port E bit 0. That signal will alternately change. Measure the time duration of the half period. Next, we want to make that time to be about 1 second with 25 milliseconds tolerance (+/-25 milliseconds). Go back to the assembly program and look for the variables Delay1 or Delay2. Modify either or both of those variables in order to make the time to be 1second. Capture the waveform for the report.

PART 2)

The next project is to implement the assembly code that is equivalent to part 1) of lab #2. In short, we are to read the three switches connected to PORT A and display them to the LEDs connected to PORTB.

C Code:

```
ADCON1 = 0x0F;
TRISA = 0xFF;
TRISB = 0x00;
```

Compile and run the following program (make sure that this is in a new folder called lab3p2):

```
; THIS SECOND ASSEMBLY LANGUAGE PROGRAM WILL READ THE VALUES OF ; ALL THE BITS 0-2 OF PORT A AND OUTPUT THEM ; TO THE PINS 0 THROUGH 2 OF PORT B
```

#include <P18F4620.inc>

```
 \begin{array}{ll} config & OSC = INTIO67 \\ config & WDT = OFF \\ config & LVP = OFF \\ config & BOREN = OFF \\ \end{array}
```

ORG 0x0000

START:

```
0x0F
    MOVLW
    MOVWF
              ADCON1
    MOVLW
              0xFF
              TRISA
    MOVWF
    MOVLW
              0x00
    MOVWF
              TRISB
MAIN_LOOP:
    MOVF
              PORTA, W
    ANDLW
              0x0F
    MOVWF
              PORTB
    GOTO
              MAIN_LOOP
    END
```

After you have compiled and downloaded the program into the board, change one switch at a time and check that the corresponding LED does change according to the logic state of the switch.

PART 3)

Next, your team will implement part 2) of Lab #2 in assembly.

Take the code in the above Part 2) and modify it to control the RGB LED D1 connected to PORTC. Just use the c code done in Lab #2 part 2) as reference and change it into assembly based on the example code provided above. Don't forget to add the additional TRISC to control the output of PORTC.

PART 4)

We will implement now the part 3) of Lab #2. We do need to write an infinite loop with an internal loop that count from 0 to 7 and then repeat itself while outputting that count to PORTC and then call a subroutine to delay 1 second.

The following program will implement the FOR loop by using an up counter saved at the location 0x28 and it is used as an index for the color to be outputted to the PORTC. Let us call that counter as 'Color_Value' and we will load with a starting value of 0.

We will use another counter at location 0x29h and we will call that counter 'Loop_Count' and we will initialize it with the value of 08h at the start.

The counter at Color_Value will be incremented by 1 each time through the loop while the counter Loop_Count will be decremented by 1. When it reaches the value of 0, the FOR loop is completed.

The subroutine 'DELAY_ONE_SEC' is called once a color is outputted to the port for the purpose of creating a long delay to allow the color to be displayed for a good amount of time. Remember that routine 'DELAY_ONE_SEC' can be copied from this lab's part 1. Make sure to use the adjusted values for Delay1 and Delay2

```
#include <P18F4620.inc>
config OSC = INTIO67
config WDT = OFF
config LVP = OFF
config BOREN = OFF

Counter_L equ 0x20
Counter_H equ 0x21
Color_Value equ 0x28
Loop_Count equ 0x29
```

ORG 0x0000

```
; CODE STARTS FROM THE NEXT LINE
START:
     ORG
                0x0000
START:
     MOVLW
                0x0F
     MOVWF
                ADCON1
     MOVLW
                0x00
     MOVWF
                TRISC
WHILE_LOOP:
                0x00
     MOVLW
                Color Value
     MOVWF
                0x08
     MOVLW
                Loop_Count
     MOVWF
FOR LOOP:
     MOVF
                Color Value,W
     MOVWF
                PORTC
     CALL
                DELAY_ONE_SEC
     INCF
                Color_Value,F
     DECF
                Loop Count,F
     BNZ
                FOR_LOOP
     GOTO
                WHILE LOOP
; add the code for 'DELAY_ONE_SEC' here
     END
```

Remember to add the code under 'DELAY_ONE_SEC' from part 1) of this lab to the above code (before 'END').

PART 5)

From the array(s) generated in lab #2 part 5), we will use its content to fill in two sequences of 8 values. For example for the first array of data, use an arbitrary location like 0x40. Put in the first value of the array at that location 0x40. Next, take the second value and place it at the next location 0x41. Repeat the process for the remaining values of the array. When completed, all the locations from 0x40 to 0x47 should have the values of the first array from the previous lab.

The next step is to repeat the same process for the second array and pick another starting location like 0x50.

For example, if the first two values of the first array is a10 and a11. We will need to move those two values to location 0x40 and 0x41. We will simply do the following:

MOVLW a10 MOVWF 0x40 MOVLW a11 MOVWF 0x41

Keep doing the same process with the 6 additional values for the first array. Next, repeat the same process for the 8 values of the second array and use the starting memory locations at 0x50.

After the creation of those two arrays are completed, now we will use the indirect addressing mode (with the registers FSR0 and FSR1) to fetch the color value to be outputted to the PORT(s) associated with the LEDs D2 and D3. Use the instruction:

LFSR x.address

Where 'x' can be 0,1,or 2 for the FSR0, FSR1, FSR2 respectively And 'address' is the value of the address where the FSR register needs to point to. Therefore, if we want to point FSR0 to the address 0x40, we will write:

LFSR 0.0x0040

Do the same for FSR1 to point to the address 0x50.

To fetch the data pointed by the FSR register into the W register, we will use the instruction:

MOVF INDFx, W

Where 'x' is the number of the FSR register.

Once the data is loaded in the W, then we can move the content of W into the appropriate port:

MOVWF PORTX

To increment the FSR register by 1 in order to point to the next value in the array, use the instruction:

INCF FSRxL

Use the code from Part 4) above to add the changes to implement the same function as in lab2 part 5).

Notes: Don't forget to program the TRISx registers used by the RGB LEDs D1 and D2.