

## Call Us:

(833) 227-3274

Live Chat With Us: www.CarAndDriverTech.com

**Email Us:** 

Support@CarAndDriverTech.com



Road Patrol Touch Duo



USER MANUAL-ENGLISH MODEL #: ZX-1222 & ZX-1002

# Read Me Important Safety Instructions

Read these instructions, Keep these instructions, Heed all warnings, Follow all instructions.

- This Product is not waterproof. Do not expose this product to Rain or Moisture.
- Do not block any ventilation openings.
- Install in accordance with the manufacturer's instructions.
- Do not install the device where it will block the driver's view of the road, mirrors or the deployment of airbags.
- Keep your attention on the road! Do not try to use or adjust any settings on the Road Patrol Touch Duo while the car is in motion.
- Ensure that the Road Patrol Touch Duo lens is kept clean and ensure that its field of view is clear of any obstructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Don't leave the device in direct sunlight for long periods of time.
- Best Operating temperatures will not exceed -20°F- 104°F.
- The user should reformat the SD card at least once a month to prevent the SD card from being stressed. Note: The user should back up all saved files before reformatting the card as doing this will delete all files.
- Never attempt to disassemble, repair or make any modifications to the Road Patrol Touch Duo as doing so will void the warranty.
- Use only attachments/accessories specified by the manufacturer.
- Unplug this device when unused for long periods of time.
- If repairs are necessary, please use qualified service personnel.
   Repairs may be necessary if the device has been damaged in any way. Such as the power-supply cord or plug being damaged, the device being exposed to rain or moisture, objects falling into the device, the device does not operate normally, or has been dropped.
- The Road Patrol Touch Duo is not compatible with Dash Cam Hardwire Kit's. You should not hardwired this device to your car.
   Note: This is not an action camera. It must be plugged into your vehicle at all times for proper use. The Road Patrol Touch duo will remain on for only a few seconds when unplugged.



### **Product Overview**



- 1. Micro USB Port
- 2. Rear Camera
- 3. Menu/Mode Button
- 4. Power Button
- 5. TF Card Slot
- 6. Microphone
- 7. Front Camera
- 8. Speaker
- 9. Infrared Light
- 10. Extension Mount
- 11. AUX Ports For Extension Cable
- 12. (2) Extension Cables (3 and 16 feet)

- 13. Headrest Elastic Band
- 14. Adhesive Cable Clips
- 15. Power Cable
- 16. (2) Suction Cup Mounts
- 17. USB Data Cable
- 18. LED Ring
- 19. Adhesive Disk

### Set-Up & Mount The Road Patrol Touch Duo

**Important Note:** The first mention of any accessories and parts will be followed by their corresponding number in { }. This will allow you to more easily identify the mentioned part using the product overview on page. 3.


# Connect The Road Patrol Touch Duo To The Suction Cup Mount.

Screw one of the provided Suction Cup Mounts {16} into the main body of the Road Patrol Touch Duo (Fig. 1).



#### Mount The Road Patrol Touch Duo On Your Windshield

Take the Suction Cup Mount with attached Road Patrol Touch Duo and verify that the lock on the suction cup is open (Fig. 2). Press the suction cup firmly onto your windshield by the rear view mirror and press the lock closed (Fig. 3) to secure the Road patrol Touch Duo in place.



# **Connect The Road Patrol Touch Duo To Your Car With The Power Cable**

Take the cigarette plug end of the Power Cable {15} and plug it into your car's cigarette outlet (Fig. 4). Take the other end of the power cable and plug it into the Road Patrol Touch Duo (Fig. 5). Make sure the cable is secured along the edge of the windshield and the headliner using the Adhesive Cable Clips {14}. As long as the car is powered On/Off the Road patrol Touch Duo will power On/Off as well.



## **Set-Up Rear Cam**

### **Option 1: Set-Up: Using Suction Cup**

### Remove The Rear Camera from The Road Patrol Touch Duo


Separate the Rear Camera {2} from the main body of the Road Patrol Touch Duo (Fig. 6).

Note: Be sure not to pull the Road Patrol Touch Duo from your windshield if you have previously mounted it.



# **Connect The Road Patrol Touch Duo To The Suction Cup Mount.**

Screw the second provided Suction Cup Mount into the Extension Mount {10}(Fig. 7). Then insert the Rear Camera into the Extension Mount (Fig. 8).




# **Connect The Road Patrol Touch Duo To The Extension Mount.**

Take the provided Extension Cable {12} and plug one end of it into the mounted Road Patrol Touch Duo (Fig. 9). Take The other end of the Extension cable and plug it into the Extension Mount (Fig. 10).




#### Selecting A Location For Your Rear Camera.

The Rear Camera can be mounted on either your windshield or your Rear Window. For suggested mounting locations and viewing angles see (Fig. 11) below.



### Mounting The Rear Camera On Your Rear Window.

Your Road Patrol Touch duo comes with an adhesive disk {19} so that you can mount your rear camera on the inside of your rear window. When mounting your rear camera in a location that has defroster lines (Fig. 12). We recommend that you peel the provided adhesive disk (Fig. 13) and apply it to the window (Fig. 14). This will better secure the suction cup even when it is experiencing temperature changes (Fig. 15). **Note:** You should wait 30 minutes after setting up the adhesive disk before installing the rear camera, as the adhesive needs time to set. Warning: The adhesive disk is meant only for use with the Road Patrol Touch Duo.






### Option 2: Set-Up: Using Headrest Elastic Band

Note: See "Remove The Rear Camera from The Road Patrol Touch Duo" on page 5.


# Insert The Elastic Band Into The Extension Mount Of The Road Patrol Touch Duo.

Thread the provided Headrest Elastic Band {13} into the Extension Mount {10} (Fig. 16). Then insert the Rear Camera {2} into the Extension Mount (Fig. 17).



# **Connect The Road Patrol Touch Duo To The Extension Mount.**

Take the provided Extension Cable {12} and plug one end of it into the mounted Road Patrol Touch Duo (Fig. 18). Take The other end of the Extension cable and plug it into the Extension Mount behind the elastic band (Fig. 19).



# Mount the Rear Camera On Either The Back Of The Driver's or Passenger's Headrest.

The Rear Camera {2} can be mounted on either the back of the driver's or passenger's headrest using the Headrest elastic band. See (Fig. 20) and (Fig. 21) below.



#### **Powering On The Road Patrol Touch Duo**

When the Road Patrol Touch Duo is connected to a car that it is powered On then the Road Patrol Touch Duo will power on as well. See "Connect The Road Patrol Touch Duo To Your Car With The Power Cable" on page 4.

A red charging indicator will begin flashing on the screen demonstrating that recording has begun.

Note: The user may also manually power On/Off the Road Patrol Touch Duo by pressing and holding the "Power" button for three seconds. *Note:* 

- > Format the Micro SD card before you start recording for the first time.
- > Be sure that the Micro SD card has been inserted properly before powering up the device.

#### **Power Off**

**Option 1:** When the car's engine is turned off, the device will automatically turn off shortly after.

**Option 2:** To manually power off the device press and hold the power button (4) for at least three seconds. Do not eject the SD card during this process as it may cause damage to the last recorded file.

Note: It will remain on just long enough to save the current recording.

### Main Menu















Touch any place on the screen to open the main menu		
Icon	Description	Feature
	Recording	Touch to turn on/off recording
	Photo Shooting	Touch to take photos.
	Audio	Touch to turn on/off audio recording.
	Lock Video	Touch during recording to lock the current recording file.
	Display Mode	Touch to swap between the Main Cameras and Rear Camera's view on screen.
	Playback	Touch to open the playback interface.
<b>(\$)</b>	System Setting	Touch to open system settings or press the "Menu" Button.

### Playback Folder



Touch any place on the screen to open the main menu. Then press to open playback mode.

Icon	Description	Feature
<b>←</b>	Back	Touch to back to return to the main interface.
^	Up	Page up.
~	Down	Page down.
<b>A</b>	Lock Video	Touch to lock the file you selected.

亩	Delete	Touch to delete the file you selected.
► (va	Front Video	Touch to play the Road Patrol Touch Duo's recordings.
▶ @	Rear Video	Touch to play the Rear Camera's recordings.
Pat Ca	Locked Front Video	Touch to view the Road Patrol Touch Duo's locked recordings.
Pat Car	Locked Rear Video	Touch to view the Rear Camera's locked recordings.
	Image	Touch to see images.

Note: While in the playback Folder all of the oldest video and images will be stored at the top while the newest ones will be saved at the bottom.

## System Setting Menu (3)



Touch any place on the screen to open the main menu, then		
Touch to open the Settings.		
Icon	Description	Feature
30FPS 1080P	Resolution	Touch to set recording resolution: 1) FHD 30fps. 2) HD 30fps. Default FHD 30fps.
-A)-	Exposure	Touch to set exposure: 2.0, 1.7, 1.3, 1.0, 0.7, 0.3, 0, -0.3, -0.7, -1.0, -1.3, -1.7, -2.0. Default 0.
3min	Loop Recording	Touch to set loop recording time: 1min/ 3min/ 5min. Default 3min.
	Record Audio	Touch to turn on/off audio recording. Default On.
-50HZ	Frequency	Touch to set frequency: 50Hz/60Hz. Default 50Hz.
EN	Language	Touch to set language. Default English.

	G-sensor	Touch to set G-sensor level: Off/ Low/ Middle/ High. Default Middle.
	Parking Mode	Touch to turn On/Off parking mode. In Parking Mode, the Road Patrol Touch duo will utilize the built in Gsensor to turn itself on and record (for up to ten seconds) in the event of an accident while parked.
SD =	Format SD-Card	Touch to format the inserted SD Card.
Φ,	Reset Settings	Touch to reset to default settings.
	Clock Settings	Touch to set date/time.
<b>"</b>	Volume	Touch to set beep volume: Off/ Low/ Middle/ High. Default Low.
Imin	Backlight	<ul> <li>Touch to set how long the screen will remain on when not in use.</li> <li>There are four settings. <ol> <li>Off. 2) 1 min. 3) 2 min. 4) 3 min. The default setting is Off.</li> <li>The screen may glow even when off. This is a characteristic of the high definition OLED touch screen.</li> </ol> </li> </ul>
i	FW Version	Touch to check the firmware version.
More Details On Page. 13	ADAS - Advanced Driver Assistance System (Drive Smart Alert System™)	Touch to turn On/Off the Lane Departure and Forward Collision Warning's. Which provide warnings when you are either drifting out of your lane or you are at risk of colliding with the car in front of you.
SD = 15 Days	Format SD Timer	Touch to set format SD warning: Off/ 15 Days/ 30 Days/ 60 Days. Default 30 Days.

<u>.</u>	Infrared Switch	Turn the Infrared feature On/ Off/ Auto. Default on
LED	LED	Turns the the LED ring On/ Off
	Legal & Regulatory	View Legal and regulatory information.




### ADAS - Advanced Driver Assistance System (Drive Smart Alert System™)

The Forward Collision Warning and the lane Departure warning are both part of the Drive Smart Alert System and can be turned On/Off in the System Settings Menu (3).

Forward Collision Warning: The Road Patrol Touch Duo will sound a warning when you are approaching within 12-14 feet of the driver in front of you.

Lane Departure Warning: Alerts you when your car veers from its lane. Two green lines will be displayed on screen (Fig. 22). These lines will line up with the lane lines on the road while driving.



#### Call Us:

(833) 227-3274

#### Live Chat With Us:

www.CarAndDriverTech.com

#### **Email Us:**

Support@CarAndDriverTech.com

#### **FCC Statement**

This device complies with part 15 of FCC Rules. Operation is subject to the following conditions.

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

#### SUMMIT ELECTRONICS LLC ONE YEAR LIMITED WARRANTY

SUMMIT ELECTRONICS LLC LIMITED WARRANTY ("Warranty") — For Product Categories Listed in Chart Below (as applicable, "Product") Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully. If you are still having trouble with your Product, please contact Technical Support at support @summitcegroup.com

**Warning**: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children.

Subject to the terms and conditions herein, SUMMIT ELECTRONICS LLC (hereinafter called "SUMMIT ELECTRONICS LLC") warrants to the original purchaser of the Product

("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects"). Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period for one year, to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable

Warranty Period, SUMMIT ELECTRONICS LLC will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable) either: (i) repair Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor

(as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and SUMMIT ELECTRONICS LLC's sole liability for breach of the limited warranty contained herein.

This Warranty specifically excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number: (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than SUMMIT ELECTRONICS LLC; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources,

God. Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. SUMMIT ELECTRONICS LLC disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify SUMMIT ELECTR-ONICS LLC for any damages claimed against SUMMIT ELECTRONICS LLC for such uses. EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS", AND SUMMIT ELECTRONICS LLC DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (I) OF MERCHANTABILITY, (II) OF FITNESS FOR A PARTICULAR PURPOSE, OR (III) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL SUMMIT ELECTRONICS LLC BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF SUMMIT ELECTRONICS LLC HAS BEEN ADV ISED OF THE POSSIBILITY OF SUCH DAMAGES, SUMMIT ELECTRONICS LLC'S AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCT CAUSING THE DAMAGES, IF ANY. This Warranty gives Customer specifics rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. To obtain Warranty service, Customer must email SUMMIT ELECTRONICS LLC Technical Support prior to making a Product return. Customer must include with Product return the following items (failure to enclose any of these items may result in a delay in the processing of your Warranty claim): (i) a dated sales receipt that indicates the place of purchase, model number of Product, and amount paid; (ii) a detailed description of Customer's problem with Product; (iii) Customer's full name, phone number, and return address, and; (iv) a money order made out to SUMMIT ELECTRONICS LLC Electronics Corporation to cover return shipping charges to US destinations only, for the applicable dollar amount shown for the Product in the table above. SUMMIT ELECTRONICS LLC will not make return shipments to a P.O. Box. For shipping to international addresses, actual freight will be charged to Customer. Return your Product freight-prepaid in its original packaging, or packaging that affords an equal measure of protection. Please allow 4 to 6 weeks for the processing of your claim (6 to 8 weeks from November to February).

You must email SUMMIT ELECTRONICS LLC Technical Support prior to making a return. Please ask if you are unsure of which category your product falls under \*US destinations only.