
LGF_Random_DInt

Short description

This function generates a random value with each call. The random number has the data type DINT.

Block



Output parameters

Parameters	Data type	Description	
Ret_Val	DINT	Random number	
error	BOOL	FALSE: No error TRUE: An error occurred during the execution of the FB.	
status	WORD	16#0000-16#7FFF: Status of the FB, 16#8000-16#FFFF: Error identification (see following Table).	
subFunctionStatus	WORD	Status or return value of the called FCs and system blocks.	

Status and error displays

status	Meaning	Remedy / notes
16#0000	No error	-
16#8600	Error in "RD_SYS_T" command.	Check the error code in "subFunctionStatus"

Note

The status of called commands is output in "subFunctionStatus". In this case, the output value in "status" indicates which command caused the error. In this case, refer to the TIA Portal Online Help section for information on the respective commands.

Principle of operation

The function generates random values in the range of $-2147483648 \le \text{Ret}_\text{Val} \le 2147483647$.

Background information

The random value is formed from the nanoseconds of the current system time of the CPU. The byte order of this value is inverted and then converted to DINT.

Further information on libraries in TIA Portal:

- Topic page libraries
 https://support.industry.siemens.com/cs/ww/en/view/109738702
- Guideline on Library Handling
 https://support.industry.siemens.com/cs/ww/en/view/109747503
- Programming Guideline for S7-1200/1500 in chapter "Libraries" https://support.industry.siemens.com/cs/ww/en/view/81318674
- Programming Styleguide
 https://support.industry.siemens.com/cs/ww/en/view/81318674