
LGF_DTLToUnixTime

Short description

This block converts the date and time of data type DTL to a Unix time of data type DInt. The timestamp is calculated in UTC. This means that the time zone is not taken into account.

Only times after 01/01/1990 are permitted.

Block



Input parameters

Parameters	Data type	Description
timeDTL	DTL	Date and time

Output parameters

Parameters	Data type	Description	
Ret_Val	DINT	Converted Unix time	
error	BOOL	FALSE: No error	
		TRUE: An error occurred during the execution of the FB.	
status	WORD	16#0000-16#7FFF: Status of the FB,	
		16#8000-16#FFFF: Error identification (see following Table).	

Status and error displays

Status	Meaning	Remedy
16#0000	No error.	-
16#8000	Unix time (timeUnix) is before 01/01/1990	-

Further information on libraries in TIA Portal:

- Topic page libraries
 https://support.industry.siemens.com/cs/ww/en/view/109738702
- Guideline on Library Handling
 https://support.industry.siemens.com/cs/ww/en/view/109747503
- Programming Guideline for S7-1200/1500 in chapter "Libraries" https://support.industry.siemens.com/cs/ww/en/view/81318674
- Programming Styleguide
 https://support.industry.siemens.com/cs/ww/en/view/81318674