Note: Photo must fit GUI

○ Monochrome

○ Bloom

○ Sepia

○

○

[Cancel] [Apply]

* White Border Display photo

Camera: _____

Shutter speed: //

V[_____] [✓]

ISO: _____

[_____] [✓]

Camera Mode: _____

[auto] [manual] [____]

[Filter] [Reset] [Show file location]

default 3S

Set Timer: [_____]

Min: Max:

Take Photo after Distance [_____]

[Start]