# Control Systems L7: Transient and Steady State Response Analyses

Daro VAN

Phnom Penh, May 17th, 2020

### Outline

- Introduction
- First Order Systems
- Second Order Systems
- Servo System with Velocity Feedback
- 5 Transient-Response Analysis with MATLAB

Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (chapter 5)

### Outline

- Introduction
- 2 First Order Systems
- Second Order Systems
- Servo System with Velocity Feedback
- 5 Transient-Response Analysis with MATLAB

Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (chapter 5)

**Analyzing Control Systems** 

**Mathematical Models** 

**Analyzing Control Systems** 

**Mathematical Models** 



Analysis of system performance (various control systems)

**Typical Test Signals** 

### The commonly used test input signals are:

- Step functions
- Ramp functions
- Impulse functions
- Acceleration functions
- Sinusoidal functions
- White noise

#### Typical Test Signals

The commonly used test input signals are:

- Step functions
- Ramp functions
- Impulse functions
- Acceleration functions
- Sinusoidal functions
- White noise

With these test signals, mathematical and experimental analyses of control systems can be carried out easily, since the signals are very simple functions of time.

Note: We will use the signals marked blue.

Tansient Response and Steady State Response

The time response of a control system consists of two parts:

- Transient response (from initial state to final state)
- Steady-state response (t approach infinity)

#### **Tansient Response and Steady State Response**

The time response of a control system consists of two parts:

- Transient response (from initial state to final state)
- Steady-state response (t approach infinity)

Thus, the system response c(t) may be written as

$$c(t) = c_{tr}(t) + c_{ss}(t) \tag{1}$$

where the first term on the right-hand side of the equation is the transient response and the second term is the steady-state response.

Absolute Stability, Relative Stability, and Steady-State Error

knowledge of the components

Absolute Stability, Relative Stability, and Steady-State Error

knowledge of the components



Dynamic behavoir of the system

Absolute Stability, Relative Stability, and Steady-State Error

knowledge of the components

Dynamic behavoir of the system

 $\Downarrow$ 

absolute stability

(whether the system is stable or unstable?)

Absolute Stability, Relative Stability, and Steady-State Error

knowledge of the components

Upnamic behavoir of the system

absolute stability

(whether the system is stable or unstable?)

• A control system is in equilibrium if, in the absence of any disturbance or input, the output stays in the same state.

Absolute Stability, Relative Stability, and Steady-State Error

knowledge of the components ↓ Dynamic behavoir of the system

↓↓
absolute stability
(whether the system is stable or unstable?)

- A control system is in equilibrium if, in the absence of any disturbance or input, the output stays in the same state.
- A LTI system is stable if the output eventually comes back to its equilibrium state when the system is subjected to an initial condition.

Absolute Stability, Relative Stability, and Steady-State Error

knowledge of the components
↓

Dynamic behavoir of the system

↓↓
 absolute stability
(whether the system is stable or unstable?)

- A control system is in equilibrium if, in the absence of any disturbance or input, the output stays in the same state.
- A LTI system is stable if the output eventually comes back to its equilibrium state when the system is subjected to an initial condition.
- A LIT is critically stable if oscillations of the output continue forever.

Absolute Stability, Relative Stability, and Steady-State Error

knowledge of the components

↓

Dynamic behavoir of the system

↓↓
 absolute stability
(whether the system is stable or unstable?)

- A control system is in equilibrium if, in the absence of any disturbance or input, the output stays in the same state.
- A LTI system is stable if the output eventually comes back to its equilibrium state when the system is subjected to an initial condition.
- A LIT is critically stable if oscillations of the output continue forever.
- It is unstable if the output diverges without bound from its equilibrium state when the system is subjected to an initial condition.

Absolute Stability, Relative Stability and Steady State Error

Important system behavior (other than absolute stability) to which we must give careful consideration includes relative stability and steady-state error.

Absolute Stability, Relative Stability and Steady State Error

Important system behavior (other than absolute stability) to which we must give careful consideration includes relative stability and steady-state error.

Since a physical control system involves energy storage, the output of the system, when subjected to an input, cannot follow the input immediately but exhibits a transient response before a steady state can be reached.

Absolute Stability, Relative Stability and Steady State Error

Important system behavior (other than absolute stability) to which we must give careful consideration includes relative stability and steady-state error.

Since a physical control system involves energy storage, the output of the system, when subjected to an input, cannot follow the input immediately but exhibits a transient response before a steady state can be reached. If


the output of a system at steady state does not exactly agree with the input, the system is said to have steady-state error. This error is indicative of the accuracy of the system.

# Outline


- Introduction
- 2 First Order Systems
- Second Order Systems
- Servo System with Velocity Feedback
- 5 Transient-Response Analysis with MATLAB

Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (chapter 5)

Consider the first-order system shown below



Consider the first-order system shown below



The input-output relationship is given by

$$\frac{C(s)}{R(s)} = \frac{1}{Ts+1} \tag{2}$$

In the following, we shall analyze the system responses to such inputs as the unit-step, unit-ramp, and unit-impulse functions. The initial conditions are assumed to be zero.

Unit-Step Response of First Order Systems

Since the Laplace transform of the unit-step function is 1/s, substituting R(s) = 1/s into Equation (2), we obtain

$$C(s) = \frac{1}{Ts+1} \frac{1}{s}$$

#### Unit-Step Response of First Order Systems

Since the Laplace transform of the unit-step function is 1/s, substituting R(s) = 1/s into Equation (2), we obtain

$$C(s) = \frac{1}{Ts+1} \frac{1}{s}$$

Expanding C(s) into partial fractions gives

$$C(s) = \frac{1}{s} - \frac{T}{Ts+1} = \frac{1}{s} - \frac{1}{s+(1/T)}$$
 (3)

#### Unit-Step Response of First Order Systems

Since the Laplace transform of the unit-step function is 1/s, substituting R(s) = 1/s into Equation (2), we obtain

$$C(s) = \frac{1}{Ts+1} \frac{1}{s}$$

Expanding C(s) into partial fractions gives

$$C(s) = \frac{1}{s} - \frac{T}{Ts+1} = \frac{1}{s} - \frac{1}{s+(1/T)}$$
 (3)

Taking the inverse Laplace transform, we obtain

$$c(t) = 1 - e^{-t/T}, t \ge 0$$
 (4)

when

$$t = 0$$

$$t=0$$
  $c(t)=0$ 

when

$$t = T$$
  $c(t) = 0.632$ 

#### Unit-Step Response of First Order Systems

Since the Laplace transform of the unit-step function is 1/s, substituting R(s) = 1/s into Equation (2), we obtain

$$C(s) = \frac{1}{Ts+1} \frac{1}{s}$$

Expanding C(s) into partial fractions gives

$$C(s) = \frac{1}{s} - \frac{T}{Ts+1} = \frac{1}{s} - \frac{1}{s+(1/T)}$$
 (3)

Taking the inverse Laplace transform, we obtain

$$c(t) = 1 - e^{-t/T}, t \ge 0$$
 (4)

when


$$t = 0$$

$$t=0$$
  $c(t)=0$ 


$$t = T$$
  $c(t) = 0.632$ 

The response c(t) reaches 63.2% of its total change.

Unit-Step Response of First-Order Systems




#### Unit-Step Response of First-Order Systems




 The smaller the time constant T, the faster the system response

#### Unit-Step Response of First-Order Systems



- The smaller the time constant T, the faster the system response
- The slope of the response curve c(t) decrease monotonically from 1/T at t=0 to 0 at  $t=\infty$ .

#### Unit-Step Response of First-Order Systems



- The smaller the time constant T, the faster the system response
- The slope of the response curve c(t) decrease monotonically from 1/T at t=0 to 0 at  $t=\infty$ .
- In practice, a reasonable estimate of the response time is the length of time the response curve needs to reach and stay within the 2%line of the final value.

Unit-Ramp Response of First-Order Systems

Since the Laplace Transform of the unit-ramp function is  $1/s^2$ , we obtain the output of the system as

$$C(s) = \frac{1}{Ts + 1} \frac{1}{s^2} \tag{5}$$

#### Unit-Ramp Response of First-Order Systems

Since the Laplace Transform of the unit-ramp function is  $1/s^2$ , we obtain the output of the system as

$$C(s) = \frac{1}{Ts + 1} \frac{1}{s^2} \tag{5}$$

Expanding C(s) into partial fractions gives

$$C(s) = \frac{1}{s^2} - \frac{T}{s} + \frac{T^2}{Ts+1} \tag{6}$$

#### Unit-Ramp Response of First-Order Systems

Since the Laplace Transform of the unit-ramp function is  $1/s^2$ , we obtain the output of the system as

$$C(s) = \frac{1}{Ts + 1} \frac{1}{s^2} \tag{5}$$

Expanding C(s) into partial fractions gives

$$C(s) = \frac{1}{s^2} - \frac{T}{s} + \frac{T^2}{Ts + 1} \tag{6}$$

Taking the inverse Laplace transform, we obtain

$$c(t) = t - T + Te^{-t/T}, t \ge 0$$
(7)

#### Unit-Ramp Response of First-Order Systems

Since the Laplace Transform of the unit-ramp function is  $1/s^2$ , we obtain the output of the system as

$$C(s) = \frac{1}{Ts + 1} \frac{1}{s^2} \tag{5}$$

Expanding C(s) into partial fractions gives

$$C(s) = \frac{1}{s^2} - \frac{T}{s} + \frac{T^2}{Ts+1} \tag{6}$$

Taking the inverse Laplace transform, we obtain


$$c(t) = t - T + Te^{-t/T}, t \ge 0 \tag{7}$$

13/60


The error signal e(t) is then

$$e(t) = r(t) - c(t)$$
$$= T(1 - e^{-t/T})$$

Unit-Ramp Response of First-Order Systems




#### Unit-Ramp Response of First-Order Systems



• As t approaches infinity,  $e^{t/T}$  approaches zero, and thus the error signal e(t) approaches T or

$$e(\infty) = T$$

#### Unit-Ramp Response of First-Order Systems




As t approaches infinity, e<sup>t/T</sup> approaches zero, and thus the error signal e(t) approaches T or

$$e(\infty) = T$$

 The error in following the unit-ramp input is equal to T for sufficiently large t.

#### Unit-Ramp Response of First-Order Systems



As t approaches infinity, e<sup>t/T</sup> approaches zero, and thus the error signal e(t) approaches T or

$$e(\infty) = T$$

 The error in following the unit-ramp input is equal to T for sufficiently large t.

The smaller the time constant T, the smaller the steady-state error in following the ramp input.

Unit-Impulse Response of First Order Systems

For the unit-impulse input, R(s) = 1 and the output of the system can be obtained as


$$C(s) = \frac{1}{Ts + 1} \tag{8}$$

For the unit-impulse input, R(s) = 1 and the output of the system can be obtained as

$$C(s) = \frac{1}{Ts + 1} \tag{8}$$

The inverse Laplace Transform of Equation (8) gives

$$c(t) = \frac{1}{T}e^{-t/T}, t \ge 0 \tag{9}$$



#### An Important Property of Linear Time Invariant Systems (LTI Systems)

It has been shown that the response of

• unit-ramp input is 
$$c(t) = t - T + Te^{-t/T}, t \ge 0$$

- unit-step input is  $c(t) = 1 e^{-t/T}, \ge 0$
- unit-impulse input is  $c(t) = \frac{1}{7}e^{-t/T}, t \ge 0$

Note:This is a property of linear time-invariant systems. Linear time-varying systems and nonlinear systems do not possess these properties.

#### An Important Property of Linear Time Invariant Systems (LTI Systems)

It has been shown that the response of

- unit-ramp input is  $c(t) = t T + Te^{-t/T}, t \ge 0$
- unit-step input is  $c(t) = 1 e^{-t/T}, \ge 0$
- unit-impulse input is  $c(t) = \frac{1}{7}e^{-t/T}, t \ge 0$

Note:This is a property of linear time-invariant systems. Linear time-varying systems and nonlinear systems do not possess these properties. It can be seen that

 The response to the derivative of an input signal can be obtained by differentiating the response of the system to the original signal.

An Important Property of Linear Time Invariant Systems (LTI Systems)

It has been shown that the response of

- unit-ramp input is  $c(t) = t T + Te^{-t/T}, t \ge 0$
- unit-step input is  $c(t) = 1 e^{-t/T}, \ge 0$
- unit-impulse input is  $c(t) = \frac{1}{7}e^{-t/T}, t \ge 0$

Note:This is a property of linear time-invariant systems. Linear time-varying systems and nonlinear systems do not possess these properties. It can be seen that

- The response to the derivative of an input signal can be obtained by differentiating the response of the system to the original signal.
- The response to the integral of the original signal can be obtained by integrating the response of the system to the original signal and by determining the integration constant from the zero-output initial condition.

#### Outline

- Introduction
- 2 First Order Systems
- Second Order Systems
- Servo System with Velocity Feedback
- 5 Transient-Response Analysis with MATLAB


Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (chapter 5)

In this section, we shall obtain the response of a typical second-order control system to

- Step input
- Ramp input
- Impulse input


Servo System

The servo system consists of a proportional controllers and load elements (inertia and viscous-friction elements)



Servo System

The servo system consists of a proportional controllers and load elements (inertia and viscous-friction elements)



Suppose that we wish to control the output position c in accordance with the input position r. The equation for the load elements is

$$J\ddot{c} + B\dot{c} = T$$

where T is the torque produced by the proportional controller whose gain is K.

Servo System

By taking Laplace transforms of both sides of this last equation, assuming the zero initial conditions, we obtain

$$Js^2C(s) + BsC(s) = T(s)$$

Servo System

By taking Laplace transforms of both sides of this last equation, assuming the zero initial conditions, we obtain


$$Js^2C(s) + BsC(s) = T(s)$$

then,

$$\frac{C(s)}{T(s)} = \frac{1}{s(Js+B)}$$

By using this transfer function, can you find  $\frac{C(s)}{R(s)}$ ?


Servo System



The closed-loop transfer function is then obtained as

$$\frac{C(s)}{R(s)} = \frac{K}{Js^2 + Bs + K}$$
$$= \frac{K/J}{s^2 + (B/J)s + (K/J)}$$

Servo System



The closed-loop transfer function is then obtained as

$$\frac{C(s)}{R(s)} = \frac{K}{Js^2 + Bs + K}$$
$$= \frac{K/J}{s^2 + (B/J)s + (K/J)}$$

Such a system where the closed-loop transfer function possesses two poles is called a second-order system.

Step Response of Second Order System

The closed-loop transfer function of the system shown in Figure (c) is

$$\frac{C(s)}{R(s)} = \frac{K}{Js^2 + Bs + K} \tag{10}$$

The closed-loop transfer function of the system shown in Figure (c) is

$$\frac{C(s)}{R(s)} = \frac{K}{Js^2 + Bs + K} \tag{10}$$

which can be rewritten as

$$\frac{C(s)}{R(s)} = \frac{\frac{K}{J}}{\left(s + \frac{B}{2J} + \sqrt{\left(\frac{B}{2J}\right)^2 - \frac{K}{J}}\right)\left(s + \frac{B}{2J} - \sqrt{\left(\frac{B}{2J}\right)^2 - \frac{K}{J}}\right)} \tag{11}$$

The closed-loop poles are complex conjugate if  $B^2-4JK<0$  and they are real if  $B^2-4JK\geqq0$ 

Step Response of Second Order System

In the transient-response analysis, it is convenient to write

$$\frac{K}{J} = \omega_n^2, \frac{B}{J} = 2\zeta\omega_n = 2\sigma$$

where  $\sigma$  is called the attenuation,  $\omega_n$  is called the undamped natural frequency and  $\zeta$  is called damping ratio of the system.

Step Response of Second Order System

In the transient-response analysis, it is convenient to write

$$\frac{K}{J} = \omega_n^2, \frac{B}{J} = 2\zeta\omega_n = 2\sigma$$


where  $\sigma$  is called the attenuation,  $\omega_n$  is called the undamped natural frequency and  $\zeta$  is called damping ratio of the system.

The damping ratio  $\zeta$  is the ratio of the actual damping B to the critical damping  $B_c = 2\sqrt{JK}$  or

$$\zeta = \frac{B}{B_c} = \frac{B}{2\sqrt{JK}}$$


Step Response of Second Order System

In term of  $\zeta$  and  $\omega_n$ , the system (c) can be modified to a generic form



Step Response of Second Order System

In term of  $\zeta$  and  $\omega_n$ , the system (c) can be modified to a generic form



Step Response of Second Order System

and the closed loop transfer function given in equation (10) can be written as

$$\frac{C(s)}{R(s)} = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{12}$$

This form is called standard form of the second-order system.

Step Response of Second Order System

and the closed loop transfer function given in equation (10) can be written as

$$\frac{C(s)}{R(s)} = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{12}$$

25/60

This form is called standard form of the second-order system.

The dynamic behavior of the second-order system can then be described in terms of two parameters  $\zeta$  and  $\omega_n$ .

Step Response fo Second-Order System

• If  $0 < \zeta < 1$ , the closed-loop poles are complex conjugates and lie in the left-half s plane. The system is called underdamped, and the transient response is oscillatory.

Step Response fo Second-Order System

• If  $0 < \zeta < 1$ , the closed-loop poles are complex conjugates and lie in the left-half s plane. The system is called underdamped, and the transient response is oscillatory.

• If  $\zeta = 0$ , the transient response does not die out.

Step Response fo Second-Order System


- If  $0 < \zeta < 1$ , the closed-loop poles are complex conjugates and lie in the left-half s plane. The system is called underdamped, and the transient response is oscillatory.
- If  $\zeta = 0$ , the transient response does not die out.
- if  $\zeta = 1$ , the system is called critically damped.

Step Response fo Second-Order System

- If  $0 < \zeta < 1$ , the closed-loop poles are complex conjugates and lie in the left-half s plane. The system is called underdamped, and the transient response is oscillatory.
- If  $\zeta = 0$ , the transient response does not die out.
- if  $\zeta = 1$ , the system is called critically damped.
- If  $\zeta > 1$ , the system is overdamped.

Step Response of Second-Order System

We shall now solve for the response of the system shown below



#### Step Response of Second-Order System

• Underdamped case (o <  $\zeta$  < 1): In the case, C(s)/R(s) can be written

$$\frac{C(s)}{R(s)} = \frac{\omega_n^2}{(s + \zeta \omega_n + j\omega_d)(s + \zeta \omega_n - j\omega_d)}$$

where  $\omega_d = \omega_n \sqrt{1 - \zeta^2}$ .  $\omega_d$  is called damped natural frequency.

#### Step Response of Second-Order System

• Underdamped case (o <  $\zeta$  < 1): In the case, C(s)/R(s) can be written

$$\frac{C(s)}{R(s)} = \frac{\omega_n^2}{(s + \zeta \omega_n + j\omega_d)(s + \zeta \omega_n - j\omega_d)}$$

where  $\omega_d = \omega_n \sqrt{1 - \zeta^2}$ .  $\omega_d$  is called damped natural frequency. For unit-step input, C(s) can be written as

$$C(s) = \frac{\omega_n^2}{(s^2 + 2\zeta\omega_n s + \omega_n^2)s}$$
(13)

#### Step Response of Second-Order System

• Underdamped case (o <  $\zeta$  < 1): In the case, C(s)/R(s) can be written

$$\frac{C(s)}{R(s)} = \frac{\omega_n^2}{(s + \zeta \omega_n + j\omega_d)(s + \zeta \omega_n - j\omega_d)}$$

where  $\omega_d = \omega_n \sqrt{1 - \zeta^2}$ .  $\omega_d$  is called damped natural frequency. For unit-step input, C(s) can be written as

$$C(s) = \frac{\omega_n^2}{(s^2 + 2\zeta\omega_n s + \omega_n^2)s}$$
(13)

28/60

The inverse Laplace transform can be obtained easily if C(s) is written in the following form:

$$C(s) = \frac{1}{s} - \frac{s + 2\zeta\omega_n}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$
$$= \frac{1}{s} - \frac{s + \zeta\omega_n}{(s + \zeta\omega_n)^2 + \omega_d^2} - \frac{\zeta\omega_n}{(s + \zeta\omega_n)^2 + \omega_d^2}$$

Step Response of Second-Order System

Referring to the Laplace transform Table, it can be shown that

$$\mathcal{L}^{-1}\left[\frac{s + \zeta \omega_n}{(s + \zeta \omega_n)^2 + \omega_d^2}\right] = e^{-\zeta \omega_n t} \cos \omega_d t$$

$$\mathcal{L}^{-1}\left[\frac{\omega_d}{(s + \zeta \omega_n)^2 + \omega_d^2}\right] = e^{-\zeta \omega_n t} \sin \omega_d t$$

Step Response of Second-Order System

Referring to the Laplace transform Table, it can be shown that

$$\mathcal{L}^{-1}\left[\frac{s+\zeta\omega_n}{(s+\zeta\omega_n)^2+\omega_d^2}\right] = e^{-\zeta\omega_n t}\cos\omega_d t$$

$$\mathcal{L}^{-1}\left[\frac{\omega_d}{(s+\zeta\omega_n)^2+\omega_d^2}\right] = e^{-\zeta\omega_n t}\sin\omega_d t$$

Hence, the inverse Laplace transform of C(s) is obtained

$$\mathcal{L}^{-1}[C(s)] = c(t)$$

$$= 1 - e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_d t)$$

$$= 1 - \frac{e^{-\zeta \omega_n t}}{\sqrt{1 - \zeta^2}} \sin(\omega_d t + \tan^{-1} \frac{\sqrt{1 - \zeta^2}}{\zeta}), t \ge 0$$
(14)

Step Response of Second-Order System

It can be seen that the frequency of transient oscillation is the damped natural frequency  $\omega_d$  and thus varies with the damping ratio  $\zeta$ . The error signal for this system is the difference between the input and output and is

$$e(t) = r(t) - c(t)$$

$$= e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_d t), t \ge 0$$

Step Response of Second-Order System

It can be seen that the frequency of transient oscillation is the damped natural frequency  $\omega_d$  and thus varies with the damping ratio  $\zeta$ . The error signal for this system is the difference between the input and output and is

$$e(t) = r(t) - c(t)$$

$$= e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_d t), t \ge 0$$

This error signal exhibits a damped sinusoidal oscillation.

Step Response of Second-Order System

It can be seen that the frequency of transient oscillation is the damped natural frequency  $\omega_d$  and thus varies with the damping ratio  $\zeta$ . The error signal for this system is the difference between the input and output and is

$$e(t) = r(t) - c(t)$$

$$= e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_d t), t \ge 0$$

This error signal exhibits a damped sinusoidal oscillation.

• At steady state, or at  $t=\infty$ , no error exists between the input and output.

Step Response of Second-Order System

It can be seen that the frequency of transient oscillation is the damped natural frequency  $\omega_d$  and thus varies with the damping ratio  $\zeta$ . The error signal for this system is the difference between the input and output and is

$$e(t) = r(t) - c(t)$$

$$= e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_d t), t \ge 0$$

This error signal exhibits a damped sinusoidal oscillation.

- At steady state, or at  $t=\infty$ , no error exists between the input and output.
- If the damping ratio  $\zeta$  is equal to zero, the response becomes undamped oscillations continue indefinitely. The response c(t) for zero damping can be found as

$$c(t) = 1 - \cos \omega_n t, t \ge 0 \tag{15}$$

Step Response of Second-Order System

• Critically damped case ( $\zeta = 1$ ): If the two poles of C(s)/R(s) are equal, the system is said to be critically damped one.

Step Response of Second-Order System

• Critically damped case ( $\zeta = 1$ ): If the two poles of C(s)/R(s) are equal, the system is said to be critically damped one.

For a unit-step input, R(s) = 1/s and C(s) can be written as

$$C(s) = \frac{\omega_n^2}{(s + \omega_n)^2 s} \tag{16}$$

• Critically damped case ( $\zeta = 1$ ): If the two poles of C(s)/R(s) are equal, the system is said to be critically damped one.

For a unit-step input, R(s) = 1/s and C(s) can be written as

$$C(s) = \frac{\omega_n^2}{(s + \omega_n)^2 s} \tag{16}$$

The inverse Laplace transform can be found as

$$c(t) = 1 - e^{-\omega_n t} (1 + \omega_n t), t \ge 0$$
 (17)

Step Response of Second-Order System

• Overdamped case ( $\zeta > 1$ ): In this case, the two poles of C(s)/R(s) are negative real and unequal. For a unit-step input, R(s) = 1/s and C(s) can be written

$$C(s) = \frac{\omega_n^2}{(s + \zeta \omega_n + \omega_n \sqrt{\zeta^2 - 1})(s + \zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1})s}$$
(18)

• Overdamped case ( $\zeta > 1$ ): In this case, the two poles of C(s)/R(s) are negative real and unequal. For a unit-step input, R(s) = 1/s and C(s) can be written

$$C(s) = \frac{\omega_n^2}{(s + \zeta \omega_n + \omega_n \sqrt{\zeta^2 - 1})(s + \zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1})s}$$
 (18)

The inverse Laplace transform of equation (18) is

$$c(t) = 1 + \frac{1}{2\sqrt{\zeta^2 - 1}(\zeta + \sqrt{\zeta^2 - 1})}e^{-(\zeta + \sqrt{\zeta^2 - 1})\omega_n t}$$

$$-\frac{1}{2\sqrt{\zeta^2 - 1}(\zeta - \sqrt{\zeta^2 - 1})}e^{-(\zeta - \sqrt{\zeta^2 - 1})\omega_n t}$$

$$c(t) = 1 + \frac{\omega_n}{2\sqrt{\zeta^2 - 1}}(\frac{e^{-s_1 t}}{s_1} - \frac{e^{-s_2 t}}{s_2}), t \ge 0$$
where  $s_1 = (\zeta + \sqrt{\zeta^2 - 1})\omega_n$  and  $s_2 = (\zeta - \sqrt{\zeta^2 - 1})\omega_n$ 

Step Response of Second-Order System

• When  $\zeta$  is appreciably greater than unity, one of the two decaying exponentials decreases much faster than the other, so the faster-decaying exponential term may be neglected. That is, if  $s_2$  is located very much closer to the  $j\omega$  axis than  $s_1$  (which means  $|s_2|\gg |s_1|$ ), then for an approximate solution we may neglect  $s_1$ .

Step Response of Second-Order System

- When  $\zeta$  is appreciably greater than unity, one of the two decaying exponentials decreases much faster than the other, so the faster-decaying exponential term may be neglected. That is, if  $s_2$  is located very much closer to the  $j\omega$  axis than  $s_1$  (which means  $|s_2| \gg |s_1|$ ), then for an approximate solution we may neglect  $s_1$ .
- This is permissible because the effect of  $s_1$  on the response is much smaller than that of  $s_2$ , since the term involving  $s_1$  decays much faster than the term involving  $s_2$ .

### Step Response of Second-Order System

- When  $\zeta$  is appreciably greater than unity, one of the two decaying exponentials decreases much faster than the other, so the faster-decaying exponential term may be neglected. That is, if  $s_2$  is located very much closer to the  $j\omega$  axis than  $s_1$  (which means  $|s_2| \gg |s_1|$ ), then for an approximate solution we may neglect  $s_1$ .
- This is permissible because the effect of  $s_1$  on the response is much smaller than that of  $s_2$ , since the term involving  $s_1$  decays much faster than the term involving  $s_2$ .
- Once the faster-decaying exponential term has disappeared, the response is similar to that of a first-order system, and C(s)/R(s) may be approximated by

$$\frac{C(s)}{R(s)} = \frac{\zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1}}{s + \zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1}} = \frac{s_2}{s + s_1}$$

Step Response of Second Order Systems

With the appropriate transfer function  $\frac{C(s)}{R(s)}$ , the unit-step response can be obtained as


$$C(s) = \frac{\zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1}}{(s + \zeta \omega_n - \omega_n \sqrt{\zeta^2 - 1})s}$$

The time response c(t) is then

$$c(t) = 1 - e^{-(\zeta - \sqrt{\zeta^2 - 1})\omega_n t}$$
, for  $t \ge 0$ 

This gives an approximate unit-step response when one of the poles of C(s)/R(s) can be neglected.

**Definition of Transient-Response Specifications** 



Unit-step response curve showing  $t_d$ ,  $t_r$ ,  $t_p$ ,  $M_p$  and  $t_s$ 

Definition of Transient-Response Specifications

• Delay time,  $t_d$ : the time required for the response to reach half the final value the very first time.

**Definition of Transient-Response Specifications** 

- Delay time,  $t_d$ : the time required for the response to reach half the final value the very first time.
- Rise time,  $t_r$ : the time required for the response to rise from 10% to 90%, 5% to 95%, or 0% to 100% of its final value. For underdamped secondorder systems, the 0% to 100% rise time is normally used. For overdamped systems, the 10% to 90% rise time is commonly used.

**Definition of Transient-Response Specifications** 

- Delay time, $t_d$ : the time required for the response to reach half the final value the very first time.
- Rise time,  $t_r$ : the time required for the response to rise from 10% to 90%, 5% to 95%, or 0% to 100% of its final value. For underdamped secondorder systems, the 0% to 100% rise time is normally used. For overdamped systems, the 10% to 90% rise time is commonly used.
- Peak time,  $t_p$ : the time required for the response to reach the first peak of the overshoot.

## Definition of transient-Response Specification

• Maximum overshoot,  $M_p$ : the maximum peak value of the response curve measured from unity. If the final steady-state value of the response differs from unity, then it is common to use the maximum percent overshoot. It is defined by

Maximum percent overshoot =  $\frac{c(t_\rho)-c(\infty)}{c(\infty)} \times 100\%$ 

## Definition of transient-Response Specification

• Maximum overshoot,  $M_p$ : the maximum peak value of the response curve measured from unity. If the final steady-state value of the response differs from unity, then it is common to use the maximum percent overshoot. It is defined by

Maximum percent overshoot = 
$$\frac{c(t_p)-c(\infty)}{c(\infty)} \times 100\%$$

• Settling time,  $t_s$ : the time required for the response curve to reach and stay within a range about the final value of size specified by absolute percentage of the final value (usually 2% or 5%).

## **Definition of transient-Response Specification**

• Maximum overshoot,  $M_p$ : the maximum peak value of the response curve measured from unity. If the final steady-state value of the response differs from unity, then it is common to use the maximum percent overshoot. It is defined by

Maximum percent overshoot = 
$$\frac{c(t_p)-c(\infty)}{c(\infty)} \times 100\%$$

• Settling time,  $t_s$ : the time required for the response curve to reach and stay within a range about the final value of size specified by absolute percentage of the final value (usually 2% or 5%).

Note: Not all these specifications necessarily apply to any given case. For example, for an overdamped system, the terms peak time and maximum overshoot do not apply.

A Few Comments on Transient-Response Specifications

Except for certain applications where oscillations cannot be tolerated, it is desirable that the transient response be sufficiently fast and be sufficiently damped. Thus, for a desirable transient response of a second-order system, the damping ratio must be between 0.4 and 0.8.

A Few Comments on Transient-Response Specifications

Except for certain applications where oscillations cannot be tolerated, it is desirable that the transient response be sufficiently fast and be sufficiently damped. Thus, for a desirable transient response of a second-order system, the damping ratio must be between 0.4 and 0.8.

• Small value of  $\zeta(\zeta<0.4)$  yield excessive overshoot in the transient response.

#### A Few Comments on Transient-Response Specifications

Except for certain applications where oscillations cannot be tolerated, it is desirable that the transient response be sufficiently fast and be sufficiently damped. Thus, for a desirable transient response of a second-order system, the damping ratio must be between 0.4 and 0.8.

- Small value of  $\zeta(\zeta < 0.4)$  yield excessive overshoot in the transient response.
- Large value of  $\zeta$  ( $\zeta > 0.8$ ) responds sluggishly.

#### A Few Comments on Transient-Response Specifications

Except for certain applications where oscillations cannot be tolerated, it is desirable that the transient response be sufficiently fast and be sufficiently damped. Thus, for a desirable transient response of a second-order system, the damping ratio must be between 0.4 and 0.8.

- Small value of  $\zeta(\zeta < 0.4)$  yield excessive overshoot in the transient response.
- Large value of  $\zeta$  ( $\zeta > 0.8$ ) responds sluggishly.

Note: The maximum overshoot and the rise time conflict with each other. Both the maximum overshoot and the rise time cannot be made smaller simultaneously. If one of them is made smaller, the other necessarily becomes larger (you will see later)

### Second-Order Systems and Transient-Response Specifications

• Rise time  $t_r$ : Referring to equation (14), we obtain the rise time by letting  $c(t_r) = 1$ .

$$c(t_r) = 1 = 1 - e^{\zeta \omega_n t_r} (\cos \omega_d t_r + \frac{\zeta}{\sqrt{1-\zeta^2}} \sin \omega_d t_r)$$

since  $e^{\zeta \omega_n t_r} \neq 0$ , we obtain the following equation:

$$\cos \omega_d t_r + rac{\zeta}{\sqrt{1-\zeta^2}} \sin \omega_d t_r = 0$$

Since 
$$\omega_n \sqrt{1-\zeta^2} = \omega_d$$
 and  $\zeta \omega_n = \sigma$ , we have

$$an \omega_d t_r = -rac{\sqrt{1-\zeta^2}}{\zeta} = -rac{\omega_d}{\sigma}$$

### Second-Order Systems and Transient-Response Specifications

• Rise time  $t_r$ : Referring to equation (14), we obtain the rise time by letting  $c(t_r) = 1$ .

$$c(t_r) = 1 = 1 - e^{\zeta \omega_n t_r} (\cos \omega_d t_r + \frac{\zeta}{\sqrt{1-\zeta^2}} \sin \omega_d t_r)$$

since  $e^{\zeta \omega_n t_r} \neq 0$ , we obtain the following equation:

$$\cos \omega_d t_r + rac{\zeta}{\sqrt{1-\zeta^2}} \sin \omega_d t_r = 0$$


Since  $\omega_n \sqrt{1-\zeta^2} = \omega_d$  and  $\zeta \omega_n = \sigma$ , we have

$$an \omega_d t_r = -rac{\sqrt{1-\zeta^2}}{\zeta} = -rac{\omega_d}{\sigma}$$

Thus, the rise time  $t_r$  is

$$t_{\rm r}=rac{1}{\omega_{
m d}} an^{-1}(rac{\omega_{
m d}}{-\sigma})=rac{\pi-eta}{\omega_{
m d}}$$

Second Order System and Transient-Response Specifications



Clearly, for small value of  $t_r$ , $\omega_d$ , angle  $\beta$  must be large.

#### Second Order System and Transient-Response Specifications

• Peak time  $t_p$ : Referring to equation (14), we may obtain peak time by differentiating c(t) with respect to time and letting this derivative equal to zero

$$\begin{aligned} \frac{dc}{dt} &= \zeta \omega_n e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1-\zeta^2}} \sin \omega_d t) \\ &+ e^{-\zeta \omega_n t} (\omega_d \sin \omega_d t + \frac{\zeta \omega_d}{\sqrt{1-\zeta^2}} \cos \omega_d t) \end{aligned}$$

and the cosine terms in this last equation cancel each other, dc/dt, evaluated at  $t=t_p$ , can be simplified to

$$(\sin \omega_d t_p) rac{\omega_n}{\sqrt{1-\zeta^2}} \mathrm{e}^{-\zeta \omega_n t_p} = 0$$

#### Second Order System and Transient-Response Specifications

• Peak time  $t_p$ : Referring to equation (14), we may obtain peak time by differentiating c(t) with respect to time and letting this derivative equal to zero

$$\begin{aligned} \frac{dc}{dt} &= \zeta \omega_n e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1-\zeta^2}} \sin \omega_d t) \\ &+ e^{-\zeta \omega_n t} (\omega_d \sin \omega_d t + \frac{\zeta \omega_d}{\sqrt{1-\zeta^2}} \cos \omega_d t) \end{aligned}$$

and the cosine terms in this last equation cancel each other, dc/dt, evaluated at  $t=t_p$ , can be simplified to

$$(\sin \omega_d t_p) \frac{\omega_n}{\sqrt{1-\zeta^2}} \mathrm{e}^{-\zeta \omega_n t_p} = 0$$

This last equation yields the following equation:

$$\sin \omega_d t_p = 0 \text{ or } \omega_d t_p = 0, \pi, 2\pi, 3\pi, ...$$

#### Second Order System and Transient-Response Specifications

• Peak time  $t_p$ : Referring to equation (14), we may obtain peak time by differentiating c(t) with respect to time and letting this derivative equal to zero

$$\begin{aligned} \frac{dc}{dt} &= \zeta \omega_n e^{-\zeta \omega_n t} (\cos \omega_d t + \frac{\zeta}{\sqrt{1-\zeta^2}} \sin \omega_d t) \\ &+ e^{-\zeta \omega_n t} (\omega_d \sin \omega_d t + \frac{\zeta \omega_d}{\sqrt{1-\zeta^2}} \cos \omega_d t) \end{aligned}$$

and the cosine terms in this last equation cancel each other, dc/dt, evaluated at  $t=t_p$ , can be simplified to

$$(\sin \omega_d t_p) rac{\omega_n}{\sqrt{1-\zeta^2}} \mathrm{e}^{-\zeta \omega_n t_p} = 0$$

This last equation yields the following equation:

$$\sin \omega_d t_p = 0 \text{ or } \omega_d t_p = 0, \pi, 2\pi, 3\pi, \dots$$

Since the peak time corresponds to the first peak overshoot, Hence

$$t_p = \frac{\pi}{\omega_d}$$

Second Order System and Transient-Response Specifications

• Maximum overshoot  $M_p$ : occurs at the peak time or at  $t=t_p=\pi/\omega_d$ . Assuming that the final value of the output is unity, $M_p$  is obtained from Equation (14) as

$$M_p = c(t_p) - 1$$

$$= -e^{-\zeta \omega_n(\pi/\omega_d)} (\cos \pi + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \pi)$$

$$= e^{-(\sigma/\omega_d)\pi} = e^{-(\zeta/\sqrt{1 - \zeta^2})\pi}$$
(19)

#### Second Order System and Transient-Response Specifications

• Maximum overshoot  $M_p$ : occurs at the peak time or at  $t=t_p=\pi/\omega_d$ . Assuming that the final value of the output is unity, $M_p$  is obtained from Equation (14) as

$$M_{p} = c(t_{p}) - 1$$

$$= -e^{-\zeta\omega_{n}(\pi/\omega_{d})}(\cos \pi + \frac{\zeta}{\sqrt{1 - \zeta^{2}}}\sin \pi)$$

$$= e^{-(\sigma/\omega_{d})\pi} = e^{-(\zeta/\sqrt{1 - \zeta^{2}})\pi}$$
(19)


The maximum percent overshoot is  $e^{-(\sigma/\omega_d)\pi} \times 100\%$ . If the final value  $c(\infty)$  of the output is not unity, then we need to use the following equation:

$$M_p = \frac{c(t_p) - c(\infty)}{c(\infty)}$$

#### Second Order System and Transient-Response Specifications

• Setting time  $t_s$ : For an underdamped second-order system, the transient response is obtained from Equation (14) as

$$c(t) = 1 - rac{\mathrm{e}^{-\zeta \omega_n t}}{\sqrt{1-\zeta^2}} \sin(\omega_d t + an^{-1} rac{\sqrt{1-\zeta^2}}{\zeta}), t \geqq 0$$



#### Second Order System and Transient Response Specification

For convenience in comparing with the responses of systems, we commonly define the settling time  $t_s$  to be

$$t_{\rm s}=4T=rac{4}{\sigma}=rac{4}{\zeta\omega_n}$$
 (2% criterion)

or

$$t_{\rm S}=3T=rac{3}{\sigma}=rac{3}{\zeta\omega_n}$$

### Outline

- Introduction
- 2 First Order Systems
- Second Order Systems
- Servo System with Velocity Feedback
- 5 Transient-Response Analysis with MATLAB

Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (chapter 5)

Daro VAN Control Systems Phnom Penh, May 17th, 2020

## Servo System with Velocity Feedback

• The derivative of the output signal can be used to improve system performance. In obtaining the derivative of the output position signal, it is desirable to use a tachometer instead of physically differentiating the output signal.


## Servo System with Velocity Feedback

• The derivative of the output signal can be used to improve system performance. In obtaining the derivative of the output position signal, it is desirable to use a tachometer instead of physically differentiating the output signal.

Note: The differentiation amplifies noise effects. In fact, if discontinuous noises are present, differentiation amplifies the discontinuous noises more than the useful signal.


## Servo Systems with Velocity Feedback

In this system, the velocity signal, together with the position signal, is fed back to the input to produce the actuating error signal.




## Servo Systems with Velocity Feedback

In this system, the velocity signal, together with the position signal, is fed back to the input to produce the actuating error signal.



The block diagram can then be simplified as



giving

$$\frac{C(s)}{R(s)} = \frac{K}{Js^2 + (B + KK_h)s + K}$$

Comparing with equation (10), the damping ratio  $\zeta$  becomes

$$\zeta = \frac{B + KK_h}{2\sqrt{KJ}} \tag{20}$$

The undamped natural frequency  $\omega_n = \sqrt{K/J}$  is not affected by velocity feedback.

giving

$$\frac{C(s)}{R(s)} = \frac{K}{Js^2 + (B + KK_h)s + K}$$

Comparing with equation (10), the damping ratio  $\zeta$  becomes

$$\zeta = \frac{B + KK_h}{2\sqrt{KJ}} \tag{20}$$

The undamped natural frequency  $\omega_n = \sqrt{K/J}$  is not affected by velocity feedback. Note: the maximum overshoot for a unit-step input can be controlled by controlling the value of the damping ratio  $\zeta$ , we can reduce the maximum overshoot by adjusting the velocity-feedback constant  $K_h$  so that  $\zeta$  is between 0.4 and 0.7.

giving

$$\frac{C(s)}{R(s)} = \frac{K}{Js^2 + (B + KK_h)s + K}$$

Comparing with equation (10), the damping ratio  $\zeta$  becomes

$$\zeta = \frac{B + KK_h}{2\sqrt{KJ}} \tag{20}$$

The undamped natural frequency  $\omega_n = \sqrt{K/J}$  is not affected by velocity feedback. Note: the maximum overshoot for a unit-step input can be controlled by controlling the value of the damping ratio  $\zeta$ , we can reduce the maximum overshoot by adjusting the velocity-feedback constant  $K_h$  so that  $\zeta$  is between 0.4 and 0.7.

It is important to remember that velocity feedback has the effect of increasing the damping ratio without affecting the undamped natural frequency of the system.

Impulse Response of Second-Order Systems

For a unit-impulse input r(t), the corresponding Laplace transform is unity, or R(s) = 1. The unit-impulse response C(s) of the second-order system is

$$C(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{21}$$

Impulse Response of Second-Order Systems

For a unit-impulse input r(t), the corresponding Laplace transform is unity, or R(s) = 1. The unit-impulse response C(s) of the second-order system is

$$C(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{21}$$

The inverse Laplace transform of this equation yields the time solution for the response c(t) as follows:

For  $0 \le \zeta \le 1$ 

$$c(t) = \frac{\omega_n}{\sqrt{1 - \zeta^2}} e^{-\zeta \omega_n t} \sin \omega_n \sqrt{1 - \zeta^2} t, t \ge 0$$
 (22)

Impulse Response of Second-Order Systems

For a unit-impulse input r(t), the corresponding Laplace transform is unity, or R(s) = 1. The unit-impulse response C(s) of the second-order system is

$$C(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{21}$$

The inverse Laplace transform of this equation yields the time solution for the response c(t) as follows:

For  $0 \le \zeta \le 1$ 

$$c(t) = \frac{\omega_n}{\sqrt{1 - \zeta^2}} e^{-\zeta \omega_n t} \sin \omega_n \sqrt{1 - \zeta^2} t, t \ge 0$$
 (22)

For  $\zeta = 1$ 

$$c(t) = \omega_n^2 t e^{-\omega_n t}, t \ge 0 \tag{23}$$

Impulse Response of Second-Order Systems

For a unit-impulse input r(t), the corresponding Laplace transform is unity, or R(s) = 1. The unit-impulse response C(s) of the second-order system is

$$C(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{21}$$

The inverse Laplace transform of this equation yields the time solution for the response c(t) as follows:

For  $0 \le \zeta \le 1$ 

$$c(t) = \frac{\omega_n}{\sqrt{1 - \zeta^2}} e^{-\zeta \omega_n t} \sin \omega_n \sqrt{1 - \zeta^2} t, t \ge 0$$
 (22)

For  $\zeta = 1$ 

$$c(t) = \omega_n^2 t e^{-\omega_n t}, t \ge 0 \tag{23}$$

49 / 60

For  $\zeta > 1$ ,

$$c(t) = \frac{\omega_n}{2\sqrt{\zeta^2 - 1}} e^{-(\zeta - \sqrt{\zeta^2 - 1})\omega_n t} - \frac{\omega_n}{2\sqrt{\zeta^2 - 1}} e^{-(\zeta + \sqrt{\zeta^2 - 1})\omega_n t}, t \ge 0 \quad (24)$$

Daro VAN Control Systems Phnom Penh, May 17th, 2020

### Outline

- Introduction
- First Order Systems
- Second Order Systems
- Servo System with Velocity Feedback
- 5 Transient-Response Analysis with MATLAB

Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (chapter 5)

Daro VAN Control Systems Phnom Penh, May 17th, 2020

MATLAB Representation of Linear Systems

The transfer function of a system is represented by two arrays of numbers. Consider the system

$$\frac{C(s)}{R(s)} = \frac{2s + 25}{s^2 + 4s + 25} \tag{25}$$

MATLAB Representation of Linear Systems

The transfer function of a system is represented by two arrays of numbers. Consider the system

$$\frac{C(s)}{R(s)} = \frac{2s + 25}{s^2 + 4s + 25} \tag{25}$$

This system can be represented as two arrays, each containing the coefficients of the polynomials in decreasing powers of s as follows:

$$num = [2,25]$$
  
den = [1,4,25]

MATLAB Representation of Linear Systems

The transfer function of a system is represented by two arrays of numbers. Consider the system

$$\frac{C(s)}{R(s)} = \frac{2s + 25}{s^2 + 4s + 25} \tag{25}$$

51/60

This system can be represented as two arrays, each containing the coefficients of the polynomials in decreasing powers of s as follows:

$$num = [2,25]$$
  
den = [1,4,25]

If num and den of the closed-loop transfer function are known, commands such as

will generate plots of unit-step responses.

MATLAB Representation of Linear Systems

For a control system defined in a state-space form, where state matrix A, control matrix B, output matrix C, and direct transmission matrix D of state-space equations are known, the commands

will generate plots of unit-step responses.

MATLAB Representation of Linear Systems

For a control system defined in a state-space form, where state matrix A, control matrix B, output matrix C, and direct transmission matrix D of state-space equations are known, the commands

will generate plots of unit-step responses.

Note: the command step(sys) may be used to obtain the unit-step response of a system. First, define the system by

Then, to obtain, for example, the unit-step response, enter

step(sys)

MATLAB Representation of Linear Systems

Consider the following systems

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} -1 & -1 \\ 6.5 & 0 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 1 & 1 \\ 1 & 0 \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \end{bmatrix}$$
$$\begin{bmatrix} y_1 \\ y_2 \end{bmatrix} = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 0 & 0 \\ 0 & 0 \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \end{bmatrix}$$

Obtain the unit-step response curves.

MATLAB Representation of Linear Systems

#### Consider the following systems

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} -1 & -1 \\ 6.5 & 0 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 1 & 1 \\ 1 & 0 \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \end{bmatrix}$$
$$\begin{bmatrix} y_1 \\ y_2 \end{bmatrix} = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 0 & 0 \\ 0 & 0 \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \end{bmatrix}$$

Obtain the unit-step response curves.

After doing the Maths, we obtain, the transfer matrix G(s) given as

$$G(s) = \frac{1}{s^2 + s + 6.5} \begin{bmatrix} s - 1 & s \\ s + 7.5 & 6.5 \end{bmatrix}$$

and

$$\begin{bmatrix} Y_1(s) \\ Y_2(s) \end{bmatrix} = \begin{bmatrix} \frac{s-1}{s^2+s+6.5} & \frac{s}{s^2+s+6.5} \\ \frac{s+7.5}{s^2+s+6.5} & \frac{6.5}{s^2+s+6.5} \end{bmatrix} \begin{bmatrix} U_1(s) \\ U_2(s) \end{bmatrix}$$

MATLAB Representation of Linear System

Since this system involves two inputs and two outputs, four transfer functions may be defined, depending on which signals are considered as input and output.

MATLAB Representation of Linear System

Since this system involves two inputs and two outputs, four transfer functions may be defined, depending on which signals are considered as input and output.

Note: when considering the signal  $u_1$  as the input, we assume that signal  $u_2$  is zero, and vice versa. The four transfer functions are

$$\begin{array}{ll} \frac{Y_1(s)}{U_1(s)} = \frac{s-1}{s^2+s+6.5} & \frac{Y_1(s)}{U_2(s)} = \frac{s}{s^2+s+6.5} \\ \frac{Y_2(s)}{U_1(s)} = \frac{s+7.5}{s^2+s+6.5} & \frac{Y_2(s)}{U_1(s)} = \frac{6.5}{s^2+s+6.5} \end{array}$$

MATLAB Representation of Linear System

Since this system involves two inputs and two outputs, four transfer functions may be defined, depending on which signals are considered as input and output.

Note: when considering the signal  $u_1$  as the input, we assume that signal  $u_2$  is zero, and vice versa. The four transfer functions are

$$\begin{array}{ll} \frac{Y_1(s)}{U_1(s)} = \frac{s-1}{s^2+s+6.5} & \frac{Y_1(s)}{U_2(s)} = \frac{s}{s^2+s+6.5} \\ \frac{Y_2(s)}{U_1(s)} = \frac{s+7.5}{s^2+s+6.5} & \frac{Y_2(s)}{U_1(s)} = \frac{6.5}{s^2+s+6.5} \end{array}$$

In MATLAB, the plot can be obtained by using the following code

```
A = [1,-1;6.5,0];
B = [1,1;1,0];
C = [1,0;0,1];
D = [0,0;0,0]
step(A,B,C,D)
```

MATLAB Description of Standard Second-Order System

The second-order system

$$G(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{26}$$

55/60

is called the standard second-order system. Given  $\omega_n$  and  $\zeta$ , the command

printsys(num,den) or printsys(num,den,s)

MATLAB Description of Standard Second-Order System

The second-order system

$$G(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{26}$$

55/60

is called the standard second-order system. Given  $\omega_n$  and  $\zeta$ , the command

printsys(num,den) or printsys(num,den,s)

Consider the case where  $\omega_n=5rad/sec$  and  $\zeta=0.4$ , MATLAB program generate the standard second-order system.

MATLAB Description of Standard Second-Order System

The second-order system

$$G(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{26}$$

is called the standard second-order system. Given  $\omega_n$  and  $\zeta$ , the command

```
printsys(num,den) or printsys(num,den,s)
```

Consider the case where  $\omega_n=5rad/sec$  and  $\zeta=0.4$ , MATLAB program generate the standard second-order system.

MATLAB Program:

```
wn = 5;
dampingratio = 0.4;
[num0,den] = ord2(wn,dampingratio);
num = 25 * num0;
printsys(num,den's')
```

Impulse Response

The unit-impulse response of a control system may be obtained by using any of the impulse commands such as impulse (num, den)

```
impulse(A,B,C,D)
[y,x,t] = impulse(num,den)
[y,x,t]= impulse(num,den,t)
[y,x,t]= impulse(A,B,C,D)
[y,x,t] = impulse(A,B,C,D,iu)
[y,x,t] = impulse(A,B,C,D,iu,t)
```

Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (page 183-211)

Obtaining Response to Arbitrary Input


To obtain the response to an arbitrary input, the command Isim may be used. The commands like

```
lsim(num,den,r,t)
lsim(A,B,C,D,u,t)
y = lsim(num,den,r,t)
y = lsim(A,B,C,D,u,t)
will generate the response to input time function r or u.
```

Reading: Modern Control Engineering by Katsuhiko Ogata, 5th edition (page 183-211)


#### Homework

• Consider the system shown below, where  $\zeta = 0.6$  and  $\omega_n = 5rad/sec$ , obtain the rise time  $t_r$ , peak time  $t_p$ , maximum overshoot  $M_p$  and setting time  $t_s$ . The system is subjected to the step input.



#### Homework

• Consider the system shown below, determine the value of gain K and velocity feedback constant  $K_h$  so that the maximum overshoot is the unit-step response is 0.2 and the peak time is 1sec. With these values of K and  $K_h$ , obtain the rise time and settling time. Assume that  $J = 1kg - m^2$  and B = 1N - m/rad/sec.



#### Reference

• Katsuhiko Ogata, Modern Control Engineering, Fifth Edition, Pearson,

