


# Nordic Semiconductor ASA


## nRF9160 Development Kit (PCA10090)

- Sheet 1: Connections
- Sheet 2: nRF9160
- Sheet 3: nRF52840
- Sheet 4: Signal Switches
- Sheet 5: Interface MCU
- Sheet 6: Buttons and LEDs
- Sheet 7: SIM & Connectors
- Sheet 8: Power Supply




✖ The No ERC object is a design directive.  
This directive is placed on a node in the circuit to suppress harmless warnings and/or error violation conditions that are detected when the schematic project is compiled.

Title Connections			NORDIC SEMICONDUCTOR
Size A3	PCB Assembly Number PCA10090	Revision 1.1.0	
Date: 20.01.2022	Sheet 1 of 8		
File: pca10090_sheet1_connections.SchDoc		Drawn By: RUBR	




A


A






### SWD0/1 SEL reverse drive protection



### SWO MUX




### Interface MCU programming connector



IF MCU DISCONNECT  
IMCU\_BOOT

### Interface MCU



### Title

#### Interface MCU

Size

A3

PCB Assembly Number

PCA10090

Revision

1.1.0

Date:

20.01.2022

Sheet

4 of 8


File:

pca10090 sheet4\_interface\_mcu.SchDoc




Drawn By: RUBR


## UART control




## Interface MCU disconnect switches




## LED, button and switch control




## nRF interface and COEX control



## IO expander for LEDs, buttons and switchrs




## SPI memory control

Title  
Signal switchesSize  
A3  
PCB Assembly Number  
PCA10900Revision  
1.1.0Date: 20.01.2022  
File: pca10900 sheet5\_signal\_switches.SchDoc

Drawn By: RUBR


A

A




B

B



C

C




D


D

Title Misc			NORDIC SEMICONDUCTOR
Size A3	PCB Assembly Number PCA10090	Revision 1.1.0	
Date: 20.01.2022		Sheet 6 of 8	
File: pca10090_sheet6_misc.SchDoc			Drawn By: RUBR


### Interface connectors




### SIM card connector, eSIM and selection switch




### Debug OUT connector




### nRF52 debug IN connector




### nRF91 debug IN connector





### Trace connector




### Shield debug and current measurement connector



### USB connector and USB detect



### Nordic internal debugging interface



### Title

**SIM & Connectors**

Size **A3**

PCB Assembly Number **PCA10090**

Revision **1.1.0**

Date: **20.01.2022**


Sheet **7** of **8**

File: **pca10090 sheet7\_sim\_connectors.SchDoc**


Drawn By: **RUBR**




### Power sources and switches




### Buck regulator for VDD




### 3V3 supply




### nRF91 current measurement




### Power switch




### VIO\_REF sense buffer and switch



### Interface MCU power switch



### VSUPPLY & V5V interface



### Instrument ground



### Title

Power Supply

Size A3

PCB Assembly Number PCA10090

Revision 1.1.0

Date: 20.01.2022

Sheet 8 of 8


File: pca10090\_sheet8\_power\_supply.SchDoc



Drawn By: RUBR

**NORDIC**  
SEMICONDUCTOR  
[www.nordicsemi.com](http://www.nordicsemi.com)  
nRF9160-DK

400389  
0403RUBR



For evaluation only;  
not FCC approved for resale.

