	bleBox Hubitat Installation Instructions							
Note	These instructions are based on a manual installation from the GitHub Site. A pdf copy of these instructions are contained at the GitHub location: "https://github.com/DaveGut/bleBox-Hubitat-SmartThings/tree/master/0%20-%20Hubitat"							
0		Install the bleBox devices using the wBox app and assure each device is configured for your installation. This installation uses data you set in the wBox app to properly install the devices.						
1	Open up F	lubitat Environment (HE) and g	go "Apps Code"					
2	Select "Ne	Select "New App" in the upper right-hand corner.						
Note	In lieu of copying and pasting into the editor window, use the "ImportUrl" button in the editor windows At the bottom are the URLs for importing the application and drivers.							
3		Go to the Application folder on GitHub, open the application, and copy all of the code. Link: https://github.com/DaveGut/bleBox-Hubitat						
4	Past the co	Past the code into the app window on HE. Select Save.						
5	Open up the "Drivers Code" on HE.							
6	Go to the DeviceDrivers folder on GitHub. Reference the list below for the drivers you will need to install. For each of those drivers, complete the following steps.							
	a.	a. Select "New Driver" in the upper right-hand corner						
	b.							
	C.	Paste the code into the window	w on HE. Select Save.					
7		n done installing the required drivers, go the the HE "Apps" page.						
	"Select Ad	"Select Add User App" and select the app "bleBox Integration" from the list. App Options are						
	a.	Install bleBox Devices. Will poll your lps for devices and allow selection of devices to install.						
8	b.	List all available bleBox devices. Lists devices and updates IP addresses (in case of loss of IP)						
	C.			need a log for problem reporting.				
	d. Enable Application Debug Logging. For use when you need a log for problem reporting.							
9	Select "Ins	t "Install bleBox Devices"						
10	From the devices to add, select the dropdown and then the devices you wish to install.							
11		Select "Done". Your devices should install.						
12	Open each	n device and customize your pr		Preferences.				
			Priver File Nomenclature					
bleBox		Install Note	Device Type	Driver File				
	airSensor		bleBox airSensor bleBox dimmerBox	airSensor.groovy				
dimmerBox gateBox			bleBox gateBox	dimmerBox.groovy gateBox.groovy				
	shutterBox		bleBox shutterBox	shutterBox.groovy				
	switchBox		bleBox switchBox	switchBox.groovy				
switchBoxD		Will install two switch devices.	bleBox switchBoxD	switchBoxD.groovy				
tempSensor			bleBox tempSensor	tempSensor.groovy				
W	LightBoxS		bleBox wLightBoxS	wLightBoxS.groovy				
		Parent Driver (required)	bleBox wLightBox	wLightBox.groovy				
wLightBox (requires parent and		Color Type 1 (RGBW)	bleBox wLightBox Rgbw	wLightBoxRgbw.groovy				
		Color Type 2 (RGB)	bleBox wLightBox Rgb	wLightBoxRgb.groovy				
		Color Type 3 (Mono) (installs 4 devices)	bleBox wLightBox Mono	wLightBoxMono.groovy				
one or two child		ColorType 4 (RGB or W)	bleBox wLightBox Rgb	wLightBoxRgb.groovy				
drivers)		(installs 2 devices)	bleBox wLightBox Mono	wLightBoxMono.groovy				

	ColorType 5 or 6 (CT or CTx2) (Installs 1 device for Color Type 5 and 2 for colorType 6.	bleBox wLightBox Ct	wLightBoxCt.groovy
windRainSensor		bleBox windRainSensor	windRainSensor.groovy
	Parent Driver (required)	bleBox multiSensor	multiSensor.groovy
tempSensorPro	Child Driver (required	bleBox MSChildTemperature	MSChildTemperature.groovy

Hubitat Driver URLs					
APPLICATION		https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Application/blebox%20Manager%20App.groovy			
airSensor		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/airSensor.groovy			
dimmerBox		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/dimmerBox.groovy			
gateBox		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/gateBox.groovy			
shutterBox		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/shutterBox.groovy			
switchBox		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/switchBox.groovy			
switchBoxD		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/switchBoxD.groovy			
tempSensor		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/tempSensor.groovy			
wLightBoxS		https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/wLightBoxS.groovy			
	wLightBox (PARENT)	https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/wLightBox.groovy			
	wLightBox Rgbw	https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Drivers/wLightBoxRgbw.groovy			
wLighBox	wLightBox Rgb	https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Drivers/wLightBoxRgb.groovy			
	wLightBox Mono	https://raw.githubusercontent.com/DaveGut/bleBox- Hubitat/master/Drivers/wLightBoxMono.groovy			
	wLightBox Ct	https://raw.githubusercontent.com/DaveGut/bleBox-Hubitat/master/Drivers/wLightBoxCt.groovy			
windRainSensor		https://raw.githubusercontent.com/DaveGut/HubitatActive/master/bleBoxDevices/Drivers/windRainSensor.groovy			
tempSensorPro	multiSensor	https://raw.githubusercontent.com/DaveGut/HubitatActive/master/bleBoxDevices/Drivers/multiSensor.groovy			
tempoensorrio	MSChildTemperat ure	https://raw.githubusercontent.com/DaveGut/HubitatActive/master/bleBoxDevices/Drivers/MSChildTemperature.groovy			