## **Hubitat SmartThing Device Installation**

**Objective of driver:** Gather the data required to develop a Hubitat Environment driver for different SmartThings integrated devices.

## SmartThings Check:

- Open SmartThings on your phone.
- Verify the device you wish to install is in the list of devices.
- Make sure the device is controllable (if that is your requirement) in STs.

**SmartThing API Key**: To run this driver, you will need a Smart Things API Key. The key is in the format of the bogus key below:

c2b25b47-ed3f-4ef7-9e88-55deb5c35060

This key is obtained from <a href="https://account.smartthings.com/tokens">https://account.smartthings.com/tokens</a>

## **Installation Process**

- 1. Open a separate log window in your browser.
- 2. Install the device driver. See Figures A-1 and A-2 for examples of the page display as well as the log page. Figure A-3 shows a log line for if you enter an incorrect key. Usual failure is not copying the entire length of the key from the web page.
- 3. Enter the SmartThings API Key into Preferences and "Save Preferences". See Figures B-1 and B-2 for examples of the page display as well as the log page.
- **4.** Select the Device ID from the log display and enter into the preference SmartThings Device ID. Run "Save Preferences.

Figure A-1. Initial device Edit Page






Figure A-3. Log items if SmartThings API Key is incorrect.



Figure B-1. Successful ST API Key Entry (Bogus Key)




Figure B-2. Log entry on successful Key entry with device list. (Note selected area, which is the deviceID to copy.)

| dev:7159 | 2022-05-29 09:15:44.263 | trace | Copy your device's deviceld value and enter into the device Preferences. |
|----------|-------------------------|-------|--|
| dev:7159 | 2022-05-29 09:15:44.260 | trace | Bed Fire TV: 84ed6595-c3b0-4dbe-b332-e5efed17c1b4                        |
| dev:7159 | 2022-05-29 09:15:44.257 | trace | Bed Left: daacd6bf-f988-457c-a912-e62aec2a0f46                           |
| dev:7159 | 2022-05-29 09:15:44.255 | trace | Front Porch: 3d9807d3-6050-4904-b02a-997626f7ea69                        |
| dev:7159 | 2022-05-29 09:15:44.252 | trace | Multiroom Power: 0c78c23c-46bb-42db-9b54-db1899ead11c                    |
| dev:7159 | 2022-05-29 09:15:44.249 | trace | Den Speaker: 93b4a227-466b-4c20-a4b1-a0ff53a367c8                        |
| dev:7159 | 2022-05-29 09:15:44.246 | trace | 1b: 1ab5c91b-bd44-4a09-82e6-9a7b346d49d4                                 |
| dev:7159 | 2022-05-29 09:15:44.243 | trace | Fan: 49f32461-14a5-480e-a2bd-6ac2f4aa3262                                |
| dev:7159 | 2022-05-29 09:15:44.241 | trace | Couch Left: 66265c6e-bc66-4269-8b68-4047b4b2f497                         |
| dev:7159 | 2022-05-29 09:15:44.238 | trace | Couch Right: 2f5f9820-c4e2-4734-affa-9d8ca96484f3                        |
| dev:7159 | 2022-05-29 09:15:44.235 | trace | Laptop: 79afc460-cdcc-407e-bdec-61053f69dc55                             |
| dev:7159 | 2022-05-29 09:15:44.232 | trace | 1c: 45b1d0e9-2acb-41b3-8434-bfec1b843d30                                 |
| dev:7159 | 2022-05-29 09:15:44.229 | trace | Reading Light: 0e138501-1431-4a39-a11e-da65a0f91a64                      |
| dev:7159 | 2022-05-29 09:15:44.226 | trace | Fire Cube: 85b6f875-b0b7-40e8-90fb-900af2644395                          |
| dev:7159 | 2022-05-29 09:15:44.222 | trace | HS300-03: ab55d96f-608d-49d1-a17d-aaff3b0c019d                           |
| dev:7159 | 2022-05-29 09:15:44.218 | trace | Light Strip: 249372c6-4d9a-4877-b89c-563f117a0f67                        |