Note: States marked as S	Ts only active when you have connected to STs.	
WS: Websocket		
Source Keys	LAN: Local LAN interface	
	ST: SmartThings Colud.	
	Samsung TV Remote Current States	
artModeStatus WS Status of art Mode for frameTV's		
appld	When app playing, the TV application id	
appSource	When app playing, the TV application nam.	
inputSource level	ST: The current input source	
	ST: Volume level. (used in dashboard template)	
mute	ST: mute or unmuted	
nowPlaying	For use in Dashboard "attribute" button to capture the currently playing app/channel.	
numberOfButtons	Button interface number of buttons	
pictureMode	ST: TV picture mode	
soundMode	ST: TV picture mode ST: TV sound mode	
switch	On/Off value of set.	
OWILGIT	Now reflects current set channel. If ST interface is selected, it	
tvChannel	will reflect the ST Name. Otherwise, the last channel set using	
	•	
tvChannelName	setChannel or the channelPreset functions, If an app is playing,	
	tvChannel is blank and tvChannelName reflects the SmartThings	
	appID.	
variable	Current value of variable for Capability Variable. Variable used	
	by some functions in Dashboard ops.	
Volume	ST: Volume	
wsStatus	The current WebSocket status.	
Samsung TV Remote State Variables		
Note: State Variables do not update on Devices Edit page until a page refresh is completed.		
	The drivers list of tv applications loaded on your tv. Created by	
appData	scan for apps preferences and (if ST is enabled) by running a	
	previously unknown app.	
currentFunction:	WS: last function sent to the WS Interface	
pictureMode	ST: support picture modes for your device	
presetData	Data used in preset function contain data to start app/channel.	
soundModes	ST: available sound modes for your device.	
token	WS: token from TV allowing WS remote control.	
Samsung TV Remote Preferences		
Samsung TV IP	The IP of the TV. You should set this up as a static IP within	
	your router.	
TV Startup Display	When turned on via this driver, the startup display to initiate.	
	Only works if the device is turned on via the Hubitat Device	
	instance. Note: Selections other than none are are available but	
	not supported due to issues with the physical tv interface.	
Connect to SmartThings	Enables the preference SmartThings API Key to allow you to	
	enter that key.	

SmartThings API Key	Allows entry of ST API Key. If valid, enables preference
	SmarThings Device ID.
SmartThings Device ID	Allows entry of the device ID.
SmartThings Poll Interval	Minutes. Time between refresh and poll of the SmartThings data
	via the SmartThings cloud.
Power Polling Interval	LAN: Frequency to poll the LAN interface using a canned
	message. A valid return causes the power (switch) to set to on
	and on first encounter initiates some power-on processing. An
	invalid return sets switch to off.
Scan for App Codes	Runs a slow scan for the Samsung Smart TV applications that
	are installed on the TV. TV MUST BE ON. Scans 100 + codes
	and takes over 10 minutes to complete.