		bleBox Hubit	at Installation Instructio	ns			
	These instructions are based on a manual installation from the GitHub Site. A pdf copy of these instructions are						
Note	contained at the GitHub location:						
	"https://github.com/DaveGut/bleBox-Hubitat-SmartThings/tree/master/0%20-%20Hubitat"						
0	Install the bleBox devices using the wBox app and assure each device is configured for your installation.						
	This installation uses data you set in the wBox app to properly install the devices.						
1	Go to Sma	artThings, select your location an	d go to the "My SmartApps" ta	b.			
2	Select "Ne	Select "New SmartApp" then select the "From Code" tab.					
3	Go to the Application folder on GitHub, open the application, and copy all of the code.						
4	Past the c	Past the code into the window on SmartThings. Select "Create", then "Publish" (for me).					
5	Selct the "My Device Handlers" tab.						
6	Go to the Device Drivers folder on GitHub. Reference the list below for the drivers you will need to install. For each of those drivers, complete the following steps.						
	a. Select "Create New Device Handler" in the upper right-hand corner						
	b.	Open the relevant driver on the					
	C.	Paste the code into the window					
7	When done installing the required drivers and app, open the Classic Smart Things phone Application.						
	Select "Add a SmartApp" then "My Apps" (at bottom), then select "bleBox Integration". Options are:						
8	a. Install bleBox Devices. Will poll your lps for devices and allow selection of devices to install.						
	b.						
	C.						
	d.	Enable Application Debug Logging. For use when you need a log for problem reporting.					
	e.	Start Hourly IP Polling. Not preferred. Does hourly polling of IP addresses to update any that have					
	changed. If you assign static in addresses to your devices, this is not necessary.						
9	Select "Install bleBox Devices"						
10	From the devices to add, select the dropdown and then the devices you wish to install. If no devices are present						
11	Select "Done". Your devices should install. {Note that some devices may not appear on the first attempt.}						
12	Open each	n device and customize your pre	-	references.			
			ced User Information				
GitHub linka	age is Owner: DaveGut, Name: bleBox-SmartThings, Branch: master.						
7	When done installing the required drivers, go the HE "Apps" page.						
	"Select Add User App" and select the app "bleBox Integration" from the list. App Options are						
		 a. Install bleBox Devices. Will poll your lps for devices and allow selection of devices to install. b. List all available bleBox devices. Lists devices and updates IP addresses (in case of loss of IP) 					
8	b.	List all available blebox devices	s. Lists devices and updates in	addresses (in case of loss of IP)			
8	c. d.	Enable Application Debug Logging. For use when you need a log for problem reporting.					
	u.	Start Hourly IP Polling. Not preferred. Does hourly polling of IP addresses to update any that have					
	e. changed. If you assign static IP addresses to your devices, this is not necessary.						
9	Select "Install bleBox Devices"						
10	From the devices to add, select the dropdown and then the devices you wish to install.						
11		Select "Done". Your devices should install.					
12	Open each device and customize your preferences. Complete a Save Preferences.						
	<u> </u>		Driver File Nomenclatu				
bleBox Model		Install Note	Device Type	Driver File			
airSensor			bleBox airSensor	airSensorST.groovy			
		Load Type other than 2	bleBox dimmerBox	dimmerBoxST.groovy			
dimmerBox		Load Type 2 (not dimmable)	bleBox dimmerBox NoDim bleBox doorBox	dimmerBoxNoDimingST.groovy			
gateBox				doorBoxST.groovy gateBoxST.groovy			
		Control Type other than 3	bleBox gateBox bleBox shutterBox	shutterBoxST.groovy			
		Control Type 3 (tilt-shutter)	bleBox shutterBox Tilt	shutterBoxWithTiltST.groovy			
switchBox		, , , ,	bleBox switchBox	switchBoxST.groovy			
		Will install two switch devices.	bleBox switchBoxD	switchBoxDST.groovy			
SWILCHBOXE				- · · · · · · · · · · · · · · · · · · ·			

tempSensor		bleBox tempSensor	tempSensorST.groovy
wLightBox	Color Type 1, 2	bleBox wLightBox RGBW	wLightBox RgbwST.groovy
wLightBox	Color Type 3 (Mono)	bleBox wLightBox Mono	wLightBox MonoST.groovy
wLightBoxS		bleBox wLightBoxS	wLightBoxSST.groovy