)					
Tool #	5210	Creator	David G.	Created/Update Date	T/N #	23-5210-003

Description: This guide aims to assist you in navigating the Innova 5210 interface to view LED light definitions.



Viewing LED Definitions using Innova 5210

Title

Viewing LED Definitions:

The LED Definitions feature in the Innova 5210 provides explanations for the green, yellow, and red System Status LEDs. These LEDs on the Scan Tool visually indicate the I/M Readiness status of the vehicle being tested.

Step 1: Access the MENU

1.Locate and press the MENU button on the Innova 5210 to enter the MENU.





Step 2: Navigate to Tool Library

1.In the MENU, use the DOWN ▼ button to scroll through options until you find "Tool Library."

2. Highlight "Tool Library" and press the ENTER ← button to select it.





Step 3: Select LED Meaning

- 1. The Tool Library menu will appear.
- 2.From this menu, select "LED Meaning."
- 3. Highlight "LED Meaning" and press the ENTER ← button to confirm.

Viewing LED Definitions:

- 1. The LED Definitions screen will now be displayed.
- 2.Use the DOWN ▼ button to scroll through the screen to view the explanations for the various LED meanings.
- 3.The LED meanings correspond to the different colors of System Status LEDs on the Scan Tool, providing you with insights into the I/M Readiness status of the vehicle under test.