| Tool # | 5610 | Creator | David G. | Created/Update Date | | T/N # | 23-5610-002 |
|---|------|---------|----------|---------------------|--|-------|-------------|
| Description: Tool not linking to vehicle. | | | | | | | |

Troubleshooting: Tool Not Linking

Tool Not Linking to Vehicle

Title

Encountering issues with your tool not linking? Don't worry, we're here to help you resolve it step by step.

Step 1: Start the Vehicle's Engine

- 1. Prior to connecting the tool, start the engine of your vehicle.
- 2. This step ensures a stable power source for both the vehicle's diagnostic systems and the tool.

Note: If the tool fails to turn on, it indicates a lack of power at the DLC (Diagnostic Link Connector).

Step 3: Check Under-Dash Fuses

- 1. If the tool doesn't power on and link, check all the fuses located under the dashboard.
- 2. Blown fuses can affect the connection between the tool and the vehicle.
- 3. Replace any blown fuses you find with ones of the appropriate rating.

Step 4: Reattempt Tool Connection

- 1. After replacing blown fuses, try connecting the tool again to the vehicle's OBD port with the engine running.
- 2. Ensure that the tool powers on and establishes a link.

Step 5: Further Assistance

- 1. If the tool still doesn't link despite these steps, consider reaching out to us for further assistance.
- 2. Contact our support team at your earliest convenience, so we can better understand and address the problem you're facing.