Tool #	5310	Creator	David G.	Created/Update Date	9/7/2023	T/N #	23-5310-006	

Description: Scanning and interpreting Diagnostic Trouble Codes (DTCs) associated with the vehicle's Airbag System (SRS) using the Innova 5310 Scan Tool.



**Title** 



### 1. Establish Connection:

- Ensure the tool is linked to your vehicle.
- Access the scan options by pressing the System Status button.
  - 2. Navigate to the SRS Option:
- Use the DOWN ▼ button to scroll through the System Menu.
- Highlight the SRS option and confirm with ENTER ←.
  - 3. Confirm Vehicle Details:

- Choose the Yes option.

Scanning & Viewing DTCs for Vehicle Airbag System (SRS)

- Validate your selection by pressing ENTER ←.

# 4. Await Scan Completion:

- A notification, One moment please, will appear while the tool scans for SRS DTCs.
- Please wait until the scan bar shows 100%.

## >Note:

- > If a Communication Error is displayed, ensure the DLC port connection is secured, and your ignition is set to 'On.' If necessary, reset the computer by toggling the ignition off and on after a brief pause.
- > Multiple connection failures will suggest Contact Technical Support. If this occurs, detach the Scan Tool and reach out to Technical Support for assistance.

#### 5. Review SRS Codes:

- Once the scanning concludes, navigate through the SRS DTCs using UP ▲ and DOWN ▼ buttons.
  - > Tip: Consult the Display Functions section for detailed descriptions of display elements.
  - The system will loop back to the initial code after displaying the last DTC.
- Non-available code definitions or the absence of codes will trigger specific advisory messages.





### > Note:

> - For a step-by-step scroll, use the DTC/FF button. To exit the SRS code view, press the System Status button.

# 6. Revisiting SRS Codes:

- If you wish to view the SRS codes again, simply press the \*DTC/FF button\*.

#### > Note:

> - Should there be an interruption in communication between the 5310 tool and the vehicle's computer, press LINK to restore the connection.