	Tool #	5310	Creator	David G.	Created/Update Date	9/6/2023	T/N #	23-5310-004
--	--------	------	---------	----------	---------------------	----------	-------	-------------

Description: This guide is aimed at providing a comprehensive understanding of how to utilize the Innova 5310 Scan Tool to scan and interpret the Check Engine Light (MIL) Diagnostic Trouble Codes (DTCs).



Scanning & Viewing DTCs for MIL Check Engine Light

Title



1. Start with the System Status Button:

- Regardless of your current screen, press the *System Status button* to enter the System Menu.

2. Choose Global OBD2:

- Navigate through the System Menu.
- Highlight Global OBD2 and confirm with ENTER ←.
- > Note: Global OBD2 essentially equates to the Check Engine Light scanning mode.





3. Wait for Scan Results:

- Upon selection, the Scan Tool will initiate the retrieval process for DTCs, Monitor Statuses, and any available Freeze Frame Data.
 - Ensure the linking process reaches 100% completion.
- If no issues are detected, you'll see the message: 'No Powertrain DTCs or Freeze Frame Data presently stored in the vehicle's computer'.
- For a comprehensive understanding of the displayed information, refer to the Display Functions guide.
- > Tip: Arrow icons in display corners indicate more information available. If a DTC lacks a definition, an advisory message will be shown.

LED Indicator Guide:

- Green LED: All systems are functional. No DTCs are detected.
- Yellow LED: It denotes a 'Pending' code or a Monitor that hasn't completed its diagnostic testing.
- Red LED: A problem is detected. It also indicates the presence of DTCs. When this is lit, the vehicle's Check Engine light will likely be on.





4. Access Freeze Frame Data:

- Tap the DTC/FF button.
- This will display the Freeze Frame screen.
- For a detailed code description, long-press ENTER ← until the PID Description appears.
- Releasing ENTER ← will revert back to the Freeze Frame data.

5. Return to DTCs Screen:

- Press the DTC/FF button to revisit the main DTC Codes screen.
- By pressing the DTC/FF button successively, you can view each stored DTC in sequence.