| Title	Code retrieval Procedures						
Tool #	5110	**Creator**	David G.	**Created/Update Date**	8/30/2023	**T/N #**	23-5110-006

Description: This thorough procedure should ensure that you get accurate readings from your vehicle's computer system, which can then be used for further diagnostics and repair.


1. Safety First: Always make sure to consult your vehicle's service manual and observe all safety precautions.

2. Ignition Off: Start with the vehicle's ignition turned off.

3. Locate DLC: Locate the vehicle's 16-pin Data Link Connector (DLC).

4. Connect Code Reader: Connect the Innova 5110's cable to the vehicle's DLC.

5. Ignition On: Turn on the vehicle's ignition but do not start the engine.

6. Automatic Power On: The code reader should automatically turn on. If not, check for electrical issues like burned-out fuses.

7. Reading Codes: Interpret any Diagnostic Trouble Codes (DTCs) that appear, using the color-coded LED system (Green, Yellow, Red) for additional context.

8. Multiple Codes: If more than one DTC is displayed, use the DTC button to cycle through them.

9. Priority Code: The code reader will eventually return to the "Priority code" after all DTCs have been displayed.