| Tool # | 5210 | Creator | David G. | Created/Update Date | 8/30/2023 | T/N # | 23-5210-005 |
|--------|------|---------|----------|---------------------|-----------|-------|-------------|
| | | | | | | | |

Description: To explain the various controls and indicators on the Innova 5210 diagnostic tool.



Controls and Indicators

Title

Controls

- 1. ERASE button: Clears Diagnostic Trouble Codes (DTCs) and Freeze Frame data, resetting the Monitor status.
- 2. SYSTEM MENU button: Opens a menu that displays the list of scan options available.
- 3. DTC/FF button: Shows the DTCs from the last scan and lets you scroll through them.
- 4. LINK button: Reconnects the tool to your vehicle's Powertrain Control Module (PCM).
- 5. MENU button: Opens the main menu of the tool.
- 6. LD button: Enables you to view real-time Live Data from your vehicle.



Controls

- 7. **\(\Lambda\)** UP button: Scrolls up through menu options or additional data while in MENU mode.
- 8. ← ENTER button: Confirms a selected option or value in MENU mode.
- 9. ▼ DOWN button: Scrolls down through menu options or additional data while in MENU mode.

Indicators

- 1. GREEN LED: Shows that all engine systems and monitors are working correctly. No DTCs should be present.
- 2. YELLOW LED: Indicates a possible issue, such as a 'Pending' DTC, or incomplete emission monitor diagnostics.
- 3. RED LED: Indicates that one or more DTCs are present, suggesting a problem with one or more vehicle systems. The vehicle's Check Engine Light will also be on.
- 4. Display: A Color LCD that provides menus, sub-menus, test results, functions, and Monitor status information.