Title	Understanding Display Functions						
Tool #	5110	**Creator**	David G.	**Created/Update Date**	8/29/2023	**T/N #**	23-5110-004

Description: This guide aims to help you understand the various icons and indicators on the display screen of your Innova 5110 Scan Tool, particularly during the initial scan for the Check Engine Light.

1. I/M MONITOR STATUS

- Definition: Signifies the Inspection and Maintenance (I/M) Monitor status on your screen.

2. Monitor Icons

- Definition: Icons indicate which vehicle monitors are supported and their testing status.
  - Solid Icon: The associated Monitor has completed its diagnostic testing.
  - Flashing Icon: The associated Monitor is supported but hasn't completed testing yet.

3. Link Icon

- Definition: Indicates that the tool is currently communicating with the vehicle's computer.

4. Vehicle Icon

- Definition: Confirms that the Scan Tool is powered through the vehicle's Data Link Connector (DLC).

5. MIL Icon
- Definition: Shows the status of the Malfunction Indicator Lamp (MIL), which is only visible when a DTC triggers the vehicle's MIL.

6. ABS Icon
- Definition: Indicates the displayed DTC relates to the Anti-Lock Braking System.

7. History Icon
- Definition: Signifies that the displayed DTC is a history code.

8. Freeze Frame Icon
- Definition: Shows that Freeze Frame data is stored for the current DTC.

9. Pending Icon
- Definition: Marks the displayed DTC as pending.

10. Permanent Icon
- Definition: Marks the displayed DTC as permanent.

11. DTC Display Area
- Definition: Area where the Diagnostic Trouble Code (DTC) number appears.

12. Code Number Sequence

- Definition: Assigns a sequence number to each DTC, starting with 01, to track the number of DTCs.

13. Code Enumerator

- Definition: Shows the total number of retrieved codes.

14. Severity Icon

- Definition: Indicates the severity level of the primary code.
    - 1: Service at convenience.
    - 2: Immediate repair if drivability is affected.
    - 3: Stop and repair immediately.

15. Bluetooth Icon

- Definition: Indicates the Bluetooth status with a compatible Innova mobile application.
    - ON: Bluetooth is active.
    - OFF: Bluetooth is not connected.