Num. articolo	Num. parte	Descrizione	Quantità
1	Support plate 50x50 L.80mm Front- Left		1
1.1	M3x10	M3x10	8
1.2	Support plate 50x50 L.80mm Front-Left		1
1.3	Bearing Housing		2
1.4	TNUT M6 (3 842 501 753)		4
1.5	M6x10	Socket head cap screw	4
1.6	8mm Bearing SKF 608 RS 286-7530		2
2	Support plate 50x50 L.140mm Back-Left		1
2.1	TNUT M6 (3 842 501 753)		6
2.2	M6x10	Socket head cap screw	4
2.3	M3x10	M3x10	10
2.4	Support plate 50x50 L.140mm Back-Left		1
2.5	Bearing Housing		2
2.6	8mm Bearing SKF 608 RS 286-7530		2
3	Support plate 50x50 L.80mm Front-Right		1
3.1	Support plate 50x50 L.80mm Front-Right		1
3.2	M3x10	M3x10	8
3.3	Bearing Housing		2
3.4	TNUT M6 (3 842 501 753)		4
3.5	M6x10	Socket head cap screw	4
3.6	8mm Bearing SKF 608 RS 286-7530		2
4	Support plate 50x50 L.140mm Back_Right		1
4.1	M6x10	Socket head cap screw	6
4.2	Support plate 50x50 L.140mm Back_Right		1
4.3	M3x10	M3x10	8
4.4	Bearing Housing		2
4.5	TNUT M6 (3 842 501 753)		6
4.6	8mm Bearing SKF 608 RS 286-7530		2
5	PSFJ8-465		2
6	PSFJ8-435		2
7	Slider		4
7.1	cubic slider		1
7.2	igus_wfm-0810-30		1
7.3	belt clamp		2
7.4	M3x14	M3x14	4
7.5	plain washer grade a_din		4
8	PSFJ8-370		2
9	XY shims		8
10	GT2_20T-pulley 8mm bore		10
11	GT2 belt 830mm		4