Simulator - Quick Reference

Version 5.0.41

Usage



Simulator [-flag] [control_file]

Optional Flags:

-Q[uiet] = execute without screen messages
-H[elp] = show program syntax and control keys
-C[ontrol] = create/update a default control file
-K[eyCheck] = list unrecognized control file keys
-P[ause] = pause before exiting
-N[oPause] = never pause before exiting
-D[etail] = execute with detailed status messages
-X[ML] = write an XML file with control keys

Purpose

- 1. Simulate the second-by-second movements of vehicles and persons through the network.
- 2. Generate performance statistics, track individual travelers, and summarize events.

Configuration Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
TITLE	Text		
REPORT_FILE	File		filename[_partition][.prn]
REPORT_FLAG	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
PROJECT_DIRECTORY	Path		
MODEL_START_TIME	Time	0:00	>= 0 [seconds], 0.0 [hours], 0:00
MODEL_END_TIME	Time	24:00	> [model_start_time]
UNITS_OF_MEASURE	Text	METRIC	METRIC, ENGLISH
RANDOM_NUMBER_SEED	Int.	0	0 = computer clock, > 0 = fixed
MAX_WARNING_MESSAGES	Int.	100000	>= 0
MAX_WARNING_EXIT_FLAG	Bool	TRUE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
MAX_PROBLEM_COUNT	Int.	0	>= 0
NUMBER_OF_THREADS	Int.	1	124
SIMULATOR_REPORT_*	Text		program report name





System	File	Kevs

DEO3 VEV	TVDF DEFAULT	VALUE DANCES
REQ? KEY	TYPE DEFAULT	VALUE RANGES
NODE_FILE	File	[project_directory]filename
✓ LINK_FILE	File	[project_directory]filename
✓ POCKET_FILE	File	[project_directory]filename
✓ CONNECTION_FILE	File	[project_directory]filename
✓ PARKING_FILE	File	[project_directory]filename
✓ LOCATION_FILE	File	[project_directory]filename
✓ VEHICLE_TYPE_FILE	File	[project_directory]filename
✓ VEHICLE_FILE	File	[project_directory]filename.*
✓ PLAN_FILE	File	[project_directory]filename.*
LANE_USE_FILE	File	[project_directory]filename
TURN_PENALTY_FILE	File	[project_directory]filename
ACCESS_FILE	File	[project_directory]filename
SIGN_FILE	File	[project_directory]filename
SIGNAL_FILE	File	[project_directory]filename
PHASING_PLAN_FILE	File	[project_directory]filename
TIMING_PLAN_FILE	File	[project_directory]filename
DETECTOR_FILE	File	[project_directory]filename
TRANSIT_STOP_FILE	File	[project_directory]filename
TRANSIT_FARE_FILE	File	[project_directory]filename
TRANSIT_ROUTE_FILE	File	[project_directory]filename
TRANSIT_SCHEDULE_FILE	File	[project_directory]filename
TRANSIT_DRIVER_FILE	File	[project_directory]filename
HOUSEHOLD_FILE	File	[project_directory]filename.*
NEW_PROBLEM_FILE	File	[project_directory]filename.*





Data Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
DAILY_WRAP_FLAG	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
SUMMARY_TIME_RANGES	Text	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
SUMMARY_TIME_INCREMENT	Time	15 minutes	0, 2240 minutes

Select Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
SELECT_HOUSEHOLDS	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_MODES	List	ALL	e.g., ALL or 1, 1214 or WALK, HOV2HOV4
SELECT_PURPOSES	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_START_TIMES	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
SELECT_END_TIMES	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
SELECT_TRAVELER_TYPES	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_VEHICLE_TYPES	List	ALL	e.g., 1, 2, 410, 100200, 300
SELECT_PROBLEM_TYPES	List	ALL	e.g., 1, 2, 410, 100200, 300

Flow, Time Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
UPDATE_FLOW_RATES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
UPDATE_TURNING_MOVEMENTS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
CLEAR_INPUT_FLOW_RATES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
UPDATE_TRAVEL_TIMES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
LINK_DELAY_UPDATE_RATE	Int.	0	-15000
LINK_DELAY_FLOW_FACTOR	Dec.	1.0	1100000
EQUATION_PARAMETERS_*	List	BPR, 0.15, 4.0, 0.75	BPR, 0.15, 4.0, 0.75





Router	Service	Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
IMPEDANCE_SORT_METHOD	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
SAVE_ONLY_SKIMS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
WALK_PATH_DETAILS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
IGNORE_VEHICLE_ID	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
LIMIT_PARKING_ACCESS	Bool	TRUE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
IGNORE_TIME_CONSTRAINTS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
END_TIME_CONSTRAINT	Time	0 minutes	0360 minutes
IGNORE_ROUTING_PROBLEMS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
PERCENT_RANDOM_IMPEDANCE	Dec.	0.0 percent	0.0100.0 percent
HOUSEHOLD_TYPE_SCRIPT	File		[project_directory]filename
WALK_SPEED	Dec.	1.0 mps	0.54.0 mps
BICYCLE_SPEED	Dec.	4.0 mps	1.010.0 mps
WALK_TIME_VALUES_*	List	20.0 impedance/second	01000.0
BICYCLE_TIME_VALUES_*	List	15.0 impedance/second	01000.0
FIRST_WAIT_VALUES_*	List	20.0 impedance/second	01000.0
TRANSFER_WAIT_VALUES_*	List	20.0 impedance/second	01000.0
PARKING_TIME_VALUES_*	List	0.0 impedance/second	0.01000.0
VEHICLE_TIME_VALUES_*	List	10.0 impedance/second	01000.0
DISTANCE_VALUES_*	List	0.0 impedance/meter	0.01000.0
COST_VALUES_*	List	0.0 impedance/cent	0.01000.0
FACILITY_BIAS_FACTORS_*	List	1.0	0.52.0
LEFT_TURN_PENALTIES_*	List	0 impedance	010000
RIGHT_TURN_PENALTIES_*	List	0 impedance	010000
U_TURN_PENALTIES_*	List	0 impedance	010000
PARKING_PENALTY_FILE	File		[project_directory]filename
TRANSIT_PENALTY_FILE	File		[project_directory]filename
TRANSFER_PENALTIES_*	List	0 impedance	0100000





		•	1/
Politor	COL	/ICO	KOVC
Router	26/1	//LE	NEVS
			,-

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
STOP_WAITING_PENALTIES_*	List	0 impedance	0100000
STATION_WAITING_PENALTIES_*	List	0 impedance	0100000
BUS_BIAS_FACTORS_*	List	1.0	1.03.0
BUS_BIAS_CONSTANTS_*	List	0 impedance	010000
RAIL_BIAS_FACTORS_*	List	1.0	0.11.0
RAIL_BIAS_CONSTANTS_*	List	0 impedance	-10000
MAX_WALK_DISTANCES_*	List	2000 meters	10020000 meters
WALK_PENALTY_DISTANCES_*	List	2000 meters	10010000 meters
WALK_PENALTY_FACTOR	Dec.	0.0	0.0.25.0
MAX_BICYCLE_DISTANCES_*	List	10000 meters	100040000 meters
BIKE_PENALTY_DISTANCES_*	List	10000 meters	100020000 meters
BIKE_PENALTY_FACTOR	Dec.	0.0	0.0.25.0
MAX_WAIT_TIMES_*	List	60 minutes	5400 minutes
WAIT_PENALTY_TIMES_*	List	60 minutes	5200 minutes
WAIT_PENALTY_FACTOR	Dec.	0.0	0.0.25.0
MIN_WAIT_TIMES_*	List	0 seconds	03600 seconds
MAX_NUMBER_OF_TRANSFERS_*	Int.	3	010
MAX_NUMBER_OF_PATHS_*	Int.	4	110
MAX_PARK_RIDE_PERCENTAGE_*	Int.	50 percent	1100 percent
MAX_KISS_RIDE_PERCENTAGE_*	Int.	35 percent	1100 percent
KISS_RIDE_TIME_FACTOR_*	Dec.	2.5	1.04.4
KISS_RIDE_STOP_TYPES	Text	EXTERNAL	
MAX_KISS_RIDE_DROPOFF_WALK	Dec.	100 meters	10500 meters
MAX_LEGS_PER_PATH	Int.	1000	1010000
FARE_CLASS_DISTRIBUTION	List	0	
DEFAULT_PARKING_DURATION	List	0.0 hours	0.024.0 hours
LOCAL_ACCESS_DISTANCE	Dec.	2000 meters	1007500 meters





Router Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
LOCAL_FACILITY_TYPE	Text	EXTERNAL	MAJORLOCAL, EXTERNAL
LOCAL_IMPEDANCE_FACTOR	Dec.	0.0	0.025.0
MAX_CIRCUITY_RATIO	Dec.	0.0	0.010.0
MIN_CIRCUITY_DISTANCE	Dec.	2000 meters	010000 meters
MAX_CIRCUITY_DISTANCE	Dec.	20000 meters	0100000 meters
MIN_DURATION_FACTORS	List	0.1, 0.5, 0.8, 1.0	0.01.0

Simulation Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
SIMULATION_START_TIME	Time	0:00	
SIMULATION_END_TIME	Time	24:00	
TIME_STEPS_PER_SECOND	Int.	1	110
CELL_SIZE	Dec.	0.0 meters	0, 310 meters
PLAN_FOLLOWING_DISTANCE	Int.	526 meters	02000 meters
LOOK_AHEAD_DISTANCE	Int.	260 meters	02000 meters
LOOK_AHEAD_LANE_FACTOR	Dec.	4.0	1.025.0
LOOK_AHEAD_TIME_FACTOR	Dec.	1.0	0.05.0
MAXIMUM_SWAPPING_SPEED	Dec.	40 mps	-140 mps
MAXIMUM_SPEED_DIFFERENCE	Dec.	10 mps	010 mps
ENFORCE_PARKING_LANES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
FIX_VEHICLE_LOCATIONS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
DRIVER_REACTION_TIME_*	List	1.0 seconds	0.05.0 seconds
PERMISSION_PROBABILITY_*	List	50 percent	0100 percent
SLOW_DOWN_PROBABILITY_*	List	0 percent	0100 percent
SLOW_DOWN_PERCENTAGE_*	List	0 percent	050 percent
MAX_COMFORTABLE_SPEED_*	List	37.5 mps	0, 1540 mps
TRAVELER_TYPE_FACTORS_*	List	1.0	0.52.0
ENFORCE_PARKING_LANES FIX_VEHICLE_LOCATIONS DRIVER_REACTION_TIME_* PERMISSION_PROBABILITY_* SLOW_DOWN_PROBABILITY_* SLOW_DOWN_PERCENTAGE_* MAX_COMFORTABLE_SPEED_*	Bool Bool List List List List List List	FALSE FALSE 1.0 seconds 50 percent 0 percent 0 percent 37.5 mps	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N TRUE/FALSE, YES/NO, 1/0, T/F, Y/N 0.05.0 seconds 0100 percent 0100 percent 050 percent 0, 1540 mps





Simulation Service Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
PRIORITY_LOADING_TIME	Time	60 seconds	06500 seconds
MAXIMUM_LOADING_TIME	Time	120 seconds	06500 seconds
PRIORITY_WAITING_TIME	Time	60 seconds	06500 seconds
MAXIMUM_WAITING_TIME	Time	120 seconds	06500 seconds
MAX_DEPARTURE_TIME_VARIANCE	Time	60 minutes	0180 minutes
MAX_ARRIVAL_TIME_VARIANCE	Time	60 minutes	0180 minutes
RELOAD_CAPACITY_PROBLEMS	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
COUNT_PROBLEM_WARNINGS	Bool	TRUE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
PRINT_PROBLEM_MESSAGES	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
UNSIMULATED_SUBAREAS	List	NONE	e.g., 1, 2, 410, 100200, 300
MACROSCOPIC_SUBAREAS	List	NONE	e.g., 1, 2, 410, 100200, 300
MESOSCOPIC_SUBAREAS	List	ALL	e.g., 1, 2, 410, 100200, 300
MICROSCOPIC_SUBAREAS	List	NONE	e.g., 1, 2, 410, 100200, 300
TURN_POCKET_FACTOR	Dec.	0.8	01.0
MERGE_POCKET_FACTOR	Dec.	0.6	01.0
OTHER_POCKET_FACTOR	Dec.	0.5	01.0

Snapshot, Delay, Volume, Ridership Output Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
NEW_SNAPSHOT_FILE_*	File		[project_directory]filename
NEW_SNAPSHOT_INCREMENT_*	Time	900 seconds	0.11800 seconds
NEW_SNAPSHOT_TIME_RANGE_*	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
NEW_SNAPSHOT_LINK_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_SNAPSHOT_SUBAREA_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_SNAPSHOT_COORDINATES_*	List	ALL	Min X, Min Y, Max X, Max Y
NEW_SNAPSHOT_MAX_SIZE_*	Int.	0	04096
NEW_SNAPSHOT_LOCATION_FLAG_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N





Snapshot, Delay, Volume, Ridership O	Itput Kevs	5
--------------------------------------	------------	---

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
NEW_SNAPSHOT_CELL_FLAG_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
NEW_SNAPSHOT_STATUS_FLAG_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
NEW_SNAPSHOT_COMPRESSION_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
NEW_LINK_DELAY_FILE_*	File		[project_directory]filename
NEW_LINK_DELAY_INCREMENT_*	Time	15 minutes	0, 2240 minutes
NEW_LINK_DELAY_TIME_RANGE_*	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
NEW_LINK_DELAY_LINK_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_LINK_DELAY_SUBAREA_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_LINK_DELAY_COORDINATES_*	List	ALL	Min X, Min Y, Max X, Max Y
NEW_LINK_DELAY_VEH_TYPES_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_LINK_DELAY_TURN_FLAG_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
NEW_LINK_DELAY_FLOW_TYPE_*	Text	VEHICLES	VEHICLES, CAR_EQUIV/PCE, PERSONS
NEW_PERFORMANCE_FILE_*	File		[project_directory]filename
NEW_PERFORMANCE_INCREMENT_*	Time	15 minutes	0, 2240 minutes
NEW_PERFORMANCE_TIME_RANGE_*	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
NEW_PERFORMANCE_LINK_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_PERFORMANCE_SUBAREA_RANGE_	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_PERFORMANCE_COORDINATES_*	List	ALL	Min X, Min Y, Max X, Max Y
NEW_PERFORMANCE_VEH_TYPES_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_PERFORMANCE_TURN_FLAG_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
NEW_PERFORMANCE_FLOW_TYPE_*	Text	VEHICLES	VEHICLES, CAR_EQUIV/PCE, PERSONS
NEW_TURN_VOLUME_FILE_*	File		[project_directory]filename
NEW_TURN_VOLUME_FILTER_*	Int.	0	>= 0
	T:	15 minutes	0, 2240 minutes
NEW_TURN_VOLUME_INCREMENT_*	Time	15 milates	of Elle to trimates
NEW_TURN_VOLUME_INCREMENT_* NEW_TURN_VOLUME_TIME_RANGE_*	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00





Snapshot, Delay, Volume, Ridership Output Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
NEW_RIDERSHIP_FILE_*	File		[project_directory]filename
NEW_RIDERSHIP_TIME_RANGE_*	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
NEW_RIDERSHIP_ROUTE_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_RIDERSHIP_ALL_STOPS_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N

Occupancy, Event, Traveler, Speed Bin Output Keys

		-1	
REQ? KEY	TYPE	DEFAULT	VALUE RANGES
NEW_OCCUPANCY_FILE_*	File		[project_directory]filename
NEW_OCCUPANCY_INCREMENT_*	Time	900 seconds	13600 seconds
NEW_OCCUPANCY_TIME_RANGE_*	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
NEW_OCCUPANCY_LINK_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_OCCUPANCY_SUBAREA_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_OCCUPANCY_COORDINATES_*	List	ALL	Min X, Min Y, Max X, Max Y
NEW_OCCUPANCY_MAX_FLAG_*	Bool	FALSE	TRUE/FALSE, YES/NO, 1/0, T/F, Y/N
NEW_EVENT_FILE_*	File		[project_directory]filename
NEW_EVENT_FILTER_*	Time	0 seconds	>= 0 seconds
NEW_EVENT_TIME_RANGE_*	List	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00
NEW_EVENT_TYPE_RANGE_*	List	ALL	TRIP_START_TIME, TRIP_END_TIME, TRIP_DURATION, VEH_START_TIME, VEH_END_TIME, VEH_LOST_TIME, TRANSIT_WAIT, TRANSIT_BO
NEW_EVENT_MODE_RANGE_*	List	ALL	WALK, BIKE, DRIVE, RIDE, TRANSIT, PNR_OUT, PNR_IN, KNR_OUT, KNR_IN, TAXI, OTHER, HOV2, HOV3, HOV4
NEW_EVENT_LINK_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_EVENT_SUBAREA_RANGE_*	List	ALL	e.g., 1, 2, 410, 100200, 300
NEW_EVENT_COORDINATES_*	List	ALL	Min X, Min Y, Max X, Max Y

Control Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
DEBUG_TIME_RANGE	Time	ALL	e.g., ALL, 097200 seconds, 0.027.0 hours, 0:0027:00





Control Keys

REQ? KEY	TYPE	DEFAULT	VALUE RANGES
DEBUG_VEHICLE_LIST	List	ALL	e.g., 1, 2, 410, 100200, 300
DEBUG_LINK_LIST	List	ALL	e.g., 1, 2, 410, 100200, 300

Notes

Each '_FILE' key has a corresponding '_FORMAT' key. The following file formats can be used for input and ouput files.

TEXT, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, SQLITE3, VERSION3

