

Router Quick Reference

Version 4.0.63

Revision History

1/8/2010 Edited by AECOM Consult, Inc.

4/15/2010 Edited by RSG, Inc.

Syntax:

Router [-flag] [control_file] [partition]

Purpose:

- 1. Generate travel plans for household activities that are connected by walk, drive, transit, park-&-ride, kiss-&-ride, bicycle, and magic move modes.
- 2. Generate travel plans for household and itinerant trips by walk, drive, transit, park-&-ride, kiss-&-ride, bicycle, and magic move modes.
- 3. Build travel plans from specified origins to specified destinations at specified times of day using a specified travel mode.
- 4. Selectively route activities or trips from specified origins, to specified destinations, at specified times of day, and/or by specified modes.
- 5. Generate problem files for those activities or trips that could not be routed for specific reasons.
- 6. Implement an incremental capacity restrained assignment algorithm.
- 7. Build travel plans for select household, person, and trip records.
- 8. Update an existing plan file.
- 9. Dump out an ArcView shapefile showing the links reached by a path building task that experienced problems of a selected type.
- 10. Routing by selected trip purposes.
- 11. A vehicle file is optional for plans that are not simulated.

Required Keys

NET_NODE_TABLE	[net_directory]filename
NET_LINK_TABLE	[net_directory]filename
NET_LANE_CONNECTIVITY_TABLE	[net_directory]filename
NET_PARKING_TABLE	[net_directory]filename
NET_ACTIVITY_LOCATION_TABLE	[net_directory]filename
NET_PROCESS_LINK_TABLE	[net_directory]filename
VEHICLE_FILE (1)	[project_directory]filename
TRIP_FILE (1)	[project_directory]filename
ACTIVITY_FILE (1)	[project_directory]filename
NEW_PLAN_FILE (2)	[project_directory]filename[.partition]

Optional Keys

TITLE	Text
REPORT_FILE	Filename
REPORT_FLAG	FALSE {true/false/yes/no/1/0}
MAX_WARNING_MESSAGES	100,000
MAX_WARNING_EXIT_FLAG	TRUE {true/false/yes/no/1/0}
PROJECT_DIRECTORY	Pathname
DEFAULT_FILE_FORMAT	VERSION3 {(4)}
TRAVELER_SCALING_FACTOR	100 {2100}
NET_DIRECTORY	Pathname
NET_LANE_USE_TABLE	[net_directory]filename
NET_TOLL_TABLE	[net_directory]filename
NET_TURN_PROHIBITION_TABLE	[net_directory]filename
NET_TRANSIT_STOP_TABLE	[net_directory]filename
NET_TRANSIT_FARE_TABLE	[net_directory]filename
NET_TRANSIT_ROUTE_TABLE	[net_directory]filename
NET_TRANSIT_SCHEDULE_TABLE	[net_directory]filename
LINK_DELAY_FILE	[project_directory]filename
LINK_DELAY_START_TIME (13)	0:00 {0:00120:00}
LINK_DELAY_END_TIME (13)	24:00 {0:00120:00}
PLAN_FILE (10)	[project_directory]filename[.partition]
HOUSEHOLD_LIST (11)	[project_directory]filename[.partition]
HOUSEHOLD_RECORD_FILE (11)	[project_directory]filename[.partition]
Household_File	[project_directory]filename
HOUSEHOLD_TYPE_SCRIPT	[project_directory]filename
PARKING_PENALTY_FILE	[project_directory]filename
SORT_VEHICLES	TRUE {true/false/yes/no/1/0}
IGNORE_VEHICLE_ID	FALSE {true/false/yes/no/1/0}
VEHICLE_TYPE_FILE	[project_directory]filename
TIME_OF_DAY_FORMAT	HOURS {(5)}
PLAN_FORMAT	VERSION3 {VERSION3/BINARY}
NEW_PLAN_FORMAT	VERSION3 {VERSION3/BINARY}
NODE_LIST_PATHS	TRUE {true/false/yes/no/1/0}
WALK_PATH_DETAILS	FALSE {true/false/yes/no/1/0}
NEW_PROBLEM_FILE	[project_directory]filename[.partition]
NEW_PROBLEM_FORMAT	[default_file_format] {(4)}
ROUTE_SELECTED_MODES	{1,2,3,4,5,6,7,8,9,10,11,12,13,14}
ROUTE_WITH_SPECIFIED_MODE	{1,2,3,4,5,6,7,8,9,10,11,12,13,14}
ROUTE_FROM_SPECIFIED_LOCATIONS (1)	All



ROUTE_AT_SPECIFIED_TIMES	ROUTE_TO_SPECIFIED_LOCATIONS (1)	All
ROUTE_BY_TIME_INCREMENT 0 minutes {0240} ROUTE_SELECTED_PURPOSES All LIMIT_PARKING_ACCESS TRUE {\text{true/false/yes/no/1/0}\} END_TIME_CONSTRAINTS FALSE {\text{true/false/yes/no/1/0}\} END_TIME_CONSTRAINT 0 minutes GNORE_ROUTING_PROBLEMS FALSE {\text{true/false/yes/no/1/0}\} PERCENT_RANDOM_IMPEDANCE 0 percent RANDOM_NUMBER_SEED 0 UPDATE_PLAN_RECORDS (15) FALSE {\text{true/false/yes/no/1/0}\} PRINT_UPDATE_WARNINGS FALSE {\text{true/false/yes/no/1/0}\} PRINT_UPDATE_WARNINGS FALSE {\text{true/false/yes/no/1/0}\} PRINT_UPDATE_WARNINGS FALSE {\text{true/false/yes/no/1/0}\} PRINT_UPDATE_WARNINGS FALSE {\text{true/false/yes/no/1/0}\} WALK_SPEED 1.0 meters per second BICYCLE_SPEED 4.0 meters per second BICYCLE_TIME_VALUE 20.0 units per second [.#.#		
ROUTE_SELECTED_PURPOSES		
LIMIT_PARKING_ACCESS		
IGNORE_TIME_CONSTRAINTS		TRUE {{true/false/yes/no/1/0}
END_TIME_CONSTRAINT		• • • • • • • • • • • • • • • • • • • •
IGNORE_ROUTING_PROBLEMS		
PERCENT_RANDOM_IMPEDANCE 0 percent RANDOM_NUMBER_SEED 0 UPDATE_PLAN_RECORDS (15) FALSE {true/false/yes/no/1/0} PRINT_UPDATE_WARNINGS FALSE {true/false/yes/no/1/0} WALK_SPEED 1.0 meters per second BICYCLE_SPEED 4.0 meters per second WALK_TIME_VALUE 20.0 units per second [#,##,] (3) BICYCLE_TIME_VALUE 15.0 units per second [#,##,] (3) FIRST_WAIT_VALUE 20.0 units per second [#,##,] (3) VEHICLE_TIME_VALUE 10.0 units per second [#,##,] (3) VEHICLE_TIME_VALUE 10.0 units per second [#,##,] (3) VEHICLE_TIME_VALUE 10.0 units per second [#,##,] (3) VEHICLE_TIME_VALUE 0.0 units per second [#,##,] (3) VEHICLE_TIME_VALUE 0.0 units per second [#,##,] (3) OST_VALUE 0.0 units per second [#,##,] (3) LEFT_TURN_PENALTY 0.0 units per second [#,##,] (3) RIGHT_TURN_PENALTY 0.0 units [#,#,#] (3) UTURN_PENALTY 0.0 units [#,#,#] (3) TRANSFER_PENALTY 0.0 units [#,#,#] (3) STATION_WAITING_PENALTY 0.0 units [#,#,#] (3) TRANSFER_PENALTY		FALSE {true/false/yes/no/1/0}
RANDOM_NUMBER_SEED 0 UPDATE_PLAN_RECORDS (15) FALSE {true/false/yes/no/1/0} FALSE {t		•
UPDATE PLAN_RECORDS (15)		
PRINT_UPDATE_WARNINGS FALSE {true/false/yes/no/1/0} WALK_SPEED 1.0 meters per second BICYCLE_SPEED 4.0 meters per second [#.#.#] (3) WALK_TIME_VALUE 20.0 units per second [#.#.#] (3) BICYCLE_TIME_VALUE 15.0 units per second [#.#.#] (3) FIRST_WAIT_VALUE 20.0 units per second [#.#.#] (3) TRANSFER_WAIT_VALUE 20.0 units per second [#.#.#] (3) VEHICLE_TIME_VALUE 10.0 units per second [#.#.#] (3) VEHICLE_TIME_VALUE 10.0 units per second [#.#.#] (3) DISTANCE_VALUE 20.0 units per second [#.#.#] (3) COST_VALUE 0.0 units per second [#.#.#] (3) LEFT_TURE_PENALTY 0.0 units per second [#.#.#] (3) RIGHT_TURN_PENALTY 0.0 units per second [#.#.#] (3) UTURN_PENALTY 0.0 units per second [#.#.#] (3) UTURN_PENALTY 0.0 units per second [#.#.#] (3) UTURN_PENALTY 0.0 units [#.#.#] (3) STOP_WAITING_PENALTY 0.0 units [#.#.#] (3) STOP_WAITING_PENALTY 0.0 units [#.#.#] (3) STATION_WAITING_PENALTY 0.0 units [#.#.#] (3) TRANSIT_PENALTY_FILE (14) [project_director		FALSE {true/false/yes/no/1/0}
WALK_SPEED		
BICYCLE_SPEED		
WALK_TIME_VALUE 20.0 units per second [,#,#,] (3) BICYCLE_TIME_VALUE 15.0 units per second [,#,#,] (3) FIRST_WAIT_VALUE 20.0 units per second [,#,#,] (3) TRANSFER_WAIT_VALUE 20.0 units per second [,#,#,] (3) VEHICLE_TIME_VALUE 10.0 units per second [,#,#,] (3) DISTANCE_VALUE 0.0 units per meter [,#,#,] (3) COST_VALUE 0.0 units per cent [,#,#,] (3) LEFT_TURN_PENALTY 0.0 units [,#,#,] (3) RIGHT_TURN_PENALTY 0.0 units [,#,#,] (3) UTURN_PENALTY 0.0 units [,#,#,] (3) TRANSFER_PENALTY 0.0 units [,#,#,] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,] (3)		
BICYCLE_TIME_VALUE		
FIRST_WAIT_VALUE 20.0 units per second [,#,#,,] (3) TRANSFER_WAIT_VALUE 20.0 units per second [,#,#,#,] (3) VEHICLE_TIME_VALUE 10.0 units per second [,#,#,#,] (3) DISTANCE_VALUE 0.0 units per meter [,#,#,#,] (3) COST_VALUE 0.0 units per cent [,#,#,#,] (3) LEFT_TURN_PENALTY 0.0 units [,#,#,#,] (3) RIGHT_TURN_PENALTY 0.0 units [,#,#,] (3) UTURN_PENALTY 0.0 units [,#,#,] (3) TRANSFER_PENALTY 0.0 units [,#,#,] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,] (3)		
TRANSFER_WAIT_VALUE 20.0 units per second [,#,#,#,] (3) VEHICLE_TIME_VALUE 10.0 units per second [,#,#,#,] (3) DISTANCE_VALUE 0.0 units per meter [,#,#,#,] (3) COST_VALUE 0.0 units per cent [,#,#,#,] (3) LEFT_TURN_PENALTY 0.0 units [,#,#,] (3) RIGHT_TURN_PENALTY 0.0 units [,#,#,#,] (3) UTURN_PENALTY 0.0 units [,#,#,#,] (3) TRANSFER_PENALTY 0.0 units [,#,#,#,] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,#,] (3)		
VEHICLE_TIME_VALUE 10.0 units per second [,#,#,] (3) DISTANCE_VALUE 0.0 units per meter [,#,#,#] (3) COST_VALUE 0.0 units per cent [,#,#,#] (3) LEFT_TURN_PENALTY 0.0 units [,#,#,] (3) RIGHT_TURN_PENALTY 0.0 units [,#,#,#] (3) UTURN_PENALTY 0.0 units [,#,#,#] (3) TRANSFER_PENALTY 0.0 units [,#,#,#] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,#] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,#] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,] (3)		_
DISTANCE_VALUE		
COST_VALUE 0.0 units per cent [,#,#,#,] (3) LEFT_TURN_PENALTY 0.0 units [,#,#,#,] (3) RIGHT_TURN_PENALTY 0.0 units [,#,#,#,] (3) UTURN_PENALTY 0.0 units [,#,#,] (3) TRANSFER_PENALTY 0.0 units [,#,#,] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,] (3)		
LEFT_TURN_PENALTY 0.0 units [,#,#,] (3) RIGHT_TURN_PENALTY 0.0 units [,#,#,#] (3) UTURN_PENALTY 0.0 units [,#,#,#] (3) TRANSFER_PENALTY 0.0 units [,#,#,#] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,] (3)		
RIGHT_TURN_PENALTY 0.0 units [,#,#,#,] (3) UTURN_PENALTY 0.0 units [,#,#,#,] (3) TRANSFER_PENALTY 0.0 units [,#,#,#,] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,] (3)		
UTURN_PENALTY 0.0 units [,#,#,#,] (3) TRANSFER_PENALTY 0.0 units [,#,#,#,] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory] filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,#,] (3)		
TRANSFER_PENALTY 0.0 units [,#,#,#,] (3) STOP_WAITING_PENALTY 0.0 units [,#,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,#,] (3)		
STOP_WAITING_PENALTY 0.0 units [,#,#,#,] (3) STATION_WAITING_PENALTY 0.0 units [,#,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory] filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,#,] (3)	TRANSFER PENALTY	
STATION_WAITING_PENALTY 0.0 units [,#,#,#,] (3) TRANSIT_PENALTY_FILE (14) [project_directory]filename BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,#,] (3)	-	
BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,#,] (3)	STATION_WAITING_PENALTY	
BUS_BIAS_FACTOR 1.0 * transit type < 3 impedance [,#,#,#,] (3)	TRANSIT_PENALTY_FILE (14)	
RAIL_BIAS_FACTOR 1.0 * transit type > 2 impedance [,#,#,#,] (3) RAIL_BIAS_CONSTANT 0 transit type > 2 impedance [,#,#,#,] (3) MAX_WALK_DISTANCE 2000 meters [,#,#,#,] (3) MAX_BICYCLE_DISTANCE 10000 meters [,#,#,#,] (3) MAX_WAIT_TIME 60 minutes [,#,#,#,] (3) MIN_WAIT_TIME 0 seconds [,#,#,#,] (3) MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)		1.0 * transit type < 3 impedance [,#,#,#,] (3)
RAIL_BIAS_CONSTANT 0 transit type > 2 impedance [,#,#,#,] (3) MAX_WALK_DISTANCE 2000 meters [,#,#,#,] (3) MAX_BICYCLE_DISTANCE 10000 meters [,#,#,#,] (3) MAX_WAIT_TIME 60 minutes [,#,#,#,] (3) MIN_WAIT_TIME 0 seconds [,#,#,#,] (3) MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)	BUS_BIAS_CONSTANT	0 transit type < 3 impedance [,#,#,#,] (3)
MAX_WALK_DISTANCE 2000 meters [,#,#,#,] (3) MAX_BICYCLE_DISTANCE 10000 meters [,#,#,#,] (3) MAX_WAIT_TIME 60 minutes [,#,#,#,] (3) MIN_WAIT_TIME 0 seconds [,#,#,#,] (3) MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)	RAIL_BIAS_FACTOR	1.0 * transit type > 2 impedance [,#,#,#,] (3)
MAX_WALK_DISTANCE 2000 meters [,#,#,#,] (3) MAX_BICYCLE_DISTANCE 10000 meters [,#,#,#,] (3) MAX_WAIT_TIME 60 minutes [,#,#,#,] (3) MIN_WAIT_TIME 0 seconds [,#,#,#,] (3) MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)	RAIL_BIAS_CONSTANT	0 transit type > 2 impedance [,#,#,#,] (3)
MAX_BICYCLE_DISTANCE 10000 meters [,#,#,#,] (3) MAX_WAIT_TIME 60 minutes [,#,#,#,] (3) MIN_WAIT_TIME 0 seconds [,#,#,#,] (3) MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)	MAX WALK DISTANCE	
MAX_WAIT_TIME 60 minutes [,#,#,#,] (3) MIN_WAIT_TIME 0 seconds [,#,#,#,] (3) MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)	MAX_BICYCLE_DISTANCE	
MIN_WAIT_TIME 0 seconds [,#,#,#,] (3) MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)	MAX_WAIT_TIME	
MAX_NUMBER_OF_TRANSFERS 5 transfers [,#,#,#,] (3) MAX_NUMBER_OF_PATHS 4 paths [,#,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)		
MAX_NUMBER_OF_PATHS 4 paths [,#,#,] (3) MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)	MAX_NUMBER_OF_TRANSFERS	
MAX_PARK_RIDE_PERCENTAGE 50 percent [,#,#,#,] (3)		



KISS_RIDE_TIME_FACTOR	2.5 * drive time [,#,#,#,] (3)
KISS RIDE STOP TYPES	STOP {STATION, EXTERNAL}
MAX KISS RIDE DROPOFF WALK	100 meters
MAX_LEGS_PER_PATH	1000 legs
ADD WAIT TO TRANSIT LEG	FALSE {true/false/yes/no/1/0}
FARE_CLASS_DISTRIBUTION	100% cash, 0% card, 0% special
PARKING_HOURS_BY_PURPOSE	0.0 hours [,#,#,#,] (9)
LOCAL_ACCESS_DISTANCE	2000 meters {1007500 meters}
LOCAL_FACILITY_TYPE	EXTERNAL (6)
MAX_CIRCUITY_RATIO	2.0 {0, 1.010.0}
MIN_CIRCUITY_DISTANCE	2000 meters {010000}
MAX_CIRCUITY_DISTANCE	20000 meters {0100000}
MAX_ROUTING_PROBLEMS	100000 problems {010000000}
Max_Link_Delay_Errors	100000 errors {010000000}
LINK_DELAY_UPDATE_RATE	0 disabled {01000000}
LINK_DELAY_VOL_FACTOR	1.0 * partition volume
EQUATION_PARAMETERS_# (7)	BPR, 0.15, 4.0, 0.75 (8)
NET_DEFAULT_FORMAT	[default_file_format] {(4)}
ArcView_Problem_Dump	[project_directory]filename.shp
PROBLEM_DUMP_TYPE	0 {(12)}
PERCENT_PROBLEMS_DUMPED	100 percent {0.1100.0}
NET_NODE_FORMAT	[net_default_format] {(4)}
NET_LINK_FORMAT	[net_default_format] {(4)}
NET_LANE_CONNECTIVITY_FORMAT	[net_default_format] {(4)}
NET_PARKING_FORMAT	[net_default_format] {(4)}
NET_ACTIVITY_LOCATION_FORMAT	[net_default_format] {(4)}
NET_PROCESS_LINK_FORMAT	[net_default_format] {(4)}
NET_LANE_USE_FORMAT	[net_default_format] {(4)}
NET_TOLL_FORMAT	[net_default_format] {(4)}
NET_TURN_PROHIBITION_FORMAT	[net_default_format] {(4)}
NET_TRANSIT_STOP_FORMAT	[net_default_format] {(4)}
NET_TRANSIT_FARE_FORMAT	[net_default_format] {(4)}
NET_TRANSIT_ROUTE_FORMAT	[net_default_format] {(4)}
NET_TRANSIT_SCHEDULE_FORMAT	[net_default_format] {(4)}
DEMAND_FILE_FORMAT	[default_file_format] {(4)}
VEHICLE_FORMAT	[demand_file_format] {(4)}
HOUSEHOLD_FORMAT	[demand_file_format] {(4)}
LINK_DELAY_FORMAT	[demand_file_format] {(4)}





Reports

ROUTER_REPORT_#	HOUSEHOLD_TYPE_SCRIPT
	HOUSEHOLD_TYPE_STACK
	FARE_DATA_REPORT

Notes

A trip or activity file is required if specified origins or destinations are not provided. Trip and activity file is provided, a vehicle file is required. A trip or activity file is provided, a vehicle file is required. A trip or activity file should not be provided when generating plans from selected origins to selected destinations. 2				
 Multiple parameters correspond to "type" values defined in the household type script. {VERSION3, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, LANL, SQLITE3} {HOURS, SECONDS, 24_HOUR_CLOCK, 12_HOUR_CLOCK} {MAJOR, MINOR, COLLECTOR, LOCAL, EXTERNAL} EXTERNAL disables local processing # equals facility type code {1 = freeway, 2 = expressway, 3 = principal arterial, etc.} {BPR, BPR_PLUS, EXPONENTIAL, CONICAL, BPR+, EXP, CON}, A, B, C, D Multiple parameters correspond to trip purpose codes in the trip and activity file. If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop wi	1	activity files can be processed in the same application. The trip file will be processed first. If a trip or activity file is provided, a vehicle file is required. A trip or activity file should not be provided		
 {VERSION3, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, LANL, SQLITE3} {HOURS, SECONDS, 24_HOUR_CLOCK, 12_HOUR_CLOCK} {MAJOR, MINOR, COLLECTOR, LOCAL, EXTERNAL} EXTERNAL disables local processing # equals facility type code {1 = freeway, 2 = expressway, 3 = principal arterial, etc.} {BPR, BPR_PLUS, EXPONENTIAL, CONICAL, BPR+, EXP, CON}, A, B, C, D Multiple parameters correspond to trip purpose codes in the trip and activity file. If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, th	2			
TAB_DELIMITED, CSV_DELIMITED, DBASE, LANL, SQLITE3} {HOURS, SECONDS, 24_HOUR_CLOCK, 12_HOUR_CLOCK} {MAJOR, MINOR, COLLECTOR, LOCAL, EXTERNAL} EXTERNAL disables local processing # equals facility type code {1 = freeway, 2 = expressway, 3 = principal arterial, etc.} Hours, BPR_PLUS, EXPONENTIAL, CONICAL, BPR+, EXP, CON}, A, B, C, D Multiple parameters correspond to trip purpose codes in the trip and activity file. If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop nu	3	Multiple parameters correspond to "type" values defined in the household type script.		
 6 {MAJOR, MINOR, COLLECTOR, LOCAL, EXTERNAL} EXTERNAL disables local processing 7 # equals facility type code {1 = freeway, 2 = expressway, 3 = principal arterial, etc.} 8 {BPR, BPR_PLUS, EXPONENTIAL, CONICAL, BPR+, EXP, CON}, A, B, C, D 9 Multiple parameters correspond to trip purpose codes in the trip and activity file. 10 If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort 11 A household list or a household record file may be provided, but not both. 12 A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match 13 LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. 14 This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.	4			
 # equals facility type code { 1 = freeway, 2 = expressway, 3 = principal arterial, etc.} {BPR, BPR_PLUS, EXPONENTIAL, CONICAL, BPR+, EXP, CON}, A, B, C, D Multiple parameters correspond to trip purpose codes in the trip and activity file. If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel	5	{HOURS, SECONDS, 24_HOUR_CLOCK, 12_HOUR_CLOCK}		
 BPR, BPR_PLUS, EXPONENTIAL, CONICAL, BPR+, EXP, CON}, <i>A, B, C, D</i> Multiple parameters correspond to trip purpose codes in the trip and activity file. If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel time and impedance components of existing plan records 	6	{MAJOR, MINOR, COLLECTOR, LOCAL, EXTERNAL} EXTERNAL disables local processing		
 Multiple parameters correspond to trip purpose codes in the trip and activity file. If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel time and impedance components of existing plan records 	7	# equals facility type code {1 = freeway, 2 = expressway, 3 = principal arterial, etc.}		
 If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel time and impedance components of existing plan records 	8	{BPR, BPR_PLUS, EXPONENTIAL, CONICAL, BPR+, EXP, CON}, A, B, C, D		
 A household list or a household record file may be provided, but not both. A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel time and impedance components of existing plan records 	9	Multiple parameters correspond to trip purpose codes in the trip and activity file.		
 A problem type code: 0 = all types, 1 = Path Building, 2 = Time Schedule, 3 = Zero Node, 4 = Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel time and impedance components of existing plan records 	10	If an input plan file is provided, the new plans are merged with the input plan file in traveler-trip sort		
 Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort, 33 = Walk Location, 34 = Bike Location, 35 = Transit Location, 36 = Person Match LINK_DELAY_START_TIME and LINK_DELAY_END_TIME can be used to additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel time and impedance components of existing plan records 	11	A household list or a household record file may be provided, but not both.		
 additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing beyond 24 hours. This file can be used to input impedance penalties for combinations of stop, route, and/or run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). The program re-skims the travel time and impedance components of existing plan records 	12	Vehicle Type, 5 = Path Circuity, 6 = Travel Mode, 7 = Vehicle Access, 8 = Walk Distance, 9 = Wait Time, 10 = Walk Access, 11 = Path Size, 12 = Park-&-Ride Lot, 13 = Bike Distance, 14 = Departure Time, 15 = Arrival Time, 16 = Link Access, 17 = Lane Connectivity, 18 = Parking Access, 19 = Lane Merging, 20 = Lane Changing, 21 = Turning Speed, 22 = Pocket Merge, 23 = Vehicle Spacing, 24 = Traffic Control, 25 = Access Restriction, 26 = Transit Stop, 27 = Activity Location, 28 = Vehicle Passenger, 29 = Vehicle Location, 30 = Kiss & Ride Lot, 31 = Vehicle ID, 32 = Data Sort,		
run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty can be applied to all stops on a route and/or run). 15 The program re-skims the travel time and impedance components of existing plan records	13	additionally control the way time periods in the input link delay file are used for travel time calculations. By default, volume and travel time after midnight are added to the corresponding early morning time periods. Trips on the network after midnight use these early morning travel times. The new keys can be used to extend the time period processing		
	14	run to adjust the likelihood that a stop will be included in a path based on the capacity constraints of the transit service. Additionally, the stop number is optional (i.e., the penalty		
	15			

household list or an input trip and/or activity file. The print file includes a message about the number of updates that were made. Warning messages sent to the print file can be controlled using the PRINT_UPDATE_WARNINGS key.

