

SubareaNet (version 4.0.11)

Revision History

20 October 2010 Created by Volpe Center

The SubareaNet program:

- 1. Creates subarea network files from regional network files using a subarea boundary polygon in ArcView format.
- 2. Creates subarea transit routes and schedules from regional network files using a subarea boundary polygon in ArcView format.

SubareaNet is a console-based program that runs in a command window on either Windows or Linux. The command syntax is:

```
SubareaNet [-flag] [control file]
```

The control_file is the file name of an ASCII file that contains the control strings expected by the program. The control_file is optional. If a file name is not provided, the program will prompt the user to enter a file name. The flag parameters are also optional. Any combination of the following flag parameters can be included on the command line:

```
-Q[uiet] = execute without screen messages
-H[elp] = show program syntax and control keys
-K[eyCheck] = list unrecognized control file keys
-P[ause] = pause before exiting
-N[oPause] = never pause before exiting
-B[atch] = execute in batch processing mode
```

The program automatically creates a printout file based on the control_file name. If the file name includes an extension, the extension is removed and ".prn" is added. The printout file will be created in the current working directory and will overwrite an existing file with the same name.

Control File Examples

EXAMPLE 1 CREATE SUBAREA NETWORK

The following **SubareaNet** control file creates a smaller network, based on a shapefile that is specified in the control file. The shapefile is an ArcView shapefile with a single polygon record defining the boundary of the subarea.

```
TITLE Creates a subarea network
REPORT_FILE subareanet.prn
REPORT_FLAG True
PROJECT_DIRECTORY

DEFAULT_FILE_FORMAT TAB_DELIMITED

#---- Input Files ----
```

```
NET_DIRECTORY network
NET_NODE_TABLE Node.txt
NET_ZONE_TABLE Zone.txt
        NET_SHAPE_TABLE Shape.txt
NET LINK TABLE Link.txt
       NET_POCKET_LANE_TABLE Pocket_Lane.txt
NET_LANE_USE_TABLE Lane_Use.txt
NET_TOLL_TABLE Toll.txt
        NET_LANE_CONNECTIVITY_TABLE Lane_Connectivity.txt
        NET PARKING TABLE Parking.txt
        NET ACTIVITY LOCATION TABLE Activity_Location.txt
        NET_PROCESS_LINK_TABLE Process_Link.txt
       NET_UNSIGNALIZED_NODE_TABLE Unsignalized_Node
NET_SIGNALIZED_NODE_TABLE Signalized_Node.txt
NET_PHASING_PLAN_TABLE Phasing_Plan.txt
NET_TIMING_PLAN_TABLE Timing_Plan.txt
NET_DETECTOR_TABLE Detector.txt
                                                                             Unsignalized Node.txt
        NET_SIGNAL_COORDINATOR_TABLE Signal_Coordinator.txt
#---- Output Files ----
       NEW_DIRECTORY subnet

NEW_NODE_TABLE Node.txt

NEW_ZONE_TABLE Zone.txt

NEW_SHAPE_TABLE Shape.txt

NEW_LINK_TABLE Link.txt
       NEW_BIRK_TABLE BIRK.txt

NEW_POCKET_LANE_TABLE Pocket_Lane.txt

NEW_LANE_USE_TABLE Lane_Use.txt

NEW_TOLL_TABLE Toll.txt

NEW_LANE_CONNECTIVITY_TABLE Lane_Connectivity.txt

NEW_TURN_PROHIBITION_TABLE Turn_Prohibition.txt
        NEW PARKING TABLE Parking.txt
       NEW_PARKING_TABLE Parking.txt

NEW_ACTIVITY_LOCATION_TABLE Activity_Location.txt

NEW_PROCESS_LINK_TABLE Process_Link.txt

NEW_UNSIGNALIZED_NODE_TABLE Unsignalized_Node.txt

NEW_SIGNALIZED_NODE_TABLE Signalized_Node.txt

NEW_PHASING_PLAN_TABLE Phasing_Plan.txt

NEW_TIMING_PLAN_TABLE Timing_Plan.txt

NEW_TIMING_PLAN_TABLE Detector.txt
        NEW_SIGNAL_COORDINATOR_TABLE Signal_Coordinator.txt CREATE_NOTES_AND_NAME_FIELDS TRUE
       NET_DEFAULT_FORMAT TAB_DELIMITED
NET_NODE_FORMAT TAB_DELIMITED
NET_ZONE_FORMAT TAB_DELIMITED
NET_SHAPE_FORMAT TAB_DELIMITED
NET_LINK_FORMAT TAB_DELIMITED
       NET_POCKET_LANE_FORMAT TAB_DELIMITED

NET_LANE_USE_FORMAT TAB_DELIMITED

NET_TOLL_FORMAT TAB_DELIMITED
       NET_LANE_CONNECTIVITY_FORMAT TAB_DELIMITED NET TURN PROHIBITION FORMAT TAB_DELIMITED
        NET PARKING FORMAT TAB DELIMITED
        NET_ACTIVITY_LOCATION_FORMAT TAB_DELIMITED NET_PROCESS_LINK_FORMAT TAB_DELIMITED
```



```
NET_UNSIGNALIZED_NODE_FORMAT TAB_DELIMITED
NET_SIGNALIZED_NODE_FORMAT TAB_DELIMITED
NET_PHASING_PLAN_FORMAT TAB_DELIMITED
NET_TIMING_PLAN_FORMAT TAB_DELIMITED
NET_DETECTOR_FORMAT TAB_DELIMITED
NET_SIGNAL_COORDINATOR_FORMAT TAB_DELIMITED
NEW_DEFAULT_FORMAT TAB_DELIMITED
NEW_NODE_FORMAT TAB_DELIMITED
NEW_LONE_FORMAT TAB_DELIMITED
NEW_SHAPE_FORMAT TAB_DELIMITED
NEW_LINK_FORMAT TAB_DELIMITED
NEW_LINK_FORMAT TAB_DELIMITED
NEW_LOSE_FORMAT TAB_DELIMITED
NEW_LANE_USE_FORMAT TAB_DELIMITED
NEW_TOLL_FORMAT TAB_DELIMITED
NEW_TOLL_FORMAT TAB_DELIMITED
NEW_TOLL_FORMAT TAB_DELIMITED
NEW_TOLL_FORMAT TAB_DELIMITED
NEW_TURN_PROHIBITION_FORMAT TAB_DELIMITED
NEW_PARKING_FORMAT TAB_DELIMITED
NEW_PARKING_FORMAT TAB_DELIMITED
NEW_PARKING_FORMAT TAB_DELIMITED
NEW_PROCESS_LINK_FORMAT TAB_DELIMITED
NEW_PROCESS_LINK_FORMAT TAB_DELIMITED
NEW_PASIGNALIZED_NODE_FORMAT TAB_DELIMITED
NEW_PHASING_PLAN_FORMAT TAB_DELIMITED
NEW_PHASING_PLAN_FORMAT TAB_DELIMITED
NEW_TIMING_PLAN_FORMAT TAB_DELIMITED
NEW_DETECTOR_FORMAT TAB_DELIMITED
NEW_SIGNAL_COORDINATOR_FORMAT TAB_DELIMITED
```

Control File Parameters

Control parameters are defined using a control key followed by a string or number. The control parameters can be specified in any order. If a given key is defined more than once, the last instance of the key is used. The default value for each key is 0 or "Null". Null parameters do not need to be included in the file. Note that comment lines or extraneous keys can be included in the file. They will be ignored by the program.

The keys recognized by the **SubareaNet** program are listed below. These keys can be defined in a variety of different ways to perform different tasks. The first 15 keys specify the subarea polygon, input network, and output network. They are required; other keys are optional.

Required Keys

SUBAREA_BOUNDARY_POLYGON

The boundary polygon is required. It is an arcview shapefile that contains a single polygon record defining the boundary of the subarea. The polygon should not have any holes, and should minimize the number of significant links crossed by its boundary.

The polygon can be created in any GIS. Here are some steps, taken from the TRANSIMS training course developed at Argonne National Labs, for creating a polygon using uDig:

Zoom in to an area slightly bigger than the polygon to be created



- Choose "Layer" and then "Create Layer" from the menu bar
 - Under "geometry", change the type from "LineString" to "Polygon"
 - Change the coordinate system from "WGS84" (or some other possible default) to the appropriate UTM zone of the TRANSIMS model (TRANSIMS does not convert projections automatically):
 - NAD83 / UTM zone 16N (EPSG:26916) for Chicago
 - NAD83 / UTM zone 18N (EPSG:26918) for Alexandria
- From the tool bar, select the "Create Polygon Tool" (make sure that the newly created layer stays selected when using the polygon tool)
 - Click once for each shape point of the polygon, and double-click to finish polygon creation (create only one polygon)
- In the layer list, right-click on the newly created polygon layer and choose "Rename", then choose a meaningful name (e.g. "SubArea")
- In the layer list, right-click on the newly created polygon layer and choose "Export", then "Layer Export", then choose file name "SubArea.shp"

NET NODE TABLE

The node table key is required. It specifies the name of the TRANSIMS node file within the network directory. The full path and file name for the node table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET_LINK_TABLE

The link table key is required. It specifies the name of the TRANSIMS link file within the network directory. The full path and file name for the link table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET_POCKET_LANE_TABLE

The network pocket lane table key is required. It specifies the name of the TRANSIMS pocket lane file within the network directory. The full path and file name for the pocket lane table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET LANE CONNECTIVITY TABLE

The network lane connectivity table key is required. It specifies the name of the TRANSIMS lane connectivity file within the network directory. The full path and file name for the lane connectivity table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET PARKING TABLE

The network parking table key is required. It specifies the name of the TRANSIMS parking table file within the network directory. The full path and file name for the parking table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET_ACTIVITY_LOCATION_TABLE

The activity location table key is required. It specifies the name of the TRANSIMS activity location file within the network directory. The full path and file name for the activity location table is constructed by appending the value of this key to the value of the NET_DIRECTORY key. The activity location file is a primary input file for the ActGen process. It should contain



one or more data fields used as the attraction weight for the activity location in the location choice model.

NET_PROCESS_LINK_TABLE

The process link table key is required. It specifies the name of the TRANSIMS process file within the network directory. The full path and file name for the process link table is constructed by appending the value of this key to the value of the NET_DIRECTORY key. The process link data are used to assign vehicles to parking lots attached to activity locations.

NEW_NODE_TABLE

The node table key is required. It specifies the name of the TRANSIMS subarea node file within the new directory. The full path and file name for the node table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW LINK TABLE

The link table key is required. It specifies the name of the new TRANSIMS subarea link file within the new directory. The full path and file name for the link table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW POCKET LANE TABLE

The network pocket lane table key is required. It specifies the name of the new TRANSIMS subarea pocket lane file within the new directory. The full path and file name for the pocket lane table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW LANE CONNECTIVITY TABLE

The network lane connectivity table key is required. It specifies the name of the new TRANSIMS subarea lane connectivity file within the new directory. The full path and file name for the lane connectivity table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW PARKING TABLE

The network parking table key is required. It specifies the name of the new TRANSIMS subarea parking table file within the new directory. The full path and file name for the parking table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW_ACTIVITY_LOCATION_TABLE

The activity location table key is required. It specifies the name of the new TRANSIMS subarea activity location file within the new directory. The full path and file name for the activity location table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key. The activity location file is a primary input file for the ActGen process. It should contain one or more data fields used as the attraction weight for the activity location in the location choice model.



New_Process_Link_Table

The process link table key is required. It specifies the name of the new TRANSIMS subarea process file within the new directory. The full path and file name for the process link table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key. The process link data are used to assign vehicles to parking lots attached to activity locations.

Optional Keys

TITLE

Any text string can be used on this line. This text is printed on the top of each output page.

REPORT FILE

The report file name is optional. If a file name is not provided, the program automatically creates a report file name based on the input control file name. The report file will overwrite an existing file with the same name if the Report Flag key is False or not specified.

REPORT_FLAG

The report flag key is optional. Its default is FALSE. If it is specified as Yes or True, the report file or default printout file will be opened in "Append" mode rather than "Create" mode. This permits the user to consolidate the output of several programs into a single report file.

MAX WARNING MESSAGES

When the program generates a warning message, a counter is incremented and the total number of warning messages is reported and a warning return coded (2) is set at the end of the execution. By default the program prints up to 100,000 warning messages to the print-out file. If more than 100,000 warning messages are sent, the program stops printing additional messages to the file or terminates the program with an error message based on the MAX_WARNING_EXIT_FLAG. This parameter enables the user to modify the default warning limit.

MAX WARNING EXIT FLAG

If the maximum number of warning messages is exceeded, this flag directs the program in what to do. If the flag is TRUE (the default), the program is terminated with an error message about the warning messages. If the flag is FALSE, the program continues execution, but no additional warning messages are sent to the screen or written to the printout file. The warning message counter continues to count the messages and reports the total at the end of the execution.

PROJECT DIRECTORY

The project directory key is not required. If it is specified, it is added to all non-network file names required by the program. If it is not specified, all non-network file names should fully specify the file path.

DEFAULT FILE FORMAT

Default format for files other than network files. Default is VERSION3. Other possible values include BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB DELIMITED, CSV DELIMITED, DBASE, LANL and SQLITE3.



NET_DIRECTORY

The network directory key is not required. If it is specified, it is added to all network table names. If it is not specified, the network table names should fully specify the file path.

NET_ZONE_TABLE

The network zone table key is optional. It specifies the name of the TRANSIMS zone file within the network directory. The full path and file name for the zone table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET_SHAPE_TABLE

The network shape table key is optional. It specifies the name of the TRANSIMS shape file within the network directory. The full path and file name for the shape table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET LANE USE TABLE

The network lane use table key is optional. It specifies the name of the TRANSIMS lane use file within the network directory. The full path and file name for the lane use table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET TURN PROHIBITION TABLE

The network turn prohibition table key is optional. It specifies the name of the TRANSIMS turn prohibition file within the network directory. The full path and file name for the turn prohibition table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET TOLL TABLE

The network toll table key is optional. It specifies the name of the TRANSIMS toll file within the network directory. The full path and file name for the toll table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET_UNSIGNALIZED_NODE_TABLE

The network unsignalized node table key is optional. It specifies the name of the TRANSIMS unsignalized node file within the network directory. The full path and file name for the unsignalized node table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET SIGNALIZED NODE TABLE

The network signalized node table key is optional. It specifies the name of the TRANSIMS signalized node file within the network directory. The full path and file name for the signalized node table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET TIMING PLAN TABLE

The network timing plan table key is optional. It specifies the name of the TRANSIMS timing plan file within the network directory. The full path and file name for the timing plan table is constructed by appending the value of this key to the value of the NET_DIRECTORY key



NET_PHASING_PLAN_TABLE

The network phasing plan table key is optional. It specifies the name of the TRANSIMS phasing plan file within the network directory. The full path and file name for the phasing plan table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET_DETECTOR_TABLE

The network detector table key is optional. It specifies the name of the TRANSIMS detector file within the network directory. The full path and file name for the detector table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET_SIGNAL_COORDINATOR_TABLE

The network signal coordinator table key is optional. It specifies the name of the TRANSIMS signal coordinator file within the network directory. The full path and file name for the signal coordinator table is constructed by appending the value of this key to the value of the NET_DIRECTORY key

NET TRANSIT STOP TABLE

The transit stop table is optional. If the stop table is not provided, transit paths cannot be built. This key specifies the name of the TRANSIMS transit stop file within the network directory. The full path and file name for the transit stop table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET TRANSIT ROUTE TABLE

The transit route table is required if the transit stop file is provided. This key specifies the name of the TRANSIMS transit route file within the network directory. The full path and file name for the transit route table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET TRANSIT SCHEDULE TABLE

The transit schedule table is required if the transit stop file is provided. This key specifies the name of the TRANSIMS transit schedule file within the network directory. The full path and file name for the transit schedule table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NET TRANSIT_DRIVER_TABLE

The transit driver table is required if the transit stop file is provided. This key specifies the name of the TRANSIMS transit driver file within the network directory. The full path and file name for the transit driver table is constructed by appending the value of this key to the value of the NET_DIRECTORY key.

NEW_DIRECTORY

The new directory key is not required. If it is specified, it is added to all network table names. If it is not specified, the network table names should fully specify the file path.



NEW_ZONE_TABLE

The network zone table key is optional. It specifies the name of the output TRANSIMS subarea zone file within the new directory. The full path and file name for the zone table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW_SHAPE_TABLE

The network shape table key is optional. It specifies the name of the output TRANSIMS subarea shape file within the new directory. The full path and file name for the shape table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW_LANE_USE_TABLE

The network lane use table key is optional. It specifies the name of the output TRANSIMS subarea lane use file within the new directory. The full path and file name for the lane use table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW_TURN_PROHIBITION_TABLE

The network turn prohibition table key is optional. It specifies the name of the output TRANSIMS subarea turn prohibition file within the new directory. The full path and file name for the turn prohibition table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW_TOLL_TABLE

The network toll table key is optional. It specifies the name of the output TRANSIMS subarea toll file within the new directory. The full path and file name for the toll table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW UNSIGNALIZED NODE TABLE

The network unsignalized node table key is optional. It specifies the name of the output TRANSIMS subarea unsignalized node file within the new directory. The full path and file name for the unsignalized node table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW SIGNALIZED NODE TABLE

The network signalized node table key is optional. It specifies the name of the output TRANSIMS subarea signalized node file within the new directory. The full path and file name for the signalized node table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW TIMING PLAN TABLE

The network timing plan table key is optional. It specifies the name of the output TRANSIMS subarea timing plan file within the new directory. The full path and file name for the timing plan table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key



NEW PHASING PLAN TABLE

The network phasing plan table key is optional. It specifies the name of the output TRANSIMS subarea phasing plan file within the new directory. The full path and file name for the phasing plan table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW_DETECTOR_TABLE

The network detector table key is optional. It specifies the name of the output TRANSIMS subarea detector file within the new directory. The full path and file name for the detector table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW_SIGNAL_COORDINATOR_TABLE

The network signal coordinator table key is optional. It specifies the name of the output TRANSIMS subarea signal coordinator file within the new directory. The full path and file name for the signal coordinator table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key

NEW_TRANSIT_STOP_TABLE

The transit stop table is optional. If the stop table is not provided, transit paths cannot be built. This key specifies the name of the output TRANSIMS subarea transit stop file within the new directory. The full path and file name for the transit stop table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW_TRANSIT_ROUTE_TABLE

The transit route table is required if the transit stop file is provided. This key specifies the name of the output TRANSIMS subarea transit route file within the new directory. The full path and file name for the transit route table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW TRANSIT SCHEDULE TABLE

The transit schedule table is required if the transit stop file is provided. This key specifies the name of the output TRANSIMS subarea transit schedule file within the new directory. The full path and file name for the transit schedule table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NEW TRANSIT DRIVER TABLE

The transit driver table is required if the transit stop file is provided. This key specifies the name of the output TRANSIMS subarea transit driver file within the new directory. The full path and file name for the transit driver table is constructed by appending the value of this key to the value of the NEW_DIRECTORY key.

NET_DEFAULT_FORMAT

Default format for network files. The default file format is set by DEFAULT_FILE_FORMAT. Other options include VERSION3, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, LANL..



NET_*_FORMAT

The file format key enables the user to specify the input format for an input network file. Replace the * with any of the network file types: node, link, pocket_lane, etc. The default file format is set by NET_DEFAULT_FORMAT. Other options include VERSION3, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, LANL.

NEW DEFAULT FORMAT

Default format for new output (subarea) files. The default file format is set by DEFAULT_FILE_FORMAT. Other options include VERSION3, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, LANL.

NEW_*_FORMAT

The file format key enables the user to specify the input format for a new subarea network file. Replace the * with any of the network file types: node, link, pocket_lane, etc. The default file format is set by NEW_DEFAULT_FORMAT. The format options include VERSION3, BINARY, FIXED_COLUMN, COMMA_DELIMITED, SPACE_DELIMITED, TAB_DELIMITED, CSV_DELIMITED, DBASE, LANL.

Algorithmic Notes

A rectangular subarea is drawn around link 22, and includes portions of links 7 and 19 (Figure 1).




Figure 1 Example Network with Subarea Indicated



Figure 2 shows the subarea. If any part of a link is within the subarea polygon, that link becomes part of the subarea. New subarea origin and subarea destination activity locations (numbered 1001 - 1004) were created at nodes 22 and 26 (the boundary of the subarea). Trips that start or end outside of the subarea will enter or exit the subarea at these locations.




Figure 2 Subarea





Sample Printouts

Sample printout files generated by the **SubareaNet** program are shown below. Each printout is an ASCII text file with a maximum of 95 characters per line and 65 lines per page. The file can be viewed or printed using a variety of text editors. For best results in a word processor, use a 10-point Courier font and 0.5 inch margins on all sides.

Example 1

```
Copyright (c) 2009 by AECOM Consult
        Thu Oct 21 10:42:37 2010
Control File = SubareaNet.ctl
Report File = subareanet.prn (Append)
Creates a subarea network
Default File Format = TAB DELIMITED
Network Directory = network
Node File = network\Node.txt
Zone File = network\Zone.txt
Shape File = network\Shape.txt
Link File = network\Link.txt
Pocket Lane File = network\Pocket Lane.txt
Lane Use File = network\Lane Use.txt
Toll File = network\Toll.txt
Lane Connectivity File = network\Lane Connectivity.txt
Parking File = network\Parking.txt
Activity Location File = network\Activity Location.txt
Process Link File = network\Process Link.txt
Unsignalized Node File = network\Unsignalized Node.txt
Signalized Node File = network\Signalized Node.txt
Phasing Plan File = network\Phasing Plan.txt
Timing Plan File = network\Timing Plan.txt
Detector File = network\Detector.txt
Signal Coordinator File = network\Signal Coordinator.txt
New Network Directory = subnet
New Node File = subnet\Node.txt
New Zone File = subnet\Zone.txt
New Shape File = subnet\Shape.txt
New Link File = subnet\Link.txt
New Pocket Lane File = subnet\Pocket Lane.txt
New Lane Use File = subnet\Lane Use.txt
New Toll File = subnet\Toll.txt
New Lane Connectivity File = subnet\Lane Connectivity.txt
New Turn Prohibition File = subnet\Turn Prohibition.txt
New Parking File = subnet\Parking.txt
New Activity Location File = subnet\Activity Location.txt
New Process Link File = subnet\Process Link.txt
New Unsignalized Node File = subnet\Unsignalized Node.txt
New Signalized Node File = subnet\Signalized Node.txt
```

SubareaNet - Version 4.0.11

DRAFT October 2010

```
New Phasing Plan File = subnet\Phasing Plan.txt
New Timing Plan File = subnet\Timing Plan.txt
New Detector File = subnet\Detector.txt
New Signal Coordinator File = subnet\Signal Coordinator.txt
Notes and Name Fields will be Created
Subarea Boundary Polygon = subareapolygon.shp
External Offset Length = 15 meters
Number of Node File Records = 3490
Number of Zone File Records = 577
Number of Shape File Records = 314860
Number of Shape Data Records = 3005
Number of Link File Records = 4797
Number of Link Data Records = 1537
Number of Directional Links = 2570
Number of Pocket Lane File Records = 3315
Number of Lane Use File Records = 83
Number of Toll File Records = 12
Number of Lane Connectivity File Records = 20929
Number of Parking File Records = 18140
Number of Activity Location File Records = 18136
Number of Activity Location Data Records = 5878
Number of Process Link File Records = 36256
Number of Unsignalized Node File Records = 5288
Number of Timing Plan File Records = 2655
Number of Signal Coordinator File Records = 802
Number of Signalized Node File Records = 804
Number of Signalized Node Data Records = 281
Number of Detector File Records = 4748
Number of Phasing Plan File Records = 10954
Number of Subarea Node Records = 1149
Number of Subarea Link Records = 1537
Number of Subarea Pocket Lane Records = 1145
Number of Subarea Lane Connectivity Records = 6900
Number of Subarea Activity Locations = 6005
Number of Subarea Parking Lots = 6009
Number of Subarea Process Links = 11994
```



DRAFT October 2010

```
Number of Subarea Zone Records = 157
Number of Subarea Shape Records = 991
Number of Subarea Lane Use Records = 8
Number of Subarea Turn Prohibition Records = 0
Number of Subarea Toll Records = 8
Number of Subarea Unsignalized Node Records = 1603
Number of Subarea Signalized Node Records = 281
Number of Subarea Timing Plan Records = 927
Number of Subarea Phasing Plan Records = 3800
Number of Subarea Detector Records = 1614
Number of Subarea Signal Coordinator Records = 278
Number of Boundary Links = 75
Number of Short Links Skipped = 0
Number of New Activity Locations = 127
Number of New Parking Lots = 127
Number of New Process Links = 254
Thu Oct 21 10:42:42 2010 -- Process Complete (0:00:05)
```

