AE4301 Automatic Flight Control System Design Part I: Control Theory

Anahita Jamshidnejad Aerospace Engineering Lecture 2



Main objectives

- Understanding characteristics of time-domain transient response & being able to compute them
- Being able to develop and use root locus for pole placement



Material

- Slides on Brightspace
- Homework assignments on Brightspace
- Discussions during lectures




Transient response: Time domain criteria

- We characterize a system's transient response based on unit-step input
- Transient response characteristics are based on assumption of zero initial conditions
- Characteristics for transient response to unit-step input:
 - Overshoot
 - Delay time
 - Rise time
 - Settling time
 - Peak time
- Time domain criteria can be deduced via pole locations




Overshoot & peak time



Overshoot is often given in % of final value




Delay time



Other criteria (e.g. 10%) than the 50% limit may also be used

TUDelft

Rise time




time

Different rise-time criteria is possible (e.g. 0% to 100% or 5% to 95%)



Settling time



Common settling time criteria: 10%; 5%; 2%

TUDelft

1st-order system: Design

- Unit-step response: $y(t) = 1 e^{-t/\tau}$
- Design τ for desired delay time ($y\left(t^{\text{delay}}\right)=0.5$): $\tau=-\frac{t^{\text{delay}}}{\ln 0.5}$
- Design au for desired rise time (10% to 90%): $au = \frac{t^{\mathrm{rise}}}{\ln 9}$
- Design τ for desired 2% settling time, i.e., $y\left(t^{\text{settle}}\right)=0.98$: $\tau=-\frac{t^{\text{settle}}}{\ln 0.02}$
- Question: What is the overshoot?
- **Conclusion:** For 1st-order systems time domain criteria of response can be adjusted via τ



2nd-order system: Design

• Unit-step response (under-damped case):

$$y(t) = 1 - e^{-\zeta \omega_n t} \left(\cos(\omega_d t) + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin(\omega_d t) \right)$$

- Desired peak time: $t^{\rm peak} = \pi/\omega_d$
- Question: What is the overshoot? ... $e^{-\zeta\pi/\sqrt{1-\zeta^2}}$
- Desired rise time (0% to 100%):

$$t^{\text{rise}} = \frac{1}{\omega_n \sqrt{1 - \zeta^2}} \arctan\left(-\frac{\sqrt{1 - \zeta^2}}{\zeta}\right)$$

• For 2nd-order systems time domain criteria of response can be adjusted via ω_n and ζ (i.e., ω_d for under-damped systems)



Pole placement

Pole-placement design: decide on closed-loop pole locations

- Control effort is related to how far open-loop poles are moved by feedback
- When a zero is near a pole, system may be nearly uncontrollable (moving such poles needs large control gains/effort)
- Dominant poles: Poles closest to imaginary axis in s-plane give rise to longest lasting terms of system's transient response. These poles are called dominant poles.




Introduction

transient

Effect dominant pole 1

$$H_1 = 1/(s+1), H_2 = 10/(s+10),$$






Control: Selecting pole locations

- Characteristics of transient response of closed-loop systems is closely related to location of closed-loop poles
- When a variable gain is in closed-loop system, location of closed-loop poles depend on gain value
 Design problem: selection of gain value to, e.g.:
 - Stability (all poles of transfer function must be in LHP)
 - Tracking (force output to follow a reference input as closely as possible)
 - Regulation (keep response's error small in presence of disturbances)



Poles for various gains




Closed loop transfer function: $H_c(s) = \frac{K}{(s+1)(s+3)+K}$

Characteristic equation: $s^2 + 4s + K + 3 = 0$

Poles as function of gain K: $p_{1,2}(K) = -2 \pm \sqrt{1-K}$


TUDelft

Pole locations for various k





Complex numbers: Cartesian representation



Introduction

transient

placement

Root locus

summary



Multiplication & division: Cartesian representation

$$vw = (a + jb)(c + jd) = (ac - bd) + j(ad + bc)$$


$$\frac{v}{w} = \frac{a+jb}{c+jd} = \frac{a+jb}{c+jd} \cdot \frac{c-jd}{c-jd} = \frac{(ac+bd)+j(bc-ad)}{c^2+d^2}$$



Introduction transient placement Root locus

summary

Complex numbers: Polar representation





Multiplication & division: Polar representation

$$v = M_v e^{j\phi_v}$$

$$w = M_w e^{j\phi_w}$$

$$vw = M_v e^{j\phi_v} M_w e^{j\phi_w} = M_v M_w e^{j(\phi_v + \phi_w)}$$

$$\frac{v}{w} = \frac{M_v e^{j\phi_v}}{M_w e^{j\phi_w}} = \frac{M_v}{M_w} e^{j(\phi_v - \phi_w)}$$


Remember:

$$e^{j\phi} = \cos\phi + j\sin\phi$$



Root-locus method

Consider transfer function $G(s) = K \frac{N(s)}{D(s)}$ in a closed loop:



Equivalent closed-loop transfer function:

$$H_{c}(s) = \frac{KN(s)}{D(s) + KN(s)}$$

TUDelft

Root-locus method

- Root locus includes location of roots of closed-loop characteristic equation when gain K varies from 0 to ∞
- Root locus plots are always symmetrical w.r.t. real axis \rightarrow we only need to construct upper (lower) half of root loci
- Characteristic equation:

$$D(s) + KN(s) = 0 \Rightarrow KN(s)/D(s) = -1$$

- Location of poles and zeros of KN(s)/D(s) are determined
- Location of roots of D(s) + KN(s) = 0 or KN(s)/D(s) = -1 when K varies from 0 to ∞ is drawn in complex plane



Rules for root locus

- For K = 0 root locus corresponds to open-loop poles
- n (n number of poles) branches of root locus start at poles and m (m number of zeros) branches end at zeros
- For $K \to \infty$, n-m poles follow the aymptotes to infinity
- Break-away points are obtained from dK/ds = 0
- Root locus includes parts of real axis that are to the left of an odd number of poles and zeros
- Angles of asymptotes with real axis (l = 0, 1, 2, ...):

$$\Phi = \frac{180^{\circ} \left(2l+1\right)}{n-m}$$

Intersection point of asymptotes:

$$\sigma^{\text{int}} = \frac{\sum_{j=1}^{n} Re(p_j) - \sum_{i=1}^{m} Re(z_i)}{n - m}$$



Angle & magnitude conditions

Rewrite characteristic equation as following:

Angle condition:

$$\angle \left(K \frac{(s-z_1)}{(s-p_1)(s-p_2)} \right) = \angle -1$$


$$\angle(s-z_1)-\angle(s-p_1)-\angle(s-p_2)=\pm 180^{\circ}(2l+1)$$
 $l=0,1,2,\ldots$

Magnitude condition:

$$|K| \frac{|s - z_1|}{|s - p_1| |s - p_2|} = |-1|$$



Example



- Suppose $G_1(s) = \frac{K}{s(s+1)(s+2)}$ and $G_2(s) = 1$.
- Sketch root locus plot.





• Step 1. Write down angle and magnitude conditions.



- Step 1. Write down angle and magnitude conditions.
- **Step 2.** Determine root loci on real axis (can any roots be on positive or negative real axis?).



- Step 1. Write down angle and magnitude conditions.
- Step 2. Determine root loci on real axis (can any roots be on positive or negative real axis?).

No root locus on positive real axis.



- Step 1. Write down angle and magnitude conditions.
- Step 2. Determine root loci on real axis (can any roots be on positive or negative real axis?).

No root locus on positive real axis.

Root loci exist on negative real axis between $-\infty$ and -2 and between -1 and 0.



- Step 1. Write down angle and magnitude conditions.
- **Step 2.** Determine root loci on real axis (can any roots be on positive or negative real axis?).

No root locus on positive real axis. Root loci exist on negative real axis between $-\infty$ and -2 and between -1 and 0.

Step 3. Determine asymptotes of root loci.



- Step 1. Write down angle and magnitude conditions.
- **Step 2.** Determine root loci on real axis (can any roots be on positive or negative real axis?).

No root locus on positive real axis. Root loci exist on negative real axis between $-\infty$ and -2 and between -1 and 0.

• Step 3. Determine asymptotes of root loci.

3 asymptotes having angles 60° , -60° , 180° .



- Step 1. Write down angle and magnitude conditions.
- **Step 2.** Determine root loci on real axis (can any roots be on positive or negative real axis?).

No root locus on positive real axis. Root loci exist on negative real axis between $-\infty$ and -2 and between -1 and 0.

- Step 3. Determine asymptotes of root loci.
 3 asymptotes having angles 60°, -60°, 180°.
- Step 4. Determine intersection of asymptotes with real axis.



- Step 1. Write down angle and magnitude conditions.
- **Step 2.** Determine root loci on real axis (can any roots be on positive or negative real axis?).

No root locus on positive real axis. Root loci exist on negative real axis between $-\infty$ and -2 and between -1 and 0.

- Step 3. Determine asymptotes of root loci.
 3 asymptotes having angles 60°, −60°, 180°.
- Step 4. Determine intersection of asymptotes with real axis.
- Step 5. Determine break-away point.

placement

transient



Introduction

summary

Break-away points

Use characteristic equation and compute $\frac{dK}{ds} = 0$:

$$s(s+1)(s+2) + K = 0$$

Those solutions for s that result in a positive K can be considered as break-away points.



Break-away points

Use characteristic equation and compute $\frac{dK}{ds} = 0$:

$$s(s+1)(s+2) + K = 0$$

Those solutions for s that result in a positive K can be considered as break-away points.

$$\frac{dK}{ds} = -(3s^2 + 6s + 2) = 0$$



Summary

- We learned about various characteristics of transient response of 1st and 2nd-order systems via unit-step response
- We learned about dominant poles & root locus

