


Raster-phase tracks: L1 (brown) versus line-to-line planner (green)
Gray area is the survey region; dashed lines are requested survey legs; blue arrows show wind TO direction; P = planned raster corners



Track panels exclude ingress; footer times include the entire AUTO course. Each condition has one recorded flight per controller.