IO Ports – structure and operations

KF6010 - Distributed Real Time Systems

Dr Alun Moon alun.moon@northumbria.ac.uk

Lecture 1a

Useful documentation

- Cortex-M4 Devices Generic User Guide [M4-UG] gives an overview of the device and details of the instruction-set.
- Cortex-M4 Technical Reference Manual [M4-TRM] has details about the memory model (including bit-aliasing [M4-TRM, 3.7]) and the interrupt controller [M4-TRM, 6]
- FRDM-K64F Freedom Module User's Guide [K64F-User] gives an overview of the board and the connectivity (circuit diagrams) of the devices on the board.
- K64 Sub-Family Reference Manual [K64F-Ref]

- M4-TRM. Cortex-M4 Technical Reference Manual. ARM Limited, 2010. http://hesabu.net/kf6010/assets/ra/DDI0439B_cortex_m4_r0p0_trm.pdf.
- M4-UG. *Cortex-M4 Devices Generic User Guide*. ARM Limited, 2010. http:
 - //hesabu.net/kf6010/assets/ra/DUI0553A_cortex_m4_dgug.pdf.
- K64F-Ref. *K64 Sub-Family Reference Manual*. Freescale Semiconductor, Inc., rev. 2 edition, January 2014.
 - http://hesabu.net/kf6010/assets/ra/K64P144M120SF5RM.pdf.
- K64F-User. FRDM-K64F Freedom Module User's Guide. NXP Semiconductors, rev. 1 edition, August 2016.
 - http://hesabu.net/kf6010/assets/ra/FRDMK64FUG.pdf.