PMT User Manual

Version 1.0

Spring 2020

Table Of Contents

Portal

Overview


Page Breakdown

Display GPS Data from File

Portal

<u>Overview</u>

The **Portal** is the place where the sent data can be viewed on a map. The portal also allows the user to download a **.kml** file of the data present on the Web Hosting Site. It is also a place where the **pmt.conf** can be generated (See <u>PMT Device Setup</u>).



Page Breakdown

The Portal is divided in three main regions: **navigation bar**, side **data table** and a center **map panel**.


The **navigation bar** on the top of the page allows the user to: **Download a KML** of the viewed data, **Upload** a data point file from the PMT SD Card (will display as blue stars on map), modify the configurations (**CONFIGS**) and change the viewed **Map Look**.



The left side **data table** allows the user to view and interact with each GPS data point. The map will **zoom** to the desired data point by simply clicking one in the left data point table.




The center **map panel** is the main component of the portal where the data can be plotted on a map. Using mouse interactions, you can zoom or move to specific locations. If a data point is clicked on the map, the corresponding information popup is displayed.



Display GPS Data from File

The Portal provides an easy way to view the data contained in the PMT SD Card. After opening the Portal, click on **UPLOAD** on the top left corner.



Then click on **Choose File** and browse to the PMT SD Card. Select the **data.log** file. Click Upload. The GPS data points contained in the file will be shown in the map as **blue icons**.



IMPORTANT: Uploaded GPS data files are not stored on the Website. The data pints will disappear from the mpa if you refresh the page or close the browser.