

The Physical Layer Chapter 2

- ▶ Theoretical Basis for Data Communications
- Guided Transmission Media
- Wireless Transmission
- Communication Satellites
- Digital Modulation and Multiplexing
- Public Switched Telephone Network
- Mobile Telephone System
- Cable Television

The Physical Layer

Foundation on which other layers build

 Properties of wires, fiber, wireless limit what the network can do

Key problem is to send (digital) bits using only (analog) signals

This is called modulation

Application

Transport

Network

Link

Physical

Theoretical Basis for Data Communication


Communication rates have fundamental limits

- Fourier analysis »
- Bandwidth-limited signals »
- Maximum data rate of a channel »

Fourier Analysis

A time-varying signal can be equivalently represented as a series of frequency components (harmonics):


$$\mathbf{g}(t) = \frac{1}{2}c + \sum_{n=1}^{\infty} a_n \sin(2\pi n f t) + \sum_{n=1}^{\infty} b_n \cos(2\pi n f t)$$




CN5E by Tanenbaum & Wetherall, $^{\odot}$ Pearson Education-Prentice Hall and D. Wetherall, 2011

Bandwidth-Limited Signals

Having less bandwidth (harmonics) degrades the signal








Maximum Data Rate of a Channel

Nyquist's theorem relates the data rate to the bandwidth (B) and number of signal levels (V):

Max. data rate =
$$2B log_2 V bits/sec$$

Shannon's theorem relates the data rate to the bandwidth (B) and signal strength (S) relative to the noise (N):



CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011

Guided Transmission (Wires & Fiber) Media have different properties, hence performance

- Reality check
 - Storage media »
- Wires:
 - Twisted pairs »
 - Coaxial cable »
 - Power lines »
- Fiber cables »

Reality Check: Storage media

Send data on tape / disk / DVD for a high bandwidth link

- Mail one box with 1000 800GB tapes (6400 Tbit)
- Takes one day to send (86,400 secs)
- Data rate is 70 Gbps.

Data rate is faster than long-distance networks!


But, the message delay is very poor.



Wires - Twisted Pair

Very common; used in LANs, telephone lines

Twists reduce radiated signal (interference)



Link Terminology

Full-duplex link

- Used for transmission in both directions at once
- e.g., use different twisted pairs for each direction

Half-duplex link

- ▶ Both directions, but not at the same time
- e.g., senders take turns on a wireless channel

Simplex link


Only one fixed direction at all times; not common



Wires - Coaxial Cable ("Co-

ax")

Also common. Better shielding and more bandwidth for longer distances and higher rates than twisted pair.






Wires - Power Lines

Household electrical wiring is another example of wires

Convenient to use, but horrible for sending data






Fiber Cables (1)

Common for high rates and long distances

- ► Long distance ISP links, Fiber-to-the-Home
- ► Light carried in very long, thin strand of glass






Fiber Cables (2)

Fiber has enormous bandwidth (THz) and tiny signal loss

– hence high rates over long distances



CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011


Fiber Cables (3)

Single-mode

- Core so narrow (10um) light can't even bounce around
- Used with lasers for long distances, e.g., 100km

<u>Multi-mode</u>

- Other main type of fiber
- ► Light can bounce (50um core)
- Used with LEDs for cheaper, shorter distance links



CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011



Fiber Cables (4)

Comparison of the properties of wires and fiber:

Property	Wires	Fiber
Distance	Short (100s of m)	Long (tens of km)
Bandwidth	Moderate	Very High
Cost	Inexpensive	Less cheap
Convenience	Easy to use	Less easy
Security	Easy to tap	Hard to tap

Wireless Transmission


- Electromagnetic Spectrum »
- Radio Transmission »
- Microwave Transmission »
- Light Transmission »
- Wireless vs. Wires/Fiber »

Electromagnetic Spectrum (1)

Different bands have different uses:

- ▶ Radio: wide-area broadcast; Infrared/Light: line-of-sight
- Microwave: LANs and 3G/4G;


Networking focus





Electromagnetic Spectrum (2)

To manage interference, spectrum is carefully divided, and its use regulated and licensed, e.g., sold at auction.






Electromagnetic Spectrum (3)

Fortunately, there are also unlicensed ("ISM") bands:


- ▶ Free for use at low power; devices manage interference
- ▶ Widely used for networking; WiFi, Bluetooth, Zigbee, etc.






Radio Transmission

Radio signals penetrate buildings well and propagate for long distances






In the VLF, LF, and MF bands, radio waves follow the curvature of the earth

In the HF band, radio waves bounce off the ionosphere.



Microwave Transmission

- Microwaves have much bandwidth and are widely used indoors (WiFi) and outdoors (3G, satellites)
 - Signal is attenuated/reflected by everyday objects
 - Strength varies with mobility due multipath fading, etc.




CN5E by Tanenbaum & Wetherall, $^{\odot}$ Pearson Education-Prentice Hall and D. Wetherall, 2011

Light Transmission

Line-of-sight light (no fiber) can be used for links

- Light is highly directional, has much bandwidth
- Use of LEDs/cameras and lasers/photodetectors



 ${\it CN5E} \ by \ Tanenbaum \ \& \ Wetherall, \\ @\ Pearson \ Education-Prentice \ Hall \ and \ D. \ Wetherall, \\ 2011$

Wireless vs. Wires/Fiber

Wireless:

- + Easy and inexpensive to deploy
- Naturally supports mobility
- Naturally supports broadcast
- Transmissions interfere and must be managed
- Signal strengths hence data rates vary greatly

Wires/Fiber:

- + Easy to engineer a fixed data rate over point-to-point links
- ▶ Can be expensive to deploy, esp. over distances
- Doesn't readily support mobility or broadcast

Communication Satellites

Satellites are effective for broadcast distribution and anywhere/anytime communications


- Kinds of Satellites »
- Geostationary (GEO) Satellites »
- Low-Earth Orbit (LEO) Satellites »
- Satellites vs. Fiber »



Kinds of Satellites

Satellites and their properties vary by altitude:

 Geostationary (GEO), Medium-Earth Orbit (MEO), and Low-Earth Orbit (LEO)




CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011

Geostationary Satellites

GEO satellites orbit 35,000 km above a fixed location


- ▶ VSAT (computers) can communicate with the help of a hub
- Different bands (L, S, C, Ku, Ka) in the GHz are in use but may be crowded or susceptible to rain.





Low-Earth Orbit Satellites

Systems such as Iridium use many low-latency satellites for coverage and route communications via them



 ${\it CN5E by Tanenbaum \& Wetherall, @ Pearson Education-Prentice Hall and D. Wetherall, 2011}$

Satellite vs. Fiber

Satellite:

- + Can rapidly set up anywhere/anytime communications (after sate) lites have been launched)
- + Can broadcast to large regions
- ▶ Limited bandwidth and interference to manage

Fiber:

- + Enormous bandwidth over long distances
- Installation can be more expensive/difficult


Digital Modulation and Multiplexing

Modulation schemes send bits as signals; multiplexing schemes share a channel among users.

- Baseband Transmission »
- Passband Transmission »
- Frequency Division Multiplexing »
- Time Division Multiplexing »
- Code Division Multiple Access »

Baseband Transmission

- Line codes send <u>symbols</u> that represent one or more bits
 - ► NRZ is the simplest, literal line code (+1V="1", -1V="0")
 - Other codes tradeoff bandwidth and signal transitions



CN5E by Tanenbaum & Wetherall, © Pearson Education-Four Haifferent line codes Wetherall, 2011



Clock Recovery

- To decode the symbols, signals need sufficient transitions
 - Otherwise long runs of 0s (or 1s) are confusing, e.g.:


0 0 0 0 0 0 0 0 um, 0? er, 0?

- Strategies:
 - Manchester coding, mixes clock signal in every symbol
 - 4B/5B maps 4 data bits to 5 coded bits with 1s and 0s:

Data	Code	Data	Code	Data	Code	Data	Code
0000	11110	0100	01010	1000	10010	1100	11010
0001	01001	0101	01011	1001	10011	1101	11011
0010	10100	0110	01110	1010	10110	1110	11100
h1001/10F	<10101	12 0311 /it	h 0 36411d	าร ส์0 ส์สักก	∄0 €11	1111	11101


Passband Transmission (1)

Modulating the amplitude, frequency/phase of a carrier signal sends bits in a (non-zero) frequency range



Passband Transmission (2)


Constellation diagrams are a shorthand to capture the amplitude and phase modulations of symbols:



CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011

Passband Transmission (3)

Gray-coding assigns bits to symbols so that small symbol errors cause few bit errors:




When 1101 is sent:

Point	Decodes as	Bit errors		
Α	1101	0		
В	110 <u>0</u>	1		
С	1 <u>0</u> 01	1		
D	11 <u>1</u> 1	1		
Е	<u>0</u> 101	1		

Frequency Division


VFDM (Frequency Pivision Multiplexing) shares the channel by placing users on different frequencies:



Frequency Division Multiplexing (2)

Multiplexing (2)
OFDM (Orthogonal FDM) is an efficient FDM technique used for 802.11, 4G
cellular and other communications

Subcarriers are coordinated to be tightly packed




 ${\it CN5E by Tanenbaum \& Wetherall, @ Pearson Education-Prentice Hall and D. Wetherall, 2011}$

Time Division Multiplexing (TDM)

Time division multiplexing shares a channel over time:

- Users take turns on a fixed schedule; this is not packet switching or STDM (Statistical TDM)
- Widely used in telephone / cellular systems




Code Division Multiple Access


CDMA shares the channel by giving users a code

- Codes are orthogonal; can be sent at the same time
- Widely used as part of 3G networks


Sender Codes



$$B = \frac{ +1 +1}{ -1 -1}$$



Transmitted Signal



$$S = +A -B$$

Receiver Decoding

$$S \times C$$
 +2 $O \Rightarrow C \text{ didn't send}$

CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011


The Public Switched Telephone Network

- Structure of the telephone system »
- Politics of telephones »
- Local loop: modems, ADSL, and FTTH »
- Trunks and multiplexing »
- Switching »

Structure of the Telephone System

A hierarchical system for carrying voice calls made of:

- ► Local loops, mostly analog twisted pairs to houses
- ► Trunks, digital fiber optic links that carry calls
- Switching offices, that move calls among trunks






Wetherall, 2011

The Politics of Telephones

- In the U.S., there is a distinction for competition between serving a local area (LECs) and connecting to a local area (at a POP) to switch calls across areas (IXCs)
 - Customers of a LEC can dial via any IXC they choose






Local loop (1): modems

Telephone modems send digital data over an 3.3 KHz analog voice channel interface to the POTS

► Rates <56 kbps; early way to connect to the Internet







Local loop (2): Digital

DSL broadband sends data over the local loop to the local office using ofrequencies that are not used for POTS

- Telephone/computers attach to the same old phone line
- Rates vary with line
 - ► ADSL2 up to 12 Mbps
- ▶ OFDM is used up to 1.1 MHz for ADSL2
 - Most bandwidth down





CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Have D. Upstream Wetherall, 2011

Downstream

Local loop (3): Fiber To The Home

CN5E by Tanenbaum & Wetherall, @ Pearson Education-Prentice Hall and D. Wetherall, 2011

FTTH broadband relies on deployment of fiber optic cables to provide high data rates customers

One wavelength can be shared among many houses

A livello del local local local local local local local local space i costi e la affidabilità (parti ridotte).

In downstream, gli end office possono mandare ad ogni casa in qualsiasi ordine.In upstream, ci sono problemi di collis

Rest of network

Rest of network


Rest of splitter/combiner

Trunks and Multiplexing (1)

pagg. 152-156.


Calls are carried digitally on PSTN trunks using TDM

- ▶ A call is an 8-bit PCM sample each 125 µs (64 kbps)
- Traditional T1 carrier has 24 call channels each 125 μs (1.544 Mbps) with symbols based on AMI



Trunks and Multiplexing (2)

- SONET (Synchronous Optical NETwork) is the worldwide standard for carrying digital signals on optical trunks
 - Keeps 125 μs frame; base frame is 810 bytes (52Mbps)
 - Payload "floats" within framing for flexibility



Trunks and Multiplexing (3)

Hierarchy at 3:1 per level is used for higher rates


- Each level also adds a small amount of framing
- Rates from 50 Mbps (STS-1) to 40 Gbps (STS-768)

SONET		SDH	Data rate (Mbps)		
Electrical	Optical	Optical	Gross	SPE	User
STS-1	OC-1		51.84	50.112	49.536
STS-3	OC-3	STM-1	155.52	150.336	148.608
STS-12	OC-12	STM-4	622.08	601.344	594.432
STS-48	OC-48	STM-16	2488.32	2405.376	2377.728
STS-192	OC-192	STM-64	9953.28	9621.504	9510.912
STS-768	OC-768	STM-256	39813.12	38486.016	38043.648

SONET/SDH rate hierarchy

Trunks and Multiplexing (4)

<u>WDM (Wavelength Division Multiplexing)</u>, another name for FDM, is used to carry many signals on one fiber:




CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011

Ci sono due modi di ripartire:1. ad ogni utente una lunghezza d'onda.2. WDM switched

Switching (1)

Circuit Switching: canale di comunicazione fisico.La path deve essere stabilita prima che possa avvenire

PSTN uses circuit switching; Internet uses packet switching



CN5E by Tanenbaum & Wetherall, $^{\odot}$ Pearson Education-Prentice Hall and D. Wetherall, 2011

Switching (2)


Le possibili path sono storate nel router che avrà il compito di aggiornare le strade percorribili.I pa

<u>Setup (connection) before data</u> flows smoothly

Also teardown at end (not shown)

Packet switching treats messages independently

No setup, but variable queuing delay at routers



CN5E by Tanenbaum & Wetherall, \circledcirc Pearson Education-Prentice Hall and D. Wetherall, 2011

Switching (3)

Comparison of circuit- and packet-switched networks

Item	Circuit switched	Packet switched
Call setup	Required	Not needed
Dedicated physical path	Yes	No
Each packet follows the same route	Yes	No
Packets arrive in order	Yes	No
Is a switch crash fatal	Yes	No
Bandwidth available	Fixed	Dynamic
Time of possible congestion	At setup time	On every packet
Potentially wasted bandwidth	Yes	No
Store-and-forward transmission	No	Yes
Charging	Per minute Per packet	

Mobile Telephone System

- Generations of mobile telephone systems »
- Cellular mobile telephone systems »
- GSM, a 2G system »
- UMTS, a 3G system »

Generations of mobile telephone systems

► AMPS (Advanced Mobile Phone System) is example, deployed from 1980s. Modulation based on FM (as in radio).

2G, analog voice and digital data

 GSM (Global System for Mobile communications) is example, deployed from 1990s. Modulation based on QPSK.

3G, digital voice and data

► UMTS (Universal Mobile Telecommunications System) is example, deployed from 2000s. Modulation based on CDMA


4G, digital data including voice

 LTE (Long Term Evolution) is example, deployed from 2010s. Modulation based on OFDM


Cellular mobile phone

At based on notion of spatial regions called cells

- Each mobile uses a frequency in a cell; moves cause <u>handoff</u>
- Frequencies are reused across non-adjacent cells
- To support more mobiles, smaller cells can be used



Cellular reuse pattern
CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011




Smaller cells for dense mobiles

GSM - Global System for

Mobile Salvided International (IM) card (Subscriber Identity Module) with credentials

- Mobiles tell their HLR (Home Location Register) their current whereabouts for incoming calls
- Cells keep track of visiting mobiles (in the Visitor LR)




CN5E by Tanenbaum & Wetherall, © Pearson Education-Prentice Hall and D. Wetherall, 2011



GSM - Global System for Mobile Communications (2) Air interface is based on FDM channels of 200 KHz divided in an eight-slot


Air interface is based on FDM channels of 200 KHz divided in an eight-slot TDM frame every 4.615 ms

- ▶ Mobile is assigned up- and down-stream slots to use
- ► Each slot is 148 bits long, gives rate of 27.4 kbps



UMTS - Universal Mobile Telecommunications System (1)

Architecture is an evolution of GSM; terminology differs Packets goes to/from the Internet via SGSN/GGSN



UMTS - Universal Mobile Telecommunications System (2)

Air interface based on CDMA over 5 MHz channels

- ▶ Rates over users <14.4 Mbps (HSPDA) per 5 MHz
- ► CDMA allows frequency reuse over all cells

CDMA permits soft handoff (connected to both cells)

Soft Handoff: la connessione con un ripetit
handoff


Cable Television

- Internet over cable »
- Spectrum allocation »
- Cable modems »
- ADSL vs. cable »

Internet over Cable


Internet over cable reuses the cable television plant

 Data is sent on the shared cable tree from the head-end, not on a dedicated line per subscriber (DSL)



Spectrum Allocation


Upstream and downstream data are allocated to frequency channels not used for TV channels:



Cable Modems

Cable modems at customer premises implement the physical layer of the DOCSIS standard

 QPSK/QAM is used in timeslots on frequencies that are assigned for upstream/downstream data



Cable vs. ADSL

Cable:

- + Uses coaxial cable to customers (good bandwidth)
- ▶ Data is broadcast to all customers (less secure)
- Bandwidth is shared over customers so may vary

ADSL:

- + Bandwidth is dedicated for each customer
- Point-to-point link does not broadcast data
- Uses twisted pair to customers (lower bandwidth)

