Data path example for BNZ pc=pc+r1

Control signals	Dem ux	Reg Write	ALU-1 st-Src	ALUop	ALU control	Mem Read	Mem Write	Mem2R eg	PC-Input -Mux-Src	PC-Mux-Src
OPTR r0	1	0	-	00001	-	-	-	-	-	1
BNZ r1	0	0	1	10000	r0-0	0	0	0	1	1 if r0-0 ==0, 0 if !=

// IF r0!=0, pc=pc+r1; ELSE pc=pc+1

