



SAFETY TOOLBOX TALK

Ref:	077	Author:	D Bibby	Date:	22.07.2024
Topic:	Welfare Facilities GP350				

This briefing is not intended to tell you how to do your jobs, it is designed to help keep you safe. We want everybody to be able to return home safely to their family and friends at the end of each day.

The GP350 Mobile Unit is supplied suitable for up to 6 people and conforms fully with the Workplace (Health, Safety & Welfare) Regulations 1992 and the welfare duties set out in the Construction (Design & Management) Regulations 2015.

On arrival each Morning

Check **fuel and oil** levels in the generator and **fresh water** level in the storage butt below sink.

To Start the Engine

The engine is fitted with an electric start and automatic choke/throttle.

Press the ON/OFF button then press and hold the start button until the engine is running.

Once running, allow the engine to warm up for at least 2 minutes before using power. To stop the engine, simply press the ON/OFF button.

Note: Timer switch is set to 3 hours.

Hot/warm water

To be able to get hot/warm water within the welfare unit. The generator should be started and left running for approx. 15-20 minutes, this will pre-heat the water in the boiler. Due to the time it takes to heat up the water, the generator is to be kept running during working hours.

Appliances

The generator has to be started in order to use the kettle and microwave during break times.

Leaving Site

Ensure the unit is securely locked and all shutters closed and locked each day..

When leaving site for the weekend start the generator as there is a 3-hour timer which cuts out the generator, the reason to do this ensure that the battery will hold its charge, ready to use on Monday.

**Discussion Points**

What should you do if the welfare unit fails to start?

How long is the timer for the generator in the welfare unit?