

Risk Assessment No: T003		Task: Loading Articulated Dump Trucks (ADT)							
Prepared By: Derick Bibby				Date: 22.08.2025			RA Review Date: 21.08.2026		
				Reviewed By: Lee Hardy			Date: 22.08.2025		
PPE: Safety Footwear, High Visibility Jacket, High Visibility Trousers, Hard Hat									
Hazard	Persons at Risk	L	S	R	Control Measures	L	S	R	
Striking ADT with excavator/loading shovel bucket	ADT Operative	4	4	16	- Only assigned CPCS trained operatives are permitted to operate plant machinery. - Loading machine of suitable size and sufficient capability. - ADT positioned correctly, as per TMP/instruction from site foreman/supervisor - Handbrake applied during loading, to prevent rolling and being struck by bucket on subsequent loads. - ADT to be positioned on level, solid ground for loading, to ensure ease of access for loading bucket. - Weather conditions must not be so bad as to impair visibility of loading operative. If conditions deteriorate during loading, STOP and reassess when suitable. - Ensure that there is sufficient clearance for ADT to be loaded safely.	2	4	8	
Overloading, falling debris	Site personnel Pedestrians	4	4	16	- Ensure ADT skip bed is fully down, and the rear gate closed. - ADT not to be loaded near pedestrian walkways, where loose spoil could fall and injure personnel. - Load to be filled evenly across skip bed, ensuring that material is not overloaded or hanging over the sides.	2	4	8	