Lab1 - Introduction to Turtlebot

1 Introduction

This lab is designed to do a first approach to the Turtlebot 2 1 and to get use to the ROS network configuration. This robot will be used in the upcoming lab sessions. You can find all the information related to this robot in http://wiki.ros.org/Robots/TurtleBot. Furthermore, this lab session is also an introduction to the ros launch system known as launch files.



Figure 1: Turtlebot 2 with a Kubuki base

2 Pre-lab

Install all the turtlebot packages available in the ros repository by using sudo apt-get install ros-hydro-turtlebot*. It is also recommended to install chrony sudo apt-get install chrony and synchronize the computer sudo ntpdate ntp.ubuntu.com.

After installing all the Turtlebot 2 packages follow this instructions:

- Run roslaunch turtlebot_gazebo turtlebot_world.launch. This package is the one that starts the robot simulation within the Gazebo simulator.
- Add the Willow garage model to the gazebo simulator (place it so the robot is inside the building). You will have the model available after a while in the insert tab.
- Run roslaunch turtlebot_teleop keyboard_teleop.launch in a new terminal. Drive the robot around using the keys indicated in the terminal.
- Run roslaunch turtlebot_gazebo gmapping_demo.launch and roslaunch turtlebot_rviz_launchers view_navigation.launch in two new terminals. Drive the robot around and build a map. Save a screen shot of Rviz where a map of at least two rooms can be seen (the visualizer, not the simulator) and submit it through the Moodle before the day of the lab.

Submit a pdf with a screen capture of the gazebo simulator as well as another capture of the Rviz visualizer with a produced map.

3 Lab work

Most of the work asked here is based on the Turtlebot tutorials from http://wiki.ros.org/Robots/TurtleBot. For the robots use *turtlebot* as user name and *ros* as password.

3.1 Network configuration

In ROS, two main variables have to be set up before start working: the ROS_MASTER_URI, which tells the system which robot/computer will host the roscore, and the ROS_HOSTNAME, which hosts the pc's IP or name. Pay special attention to this two variables if the messages are not properly sent or received over the network. If this happens, it means that the network configuration is wrong and some of the variables can not be resolved to an IP address.

 $Master\ VIBOT$ 1/6

3.1.1 Working with your own computer

In order to set up the network, connect to the appropriate wifi according to the robot (see table 1). Then, configure your network according to the IPs from table 1. For the configuration, three steps are done. First add the Turtlebot to the hosts file in /etc/hosts of your laptop:

 $\$ sudo sh -c 'echo TURLEBOT_IP ROBOT_NAME >> /etc/hosts'

Use the TURTLEBOT_IP and ROBOT_NAME from the following table:

Robot Name	WiFi	Password	Robot's IP
turtlebot1	turtlebot1	turtlebot1	10.42.0.1
turtlebot2	turtlebot2	turtlebot2	10.42.0.1
turtlebot3	turtlebot3	turtlebot3	10.42.0.1
turtlebot4	turtlebot4	turtlebot4	10.42.0.1
turtlebot5	turtlebot5	turtlebot5	10.42.0.1

Table 1: Network configuration for Turtlebots. All passwords are in WEP 128-bit Passphrase.

and your computer's IP for YOUR_IP (you can see your computer's IP by using the ifconfig command). Then, set up your ROS_MASTER_URI:

\$ echo export ROS_MASTER_URI=http://ROBOT_NAME:11311 >> /home/\$(whoami)/.bashrc

finally set up your ROS_HOSTNAME:

\$ echo export ROS_HOSTNAME=YOUR_IP >> /home/\$(whoami)/.bashrc

For all this changes to take effect you have to reload your .bashrc file:

\$ source /home/\$(whoami)/.bashrc

To check if the connection is properly done, first we open an ssh connection to the robot:

\$ ssh turtlebot@ROBOT_NAME

and there, we run a roscore. Then run in your pc's terminal:

\$ rostopic list

This command should return a list of topics if a the ROS master has a core running. If the ROS core is running in the master, and the **rostopic list** does not connects to it, the network configuration is not well done.

Master VIBOT 2/6

3.1.2 Working with the computers from the laboratory

To connect to the robots from the computers in the laboratory you have to connect your windows machine to the appropriate WiFi network 1. Switch on the virtual machine and connect the first network (Intel 82540EM Gigabit Ehternet Controller) to the appropriate turtlebot network and the second network interface (Red Hat Virtio network device) to internet_acess to be able to surf the web.

To check if the connection is properly done, first we open an ssh connection to the robot:

\$ ssh ROBOT_NAME

where ROBOT_NAME is turtlebot# (example: turtlebot1). There, we run a roscore. To set up the desktop terminal to work with that specific turtlebot type:

\$ turtlebot#

where # is the number of the turtlebot you are going to use. This will change your ROS_MASTER_URI to the specified robot. Finally on the desktop run:

\$ rostopic list

This command should return a list of topics if a the ROS master has a core running.

3.2 Bringup

In order to start the robot, ssh into it's computer and run:

\$ roslaunch turtlebot_bringup minimal.launch

and, in your pc's terminal run:

\$ roslaunch turtlebot_dashboard turtlebot_dashboard.launch

This will launch a graphical interface to check the robot's status. Here you can check, among other things, the batteries of both the robot and its pc.

To start the Kinect on the robot run:

\$ roslaunch turtlebot_bringup 3dsensor.launch

and, in a new terminal:

Master VIBOT 3/6

\$ roslaunch turtlebot_rviz_launchers view_robot.launch

Note that running rviz in your own workstation (not the robot's laptop) might end up slowing down the network. If you experience this issue, run the rviz within the robot's laptop.

3.3 Teleoperation

For the keyboard teleoperation ssh into the turtlebot and run:

\$ roslaunch turtlebot_teleop keyboard_teleop.launch

3.4 Navigation and mapping

This robot has already built up packages which allow to build maps using SLAM and also to do autonomous navigation on a given map. First, we are going to use the mapping node to obtain a small map. After bringing up the turtlebot and setting up the keyboard teleoperation, run (in a new terminal):

\$ roslaunch turtlebot_navigation gmapping_demo.launch

In order to visualize the map and the robot's position run:

\$ roslaunch turtlebot_rviz_launchers view_navigation.launch

Drive the robot around to build a small map and capture a screen shot for the report. To save the map use, on the robot's pc:

 $\$ rosrun map_server map_saver -f /tmp/my_map

In order to navigate the robot autonomously on that map launch (on the robot):

\$ roslaunch turtlebot_navigation amcl_demo.launch map_file:=/tmp/my_map.yaml

and close the teleoperation. If you have closed Rviz on your workstation use the same command as for the mapping to open it again. Now click on "2D Pose Estimate" and click where the robot is within the map (click for the position, and point for the direction). Now tell the robot where to go using "2D Nav Goal". Capture the screen while the robot is computing the trajectory for the report.

Master VIBOT 4/6

3.5 Follower

The last tutorials are two funny function for Turtlebot: the follower package and the panorama one. For the follower, run (on the robot):

\$ roslaunch turtlebot_follower follower.launch

Now stand in front of the robot and move, it should follow you if you are not moving fast. For the panorama package run (on the robot):

\$ roslaunch turtlebot_panorama.launch

now you can start the panorama by publishing the following:

\$ rostopic pub turtlebot_panorama/take_pano std_msgs/Empty

or calling the following service:

\$ rosservice call turtlebot_panorama/take_pano 0 360.0 30.0 0.3

it can also be stopped using either one of the following calls:

- \$ rostopic pub turtlebot_panorama/stop_pano std_msgs/Empty
- \$ rosservice call turtlebot_panorama/take_pano 2 360.0 30.0 0.3

capture a panorama for the report. To view the panorama run:

\$ rosrun image_view image_view image:=/turtlebot_panorama/panorama

3.6 Turtlebot driver

Along with the lab documentation you can find a ROS package called lab1_turtlebot. This package contains the script where the lab programming will be done. Please modify the driver.py (lab1_turtlebot/src/driver.py) in order to be able to make the Turtlebot go to a given position. For this purpose, please modify the constructor of the driver class where the definition of the subscriber, publisher and velocity message are missing. You will have to modify also the functions read_position, which stores the position received on a message to the class variables, and compute_velocity where the velocity message is created.

To launch the node run:

Master VIBOT 5/6

\$ roslaunch lab1_turtlebot driver.launch

If no arguments are given to the driver.lanch, the goal point is (0,0,0) for (x,y,θ) . If you want this points to change use:

```
\ roslaunch lab1_turtlebot driver.launch x:=x y:=y theta:=\theta
```

Furthermore, it is possible to launch this node in a virtual environment. For this purpose first you have to set up your masters to your workstation to avoid problems with the real robot:

```
$ export ROS_MASTER_URI=http://localhost:11311
```

(the laboratory desktops have a short cut by typing local in the terminal you want it to have itself as ROS_MASTER_URI) now, the terminal where you have run this command uses your workstation as ROS master. To launch the simulator run:

```
$ roslaunch turtlebot_driver driver.launch sim:=true
```

Please note that the this parameter can be combined with the previous ones to set up a goal location.

4 Optional

Modify you turtlebot_driver.py in order to be able to read from a txt file (given as input for the launch file) a whole trajectory instead of just going to one point. In this case you will have to modify also the function load_goals and next_goal. The trajectory file will have the following structure:

```
x_0, y_0, \theta_0
x_1, y_1, \theta_1
\dots
x_n, y_n, \theta_n
```

and will be passed as an argument called file to the launch file. Please find an example of a trajectory in others/list.txt

5 Lab report

Upload a zip file containing the report without the prelab part (2-3 pages in pdf format) as well as the final driver.py file. If you have done the optional part, please submit the new launch file also.

 $Master\ VIBOT$