Eg. SCI comm with .m in interrupt mode

target model



1. configuration



2. function blocks setting







3. Build, Deploy & Start target model

host .m script

1. run the function with the port seen from device manager and baudrate

```
c2000HostSCICommunication('COM6', 115200);
```

```
>> c2000HostSCICommunication('COM6', 115200)
Enter uint8 data: [23 15 67]
Received data 23  15  67
```