



Executive Service (ES) Tutorial

OSK v3.1



Executive Services (ES) – Overview



Initializes the cFE

- Reports reset type
- Maintains an exception-reset log across processor resets

Creates the application runtime environment

- Primary interface to underlying operating system task services
- Manages application resources
- Supports starting, stopping, and loading applications during runtime

Memory Management

- Provides a dynamic memory pool service
- Provides Critical Data Stores (CDS) that are preserved across processor resets



Executive Services – Applications




- Applications are an architectural component that owns cFE and operating system resources
- Each application has a thread of execution in the underlying operating system (i.e. a task)
- Applications can create multiple child tasks
 - Child tasks share the parent task's address space
- Mission applications are defined in cfe_es_startup.scr and loaded after the cFE applications are created
- Application Restarts and Reloads
 - Start, Stop, Restart, Reload commands
 - Data is not preserved; application run through their initialization
 - Can be used in response to
 - Exceptions
 - On-board Failure Detection and Correction response
 - Ground commands



Executive Services – Performance Analyzer




- Provides a method to identify and measure code execution paths
 - System tuning, troubleshooting, CPU loading
- Executive Service provides Developer inserts execution markers in FSW
 - Entry marker indicate when execution resumes
 - Exit marker indicates when execution is suspended
 - CFE_ES_PerfLogExit() => CFE_SB_RcvMsg() => CFE_ES_PerfLogEntry()
- Operator defines what markers should be captured via filters and defines triggers that determine when the filtered marker are captured
- Captured markers are written to a file that is transferred to the ground and displayed using the cFS Performance Monitor (CPM) tool





Performance Monitor Steps







Performance Monitor Scenario




Trace execution of two apps

- File Manager: Pends indefinitely for a command to perform a file service
 - Uses a child task to perform services used in demo
- Memory Dwell: Pends on 1Hz packet from Scheduler App
 - No correlation between MD's execution and FM's command processing.
- "Send Housekeeping Packet Requests" from Scheduler App has been disabled for both apps

Data collection scenario

- Start data collection
- 2. Wait 4 seconds
- Issue FM "Send Directory in Telemetry" command
- 4. Wait 4 seconds
- 5. Issue FM "Write Directory to File" command
- 6. Wait 4 seconds
- 7. Issue FM "Send Directory in Telemetry" command
- 8. Wait 4 seconds
- 9. Stop data collection

Expected FM Command Trace






Performance Monitor Data Collection Configuration



- Applications define performance IDs that must be unique within a platform
 - Current convention is to define IDs in cfs/apps/xx/fsw/mission_inc/xx_perfids.h
- A cFE ES command sets the "Filter Mask" that defines which performance IDs will be logged
- A cFE ES command sets the "Trigger Mask" that defines which performance IDs are used to start the data collection
 - Data collection can also start when the ES collect data command is received
- A "Masks" is an array of 32-bit words where each bit corresponds to a performance ID 🗘






Boot Sequence



- The PROM boots the OS kernel linked with the BSP, loader and EEPROM file system.
 - Accesses simple file system
 - Selects primary and secondary images based on flags and checksum validation
 - Copies OS image to RAM
- The OS kernel boots the cFE
 - Performs self decompression (optional)
 - Attaches to EEPROM File System
 - Starts up cFE
- cFE boots cFE interface apps and mission components (C&DH, GNC, Science applications)
 - Creates/Attaches to Critical Data Store (CDS)
 - Creates/Attaches to RAM File System
 - Starts cFE applications (EVS, TBL, SB, & TIME)
 - Starts the C&DH and GNC applications based on "cfe_es_startup.scr"






cFE Executive Services Startup



Page 9



The cFE core is started as one unit. The cFE Core is linked with the RTOS and support libraries and loaded into system EEPROM as a static executable.



Startup Script



- The startup script is a text file, written by the user that contains a list of entries (one entry for each application)
 - Used by the ES application for automating the startup of applications.
 - ES application allows the use of a volatile and nonvolatile startup scripts.
 The project may utilize zero, one or two startup scripts.

Object Type	CFE_APP for an Application, or CFE_LIB for a library.	
Path/Filename	This is a cFE Virtual filename, not a vxWorks device/pathname	
Entry Point	This is the name of the "main" function for App.	
CFE Name	The cFE name for the APP or Library	
Priority	This is the Priority of the App, not used for a Library	
Stack Size	This is the Stack size for the App, not used for a Library	
Load Address	This is the Optional Load Address for the App or Library. It is currently not implemented so it should always be 0x0.	
Exception Action	This is the Action the cFE should take if the Application has an exception. • 0 = Do a cFE Processor Reset • Non-Zero = Just restart the Application	



Example cfe_es_startup.scr



```
CFE APP, /cf/apps/ci lab.o, CI Lab AppMain, CI LAB APP, 70, 4096, 0x0, 0;
CFE_APP, /cf/apps/sch_lab.o, SCH_Lab_AppMain, SCH_LAB_APP, 120, 4096, 0x0, 0;
CFE APP, /cf/apps/to lab.o,
                                                          74, 4096, 0x0, 0;
                            TO Lab AppMain, TO LAB APP,
                                                          0, 0x0, 0;
CFE LIB, /cf/apps/cfs lib.o, CFS LibInit, CFS LIB,
! Startup script fields:
! 1. Object Type
                    -- CFE APP for an Application, or CFE LIB for a library.
! 2. Path/Filename -- This is a cFE Virtual filename, not a vxWorks device/pathname
! 3. Entry Point -- This is the "main" function for Apps.
! 4. CFE Name -- The cFE name for the the APP or Library
! 5. Priority
                  -- This is the Priority of the App, not used for Library
! 6. Stack Size -- This is the Stack size for the App, not used for the Library
                    -- This is the Optional Load Address for the App or Library. Currently
! 7. Load Address
not implemented
                       so keep it at 0x0.
! 8. Exception Action -- This is the Action the cFE should take if the App has an exception.
                               = Just restart the Application
                       Non-Zero = Do a cFE Processor Reset
! Other Notes:
! 1. The software will not try to parse anything after the first '!' character it sees. That
    is the End of File marker.
! 2. Common Application file extensions:
    Linux = .so (ci.so)
  OS X = .bundle (ci.bundle)
    Cygwin = .dll (ci.dll)
    vxWorks = .o (ci.o)
    RTEMS with S-record Loader = .s3r ( ci.s3r )
    RTEMS with CEXP Loader = .o ( ci.o )
```



Executive Services – Logs



Exception-Reset

Logs information related to resets and exceptions

System Log

- cFE apps use this log when errors are encountered during initialization before the Event Services is fully initialized
- Mission apps can also use it during initialization
 - Recommended that apps should register with event service immediately after registering with ES so app events are captured in the EVS log
- Implemented as an array of bytes that has variable length strings produced by printf() type statements



Executive Services – Reset Behavior



Power-on Reset

- Operating system loaded and started prior to cFE
- Initializes file system
- Critical data stores and logs cleared (initialized by hardware first)
- ES starts each cFE service and then the mission applications

Processor Reset Preserves

- File system
- Critical Data Store (CDS)
- ES System Log
- ES Exception and Reset (ER) log
- Performance Analysis data
- ES Reset info (i.e.reset type, boot source, number of processor resets)
- Time Data (i.e. MET, SCTF, Leap Seconds)
- A power-on reset will be performed after a configurable number of processor resets
 - Ground responsible for managing processor reset counter
- Service initialization order: ES, EVS, SB, TIME, TBL, FS
- Service app initialization order: EVS, SB, ES, TIME, TBL
- Applications images are often compressed in non-volatile memory and decompressed by ES when they are loaded



Executive Services – Retrieving Onboard State



Telemetry

- Housekeeping Status
 - Log file states, App, Resets, Performance Monitor, Heap Stats

Telemetry packets generated by command

- Single App Information
- Memory Pool Statistics Packet
- Shell command output packet

Files generated by command

- System Log
- Exception-Reset Log
- Performance Monitor
- Critical Data Store Registry
- All registered apps
- All registered tasks





Executive Services System Integration and App Development (1 of 2)



Child Tasks

- Recommend creating during app initialization
- Relative parent priority depends on child's role
 - Performing lengthy process may be lower
 - Servicing short duration I/O may be higher

os	Call	Notes
Posix/Linux	pthread_create()	
RTEMS	rtems_task_create()	
VxWorks	taskSpawn()	



Executive Services System Integration and App Development (2 of 2)



- Query startup type (Power On vs Processor)
 - Not commonly used since CDS performs data preservation

Critical Data Store (CDS)

- E.g. Data Storage maintains open file management data in a CDS
- Typical code idiom in app's initialization

```
Result = CFE_ES_RegisterCDS()
if (Result == CFE_SUCCESS)
    Populate CDS
else if (Result == CFE_ES_CDS_ALREADY_EXISTS)
    Restore CDS data
... Continually update CDS as application executes
```

Memory Pool

- Ideally apps would allocate memory pools during initialization but there aren't any restrictions
- cFE Examples: Software Bus, Tables, and Events
- App Examples: CFDP and Housekeeping





Executive Services – Configuration Parameters



List parameters that with higher probability of being tuned



Executive Services APIs



Utility Functions	Purpose
CFE_ES_GetBlockInCDS	Allocate a block of space in the critical data store
CFE_ES_WriteToSysLog	Write to provided string to the System Log
CFE_ES_CalculateCRC	Calculate a data integrity value on a block of memory.
Critical Data Store (CDS) Functions	Purpose
CFE_ES_RegisterCDS	Allocates a block of memory in the Critical Data Store for a cFE Application
CFE_ES_CopyToCDS	Saves a block of data to the CDS
CFE_ES_RestoreFromCDS	Recover a block of data from the CDS
Memory Pool Functions	Purpose
CFE_ES_PoolCreate	Manages a memory pool created by an application
CFE_ES_GetPoolBuf	Gets a buffer from the memory pool created by CFE_ES_CreatePool
CFE_ES_PutPoolBuf	Releases a buffer from the memory pool
Performance Analysis Functions	Purpose
CFE_ES_PerfLogEntry	Entry marker for the performance analysis tool



Executive Services APIs



Application and Task Control Functions	Purpose
CFE_ES_GetResetType	Identifies the type of the last reset the processor most recently underwent
CFE_ES_ResetCFE	Perform a reset of the cFE Core and all of the cFE Applications
CFE_ES_RestartApp	Perform a restart of the specified cFE Application
CFE_ES_ReloadApp	Stops and then Starts a cFE Application from the specified file
CFE_ES_DeleteApp	Deletes a cFE Application
CFE_ES_ExitApp	Provides an exit point for a cFE Application's run loop
CFE_ES_RegisterApp	Register the cFE Application
CFE_ES_GetAppIDByName	Returns the cFE Application ID corresponding to the given cFE Application name
CFE_ES_GetAppID	Returns the cFE Application ID of the calling cFE Application
CFE_ES_GetAppName	Returns the cFE Application Name of the calling cFE Application
CFE_ES_GetTaskInfo	Returns info about the specified child task ID including Task name, Parent task etc.
CFE_ES_RegisterChildTask	Register a child task (note each cFE Application has a main task)
CFE_ES_CreateChildTask	Create a child task
CFE_ES_DeleteChildTask	Delete a child task
CFE_ES_ExitChildTask	Exits a child task