

## Example: parallel port (LPTI)

Three registers




 Every bits (except IRQ) corresponds to a pin on 25-pin connector





## Parallel Port Driver



```
void
sendbyte(uint8_t byte)
 /* Wait until \overline{BSY} bit is 1. */
 while ((inb (0x379) & 0x80) == 0)
   delay ();
 /* Put the byte we wish to send on pins D7-0. */
  outb (0x378, byte);
  /* Pulse STR (strobe) line to inform the printer
  * that a byte is available */
 uint8_t ctrlval = inb (0x37a);
  outb (0x37a, ctrlval \mid 0x01);
 delay ();
 outb (0x37a, ctrlval);
```