

TAG DESCRIPTION TABLE

83495C1CV9D0P1

19 August 2014

abbrsect

Abbreviation Section

Description: Identifies the paragraph used to define abbreviations/acronyms and the associated list.

Source paragraph: MIL-STD-38784A 4.3.4 & 4.5.9

Content Model: (((*title*)?, (*warning* | *caution* | *note* | *para* | *step1*)*, *subpara1*)*, (*abbrtitle*?, *acronymlist*))

Parents: [foreword](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCl *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

abbrtitle

Abbreviation Title

Description: Identifies the title for the list of acronyms and abbreviations.

Source paragraph: MIL-STD-38784A 4.3.4 & 4.5.9

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrsect](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

acronym

Acronym

Description: Identifies the first time an acronym or abbreviation is used in a chapter. The def part of the acronym is used to define the acronym/abbreviation, while the term part of the acronym contains the actual acronym/abbreviation. Within the text, the term portion will be surrounded with parenthesis.

Source paragraph: MIL-STD-38784A 4.3.4 & 4.5.9

Content Model: (def, term) -(acronym | figure | table | foldout | objmedia)

Parents: abbrtitle, activity, address, applicabil, apptitle, authnot, cage, change, chap, chapno, chaptitle, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, faultcode, ftnote, func, functitle, hazmat, ilink, insertpg, internatlst, item, label, lepchg, leppage, line, maintlvl, mfr, mfrnad, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, persreq, phrase, pretmidno, prindex, pubdate, purpose, reference, remarks, removepg, revnum, secindex, seqno, sermo, sigblock, spec, sssn, subject, subtitle, supersed, suppl, symtitle, system, tctono, term, tfnid, title, tmidno, tpdrllocation, tpdarno, typedes, typeno, underline, use, volnot, volnum

Excluded in: acronym, acronymlist

Entities used in this element: chgatt, delstat, exclus, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

acronymlist

Acronym/Abbreviation List

Description: Identifies the list of acronyms and abbreviations.

Source paragraph: MIL-STD-38784A 4.3.4 & 4.5.9

Content Model: (acronymrow+ | (term, def)+) -(acronym | figure | table | foldout | objmedia)

Parents: abbrsect

Entities used in this element: chgatt, delstat, exclus, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.5in	Allows you to define the right term width.
ltermwidth	NUTOKEN	1in	Allows you to define the left term width.
autobuild	CDATA	#CONREF	This attribute should be set equal to 1. when the acronymlist is autogenerated.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

acronymrow

Description:

Source paragraph:

Content Model: (term, def)

Parents: acronymlist

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

activity

Reporting Activity

Description: Identifies the activity submitting a technical publication deficiency report list.

Source paragraph: MIL-STD-38784A 4.5.9

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: tpdrow, tpdrtbl

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

addata

Additional Data

Description: All other technical data required in the function.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.8

Content Model: (para+ | none | notapp | refertab)

Parents: incond

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

addcontents

Add contents

Description: Added to the contentsentry to allow other TOs to be illustrated in the table of contents per the authors disgression.

Source paragraph: MIL-DTL-83495C 3.4.3.1.1

Content Model: (chaptitle, functitle+)+

Parents: [contentsentry](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

address

Change Sheet Name/Address

Description: Identifies the name and address of the activity responsible for preparation of the change instruction sheet.

Source paragraph: MIL-STD-38784A 4.7.3.10.2

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginsst](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

all

All

Description: Used when applicability is all

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.1

Content Model: EMPTY

Parents: [appl](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

appl

Applicability

Description: Defines the applicability codes.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.1

Content Model: (([para](#))⁺ | [all](#) | ([applicd](#)?⁺, [applic](#)⁺)⁺)

Parents: [incond](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

applic

Applicability/Effectivity Definition Entry

Description: Defines applicability/effectivity markings.

Source paragraph: MIL-STD-38784A 4.3f & 4.5.9

Content Model: ([term](#), [def](#))

Parents: [appl](#), [applicdef](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#REQUIRED	Allows the author to generate a unique ID for use when referencing this entry.
flagnote	NUMBER	1	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

applicabil

Applicability/Effectivity

<i>Description:</i>	Identifies a portion of text as being applicable to a specific model, serial number, part number, etc. Use of this element will cause the applicabilty/effectivity markings defined in the applicability definition (applicdef) to appear at that point in running text.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3f
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(applicabil figure table foldout objmedia)
<i>Parents:</i>	abbrtitle , activity , address , applicabil , applttitle , authnot , cage , change , chap , chapno , chapttitle , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , faultcode , ftnote , func , functitle , hazmat , ilink , insertpg , internatlst , item , label , lepchg , leppage , line , maintlvl , mfr , mfrnad , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , persreq , phrase , pretmidno , prindex , pubdate , purpose , reference , remarks , removepg , revnum , secindex , seqno , sermo , sigblock , spec , sssn , subject , subtitle , supersd , suppl , symtitle , system , tctono , term , tfnid , title , tmidno , tpdrlocation , tpdrno , typedes , typeno , underline , use , volnot , volnum
<i>Excluded in:</i>	applicabil , extapplicabil
<i>Entities used in this element:</i>	chgatt , delstat , exclus , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
applicref	IDREFS	#REQUIRED	Allows you to assign an applicable reference to this element.
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

applicdef

Applicability/Effectivity Definition

<i>Description:</i>	Identifies the paragraph used to define applicability/effectivity markings, and the associated list.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3f
<i>Content Model:</i>	((title)?, (warning caution note para step1)*, subpara1 *)?, (applttitle ?, applichd ?, applic +))
<i>Parents:</i>	foreword
<i>Entities used in this element:</i>	bodyatt , chgatt , content , db , delstat , itemid , para0att , parazero , secur , status , verified , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.5in	Allows you to set the right term width.
ltermwidth	NUTOKEN	1in	Allows you to define the left term width.
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCL *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

applichd

Appicabilty/Effectivity List Column Headings

Description: Defines the column headings used for the applicabilty/effectivity list.

Source paragraph: MIL-STD-38784A 4.3f

Content Model: ([term](#), [def](#))

Parents: [appl](#), [applicdef](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

appltile

Appicability/Effectivity Definition

Description: Identifies the title for the applicabilty/effectivity list.

Source paragraph: MIL-STD-38784A 4.3f

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [applicdef](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

authnot

Authority Notice

Description: Identifies the authority notice at the bottom of the title page.

Source paragraph: MIL-STD-38784A 4.5.1.15

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

bindByCoords

Description:

Source paragraph:

Content Model: ([xref](#)^{*})

Parents: [graphic](#)

Entities used in this element: [cgmatts](#), [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
coords	CDATA	#REQUIRED	
id	ID	#IMPLIED	
title	CDATA	#IMPLIED	
descript	CDATA	#IMPLIED	
visibility	(visible hidden)	visible	
interactivity	(interactive none)	none	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	

Attribute	Type	Default	Description
revchg	NUMBER	0	

bindById

Description:

Source paragraph:

Content Model: (xref*)

Parents: [graphic](#)

Entities used in this element: [cgatts](#), [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
objectid	CDATA	#REQUIRED	
id	ID	#IMPLIED	
title	CDATA	#IMPLIED	
descript	CDATA	#IMPLIED	
visibility	(visible hidden)	visible	
interactivity	(interactive none)	none	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

bindByName

Description:

Source paragraph:

Content Model: (xref*)

Parents: [graphic](#)

Entities used in this element: [cgatts](#), [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
apstargetname	CDATA	#REQUIRED	
id	ID	#IMPLIED	
title	CDATA	#IMPLIED	
descript	CDATA	#IMPLIED	
visibility	(visible hidden)	visible	
interactivity	(interactive none)	none	

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

body

Body

Description: Identifies the portion of the manual where chapters are used, exclusive of front matter and appendices, indexes, etc.

Source paragraph: MIL-STD-38784A 4.2.9.3 & 4.5.1.3.2 & 3.2.38

Content Model: (([gchapter?](#), ([gchaptercontinue](#) | [chaptercontinue](#))?), ([chapter](#)*)) +([ftnote](#))

Parents: [docjg](#)

Entities used in this element: [bodyele](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
numcols	(1 2)	#REQUIRED	Allows the author to define the page format as one or two columns for this section of the manual.

brk

Break

Description: This element is used to indicate that a column, line, or page break should be forced at that point. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: EMPTY

Included in: [doc](#), [docjg](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	(col line npg)	line	Allows the author to define what type of break will occur when the brk element is used - column, line, or page.

cage

Cage

Description: Defines the cage codes in the consumable tables.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.5

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [consumtab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

caution

Caution

Description: Identifies a CAUTION in the manual.

Source paragraph: MIL-STD-38784A 4.3.10

Content Model: ([para](#)^{*}) -([randlist](#) | [deflist](#) | [seqlist](#) | [figure](#) | [table](#) | [foldout](#) | [objmedia](#) | [warning](#) | [caution](#))

Parents: [abbrsect](#), [applicdef](#), [entry](#), [lrp](#), [para0](#), [ratddesc](#), [safecond](#), [step](#), [step1](#), [step2](#), [step3](#), [step4](#), [subpara1](#), [subpara2](#), [subpara3](#), [subpara4](#), [subpara5](#), [subpara6](#), [subpara7](#), [subpara8](#), [symsect](#), [tctolist](#), [tmimprep](#)

Included in: [function](#), [gchapter](#), [safesum](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [list](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

change

Changed Information

Description: Identifies material that has been changed. In order to add material, the type attribute should be set to add, and the change element should surround the added material. In order to delete material where a complete history of all changes to the document are being preserved, the type attribute should be set to delete and the change element should surround the deleted material. If all changes are not being preserved, change the material and surround it with a change element, setting the type attribute to add.

Source paragraph: MIL-STD-38784A 4.7.3.9

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [ssn](#), [subject](#), [subtitle](#), [supersd](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [exclus](#), [secur](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
level	NMTOKEN	#REQUIRED	Defines the change level for the modification.
change	(add delete)	add	Defines the type of change - addition or deletion of text.
mark	NUMBER	1	Allows the author to define if a change mark will appear for this change. 1. will produce a change bar on the page - 0 will suppress it.
revchg	NUMBER	0	Allows the author to tag whether this modification is for a revision or a change. Zero indicates a change. 1. for a revision.
security	(u c s n)	n	Identifies security level of the document

chap

Chapter Title For Job Guide Index

Description: Defines the chapter title in the job guide index.

Source paragraph: MIL-DTL-83495C 3.4.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [jgindextab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

chapno

Chapter Number

Description: Defines the chapter number in the job guide index.

Source paragraph: MIL-DTL-83495C 3.4.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [jgindextab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

chapter

Chapter

Description: Identifies a chapter.

Source paragraph: MIL-STD-38784A 4.2.9.3

Content Model: (([title](#), [function+](#))) +([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [body](#)

Entities used in this element: [bodyatt](#), [chap](#), [chapatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [inclus](#), [itemid](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

chaptercontinue

Chapter Continue

Description: Identifies a chapter that is continued in a new volume.

Source paragraph:

Content Model: (function+) +(figure | table | foldout | objmedia)

Parents: body

Entities used in this element: bodyatt, chapatt, chgatt, content, db, delstat, inclus, itemid, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
chapcontstart	NUMBER	#IMPLIED	Value used to start a continued chapter in a new volume.
lastpagenum	NUMBER	#IMPLIED	Allows you to continue the correct page number onto a new book/volume.
id	ID	#IMPLIED	
security	(u c s n)	n	
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

chaptitle

Chapter Title

Description: Defines the chapter title in the addcontents element.

Source paragraph: MIL-DTL-83495C 3.4.3.1.1

Content Model: ((#PCDATA | change | tabmat | fnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: addcontents

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	
sssn	CDATA	#IMPLIED	

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

chgdate

Change Date

Description: Identifies the date of the latest change.

Source paragraph: MIL-STD-38784A 4.5.1.17

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [text](#)

chghistory

Change History

Description: Identifies the beginning of the change history dates. The first date in the chghist is the original date and subsequent dates are change 1, change 2, etc.

Source paragraph: MIL-STD-38784A 4.5.3

Content Model: ([chginfo](#)^{*})

Parents: [idinfo](#)

chginfo

Change Information

Description: Container element to identify the change information contained in the change history of the document.

Source paragraph: MIL-STD-38784A 4.5.3

Content Model: ([chgtxt](#)[?], [date](#))

Parents: [chghistory](#)

chginssht

Change Instruction Sheet

Description: Identifies the change instruction sheet.

Source paragraph: MIL-STD-38784A 4.7.3.10.2

Content Model: ([chgnum](#), [address](#), [date](#), [prtitle](#), [effdatenot?](#), [disc?](#), [distrib](#), [expcont?](#), [destr?](#), [chgpara+](#), [chglist](#), [sigblock?](#))

Parents: [front](#)

Entities used in this element: [chgsht](#)

chglist

Change List

Description: Identifies the Remove Pages and Insert Pages columns on the change instruction sheet.

Source paragraph: MIL-STD-38784A 4.7.3.10.2

Content Model: ([tabmat](#) | ([removepg](#), [insertpg](#))⁺)

Parents: [chginssht](#)

chgnum

Change Number/Letter

Description: Identifies the latest change number/letter.

Source paragraph: MIL-STD-38784A 4.7.3.1, 4.2.1.4.2.3, 4.5.1.17, & 4.5.3.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

chgpara

Change para

<i>Description:</i>	Identifies the paragraph change status.
<i>Source paragraph:</i>	MIL-STD-38784A 4.7.3.11.2
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	chginsst
<i>Entities used in this element:</i>	text

chgrec

Change Record

<i>Description:</i>	Identifies the change record page. This page will be an empty table whose contents will be completed by the person filing the change pages in the manual. The change record page will be automatically generated by the FOSI.
<i>Source paragraph:</i>	MIL-STD-38784A 4.5.5
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	front

chgtxt

Change Text

<i>Description:</i>	This element is optional and is used to provide a alpha representation of the current change level. This element will only be tagged by those branches of the armed services that require alpha change numbers. For all other users, this element is optional and should not be tagged.
<i>Source paragraph:</i>	MIL-STD-38784A 4.5.3
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	chginfo
<i>Entities used in this element:</i>	text

clink

Contextual Link

Description: One of several HyTime elements. Can be used in any situation similar to the xref or extref element - will reference any nameloc declared.

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chapttitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [funcititle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstid](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tnfid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
HyBase	NAME	#FIXED hylink	Used in combination with HyTime to establish contextual link.
HyBnames	CDATA	#FIXED "refsub linkend"	Used in combination with HyTime to establish contextual link.
anchrole	CDATA	#FIXED "refmark refsub #LIST"	Used in combination with HyTime to establish an anchor role for contextual links.
anchcstr	NAMES	"self required"	Used in combination with HyTime to establish type of anchor string defined for a contextual link.
linkend	CDATA	#IMPLIED	References a linkend declared within a nameloc element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

clreq

Checklist Requirements

Description: Defines the checklist requirements in the input conditions.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.7

Content Model: ([para](#)⁺ | [notapp](#) | [none](#))

Parents: [incond](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

cntentry

Description:

Source paragraph:

Content Model: [\(label, title, pageno\)](#)

Parents: [contents](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
inlevel	NUMBER	#IMPLIED	
delype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

cogact

Cognizant Field Activity

<i>Description:</i>	Identifies Cognizant Field Activity on the title page and is included in the distribution statement. This is a Navy requirement.
<i>Source paragraph:</i>	MIL-STD-38784A 4.5.1.11
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	idinfo
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

colspec

Column Specification

<i>Description:</i>	Defines a column in a table. Each column must have a column specification. The column specification defines the width of the column and an optional name used when column is starting or ending a horizontal span or referenced in a table entry. Column specifications in a table group apply to the table heading (boxheads) and the table body. The table heading can redefine the column specifications if needed, however, the table body must use the column specifications defined in the table group.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3.9
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	entrytbl , tfoot , tgroup , thead
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
colname	NMTOKEN	#IMPLIED	Allows the author to define a column name.
colnum	NUMBER	#IMPLIED	Allows the author to define a column number.
align	(left right center justify char)	#IMPLIED	Allows the author to align text within the cell.

Attribute	Type	Default	Description
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column.
leftmar	NUTOKEN	#IMPLIED	Defines the left margin for the cell.
rightmar	NUTOKEN	#IMPLIED	Defines the right margin for the cell.
topmar	NUTOKEN	#IMPLIED	Defines the top margin for the cell.
botmar	NUTOKEN	#IMPLIED	Defines the bottom margin for the cell.
mindepth	NUTOKEN	#IMPLIED	Allows you to define a minimum depth if desired.
colwidth	CDATA	#IMPLIED	Allows you to define the column widths.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

consum

Consumables

Description: Defines the consumable items in the input conditions.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.5

Content Model: ([consumtab](#) | [none](#) | [notapp](#))

Parents: [incond](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	

Attribute	Type	Default	Description
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

consumtab

Consumable Table

Description: Defines the consumable table in the input conditions.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.5

Content Model: (nomen, (spec | partno), (cage | mfrnad), use, reference)+

Parents: [consum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

contents

Table of Contents

Description: Identifies the table of contents. For Army documents, the table of contents consists of chapter and section titles. For all other services, the table of contents consists of chapter, section, and paragraph titles. If an index is used, the table of contents consists of chapter, section, and primary paragraph titles. This information is automatically compiled by the FOSI.

Source paragraph: MIL-STD-38784A 4.5.6

Content Model: (([cntentry](#)* | #PCDATA)*) -([note](#))

Parents: [toc](#)

Entities used in this element: [chgatt](#), [cntnt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	This attribute should be set equal to 1. when the acronymlist is autogenerated.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

contentsentry

Contents Entry

Description: Entry in the table of contents

Source paragraph: None

Content Model: ([tmidno](#), [title](#), [sssn*](#), [addcontents?](#))

Parents: [toc](#), [toc](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

contractno

Contract Number

Description: Identifies the contract number on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [secur](#), [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document

copyright

Copyright Notice

Description: Identifies the copyright notice on the title page.

Source paragraph: MIL-STD-38784A 4.1.2 & 4.5.1.14

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

dataiden

Data Identification

Description: May be used to identify specific types of data (e.g. hazardous materials, special tools, etc.). Use of this element does not affect the formatted output, but is intended to be used in database functions and data searches.

Source paragraph: MIL-STD-38784A 4.5.1.7, 4.5.1.16, 4.5.1.17, & 4.5.3.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([dataiden](#) | [figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretnidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [ssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Excluded in: [dataiden](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	CDATA	#REQUIRED	Defines the type of data being used in the database functions and database searches.
security	(u c s n)	n	Identifies security level of the element.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

date

Date

Description: Identifies a date.

Source paragraph: MIL-STD-38784A 4.5.1.17 & 4.5.9.4b

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -(figure | table | foldout | objmedia)

Parents: [chginfo](#), [chginsst](#), [ratdentry](#), [tctorow](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

dateinc

Date Incorporated

Description: Identifies the date the information affected by the directive or engineering change proposal was incorporated into the manual.

Source paragraph: MIL-STD-38784A 4.5.9.4d

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -(figure | table | foldout | objmedia)

Parents: [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

def

Definition

Description: Identifies a term and definition in a list.

Source paragraph: MIL-STD-38784A 4.3.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [acronym](#), [acronymlist](#), [acronymrow](#), [applic](#), [applichd](#), [defhd](#), [deflist](#), [symrow](#), [symsect](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

defhd

Definition List Column Headings

Description: Identifies the column headings for a definition list.

Source paragraph: MIL-STD-38784A 4.3.4

Content Model: ([term](#), [def](#))

Parents: [deflist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

deflist

Definition List

Description: Identifies a two-column definition list. This element can be used when a listing is needed to define particular terms.

Source paragraph: MIL-STD-38784A 4.3.4

Content Model: ([title?](#), [defhd?](#), ([term](#), [def](#))+)

Parents: [entry](#), [fnote](#), [para](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	1.9in	Allows you to set the right term width.
ltermwidth	NUTOKEN	0.7in	Allows you to define the left term width.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

destr

Destruction Notice

Description: Identifies the destruction notice on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.13

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

discl

Disclosure Notice

Description: Identifies the disclosure notice on the title page. The title is automatically generated by the FOSI.

Source paragraph: MIL-STD-38784A 4.5.1.10

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
disclos1	CDATA	#IMPLIED	Identifies which type of disclosure statement will appear on the title page. Use of this attribute will generate an alternate disclosoure notice as opposed the notice generated by the FOSI.

distrib

Distribution Statement

Description: Identifies the distribution statement. The title is automatically generated by the FOSI.

Source paragraph: MIL-STD-38784A 4.5.1.11

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginssht](#), [idinfo](#)

Entities used in this element: [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	(A B C D E F X)	#REQUIRED	Displays distribution statement A when type is equal to A. Attribute defaults to other allowing the author to enter their own distribution statement text.

doc

Document

Description: Identifies the entire document (technical manual).
Source paragraph: MIL-STD-38784A 4.1.7
Content Model: (docjg) +(pgbrk | brk | subjinfo | line | modreq | location | note)
Entities used in this element: [doc](#), [docatt](#), [pubatts](#), [secur](#), [service](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD FRN)	#REQUIRED	Identifies which branch of service.
FRN	CDATA	#IMPLIED	
docid	CDATA	#IMPLIED	Allows for the author to define an identification number for the document.
docstat	(revision change prelim draft formal)	prelim	Author can stipulate what form the manual is in.
verstatpg	(ver unver)	unver	Author can stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file for verification status for more detail.
index	NUMBER	0	
security	(u c s n)	n	Identifies security level of the document
controlno	CDATA	00000000	System generated attribute values used included for compliance with the JCALS menu structure.
cycle	CDATA	new	System generated attribute values used included for compliance with the JCALS menu structure.
chglevel	NUMBER	#IMPLIED	System generated attribute values used included for compliance with the JCALS menu structure.
initlabel	NUMBER	#IMPLIED	System generated attribute values used included for compliance with the JCALS menu structure.
initpage	NUMBER	1	System generated attribute values used included for compliance with the JCALS menu structure.
docno	CDATA	#IMPLIED	System generated attribute values used included for compliance with the JCALS menu structure.
highguid	NUMBER	0	System generated attribute values used included for compliance with the JCALS menu structure.
labelstyle	CDATA	FAN	System generated attribute values used included for compliance with the JCALS menu structure.
HyTime	NAME	#FIXED "HyDoc"	Used to alert the processing system that this is a HyTime compliant document. This attribute is only required and/or effective with a HyTime aware processor.

docjg

Job Guide

Description: Defines the root element of the Job Guide manual

Source paragraph: MIL-DTL-83495C 3.4

Content Model: (front, (body | jgindex)) +(pgbrk | brk | subjinfo | line | modreq | location)

Parents: doc

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
chapstart	NUMBER	#IMPLIED	Author enters the chapter number if it beginning of the manual doesn't start at 1.
funcstart	NUMBER	#IMPLIED	Allows you to start a function number in a continued chapter, use with chapcontstart.
parastart	NUMBER	#IMPLIED	Allows you to start a para0 number in a continued gchapter, use with gchapcontstart.
pagesize	(5x8 8.5x11)	5x8	Author enters page size of the manual .
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

doctype

Type of Manual

Description: Identifies the type of manual on the title page (e.g. maintenance instructions, illustrated parts breakdown, inspection manual, etc.).

Source paragraph: MIL-STD-38784A 4.1.7

Content Model: ((#PCDATA | change | tabmat | fnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: idinfo

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

downgrd

Downgrade Notice

Description: Identifies the classification downgrade notice on the title page.

Source paragraph: MIL-STD-38784A 4.4

Content Model: ([phrase](#) | [oadr](#))

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

ecpno

Engineering Change Proposal Number

Description: Identifies the ECP Number in the record of applicable technical directives.

Source paragraph: MIL-STD-38784A 4.5.9.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

effdatenot

Effective Date Notice

Description: Identifies the effective date notice on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.8

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chginsst](#), [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

emphasis

Emphasis

Description: Identifies portions of text to be highlighted (e.g. underline, bold, etc.). This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺) -(figure | table | foldout | objmedia)

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chapttitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [fnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [sermo](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
type	(u b b u i b q q a x o sup sub ui)	#REQUIRED	Displays different types of emphasis. Set this attribute equal to "u" for underline, "b" for bold, "bu" for bold/underline, "i" for italics, "bi" for bold/italics, "q" for quotes, "qa" for quote alternate (currently unsupported), "x" for box, "o" for overscore, "sup" for superscript, "sub" for subscript, and "ui" for underline/italics.
fontsize	NUTOKEN	#IMPLIED	Allows author to set the font size which will be applied to the text within the emphasis tags.
color	(black white red orange yellow green blue violet brown gray)	#IMPLIED	Specifies the color of the text.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

entry

Table Entry

Description: Identifies a table entry (cell).

Source paragraph: MIL-STD-38784A 4.2.7

Content Model: (((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+ | [randlist](#) | [deflist](#) | [seqlist](#) | [warning](#) | [caution](#) | [note](#))+)

Parents: [row](#)

Entities used in this element: [chgatt](#), [delstat](#), [entry](#), [entryatt](#), [list](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
colname	NMTOKEN	#IMPLIED	Allows you to identify a name for each column.
spanname	NMTOKEN	#IMPLIED	Allows you to identify a name for each span.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
morerows	NUMBER	0	Allows you to define a vertical span on entries within a table.
colsep	NUMBER	#IMPLIED	Toggle switch to determine if column separators appear in a table. Colsep=1 means column separators will appear.
rowsep	NUMBER	#IMPLIED	Toggle switch to determine if row separators appear in a table. rowsep=1 means column separators will appear.

Attribute	Type	Default	Description
rotate	NUMBER	0	Toggle switch to rotate the contents of the entry 90 degrees.
valign	(top middle bottom)	#IMPLIED	Defines the vertical alignment of text within a cell.
align	(left right center justify char)	#IMPLIED	Defines the horizontal alignment of text within a cell.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	
security	(u c s n)	n	Identifies security level of the document

entrytbl

Entry Table

Description: Identifies a table within a table entry. This element allows a table cell to be divided into a sub-table, with its own set of rows, columns, and entries. Use of this element basically allows the author to create a table within a table.

Source paragraph: MIL-STD-38784A 4.2.7

Content Model: (colspec*, spanspec*, thead?, tbody) -(entrytbl)

Parents: row

Excluded in: entrytbl, tfoot, thead

Entities used in this element: chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
cols	NUMBER	#REQUIRED	Allows you to define the number of columns.
colname	NMTOKEN	#IMPLIED	Allows you to identify a name for each column.
spanname	NMTOKEN	#IMPLIED	Allows you to define a name for each span that is defined for the table.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators.
align	(left right center justify char)	#IMPLIED	Allows the author to align text within the cell.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column.
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

esds

Electrostatic Discharge Sensitive Symbol

<i>Description:</i>	Identifies the ESDS symbol. Use of this element will cause the ESDS symbol to appear at that point in the running text. The esds attribute should be used to place the ESDS symbol between a paragraph/step number and text.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3.10.4
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	abbrtitle , activity , address , applicabil , apptitle , authnot , cage , change , chap , chapno , chaptitle , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , faultcode , ftnote , func , functitle , hazmat , ilink , insertpg , internatlst , item , label , lepchg , leppage , line , maintlvl , mfr , mfrnad , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , persreq , phrase , pretmidno , prindex , pubdate , purpose , reference , remarks , removepg , revnum , secindex , seqno , serno , sigblock , spec , sssn , subject , subtitle , supersd , suppl , symtitle , system , tctono , term , tfnid , title , tmidno , tpdrlocation , tpdrno , typedes , typeno , underline , use , volnot , volnum
<i>Included in:</i>	step
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

expcont

Export Control Notice

<i>Description:</i>	Identifies the export control notice on the title page. Note that the export control notice entity (&expcontnot;) may be used in place of entering the text manually.
<i>Source paragraph:</i>	MIL-STD-38784A 4.5.1.12
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object +) +(underline)
<i>Parents:</i>	chginsst , idinfo
<i>Entities used in this element:</i>	text

extapplicabil

External Applicability

Description: Allows boxing of text for external referencing.

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([applicabil](#) | [extapplicabil](#) | [figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [ssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Excluded in: [extapplicabil](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
targetdoc	CDATA	#REQUIRED	
targetid	CDATA	#IMPLIED	
displayvalue	CDATA	#IMPLIED	
HyTime	NAME	#FIXED "clink"	
HyNames	NAMES	#FIXED "linkend xrefid"	
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

extref

External Reference

Description: Generates a reference to an external document.

Source paragraph: MIL-STD-38784A 4.3.1m

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chapttitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [premidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [sermo](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
targetdoc	CDATA	#REQUIRED	Identifies the external document that you are referencing. This value should equal an ID specified in the List of Related Publications. For implementing external references in digital data - this ID must equal the ID of the external document.
targetid	CDATA	#IMPLIED	Provides the ID for the element being referenced in the external document. The value of this attribute should equal the ID of an element in the referenced document.
displayvalue	CDATA	#IMPLIED	If the author needs to add additional, unique information for purposes of referencing an external document, this attribute should be tagged. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable.
HyTime	NAME	#FIXED "clink"	Used in combination with HyTime to establish contextual link.
HyNames	NAMES	#FIXED "linkend xrefid"	Used in combination with HyTime to establish contextual link.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

faultcode

Fault Code

Description: Defines the fault codes in the dot result

Source paragraph: MIL-DTL-83495C 3.4.3.2.1 a

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [result](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

fcf

Fracture Critical Parts

Description: Identifies the fracture critical parts.

Source paragraph: MIL-STD-38784A 4.3.8.5

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptitle](#), [chgdate](#), [chgunum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [ssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltpe	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

figure

Figure

Description: Identifies an illustration.

Source paragraph: MIL-STD-38784A 4.2.8

Content Model: (([title](#))?, (([subfig](#), [subfig](#)+) | (([graphic](#), [legend](#)?) | [tabmat](#))+)) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Included in: [chapter](#), [chaptercontinue](#), [foreword](#), [function](#), [gchapter](#), [gchaptercontinue](#), [safesum](#)

Excluded in: [abbrtitle](#), [acronym](#), [acronymlist](#), [applicabil](#), [apptitle](#), [caution](#), [change](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [ecpno](#), [emphasis](#), [extapplicabil](#), [figure](#), [foldout](#), [ftnote](#), [item](#), [modelno](#), [nomen](#), [note](#), [objmedia](#), [partno](#), [remarks](#), [serno](#), [symtitle](#), [tabdisplay](#), [table](#), [tabmat](#), [tctono](#), [term](#), [title](#), [tmidno](#), [typedes](#), [typeno](#), [underline](#), [warning](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [exclus](#), [fig](#), [figatts](#), [itemid](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgwide	NUMBER	1	Defines whether the figure will fill the entire width of the page.
orient	(port land)	port	Defines the orientation of the figure.
samepg	NUMBER	0	
place	(inline float)	float	
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltypes	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the document

foldout

Foldout

<i>Description:</i>	Identifies a foldout.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.4.1
<i>Content Model:</i>	((title)?, ((subfig , subfig +) ((graphic , legend ?) tabmat +))) -(figure table foldout objmedia)
<i>Included in:</i>	chapter , chaptercontinue , gchaptercontinue
<i>Excluded in:</i>	abbrtitle , acronym , acronymlist , applicabil , appltile , caution , change , dataiden , date , dateinc , def , ecpno , emphasis , extapplicabil , figure , foldout , fnote , item , modelno , nomen , note , objmedia , partno , remarks , serno , symtitle , tabdisplay , table , tabmat , tctono , term , title , tmidno , typesdes , typeno , underline , warning
<i>Entities used in this element:</i>	bodyatt , chgatt , content , db , delstat , exclus , fig , figatts , itemid , secur , status , verified , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgstyle	(11x17 11x20.5 11x24 11x27.5 11x31 11x34.5 11x38 11x41.5 11x45)	#IMPLIED	Defines the pagesize for the foldout.
blankapron	NUMBER	1	Toggle to indicate whether the foldout includes a blank apron. A value of 1. indicates that the foldout will have a blank apron.
pgwide	NUMBER	1	Defines whether the figure will fill the entire width of the page.
orient	(port land)	port	Defines the orientation of the figure.
samepg	NUMBER	0	
place	(inline float)	float	
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	

foldouts

Foldouts

Description: Foldouts
Source paragraph: None
Content Model: ([jgfoldoutwba+](#) | [jgfoldoutnoba+](#))+
Included in: [function](#), [gchapter](#)
Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

followon

Followon Maintenance

Description: Defines instructions on returning equipment to the required condition.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.2.2

Content Model: (para+ | none | notapp)

Parents: function, task

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
paging	(fold illus)	illus	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

foreword

Foreword

Description: Identifies the foreword of the manual. This element is identical to the preface and introduction elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: MIL-STD-38784A 4.5.9

Content Model: (para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc | tmimprep)*) +(figure | table)

Parents: front

Entities used in this element: [chgatt](#), [delstat](#), [fpi](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

front

Front Matter

Description: Identifies the front matter of the manual.

Source paragraph: MIL-STD-38784A 4.5

Content Model: ([idinfo](#), [warnpage?](#), [chginsst?](#), [lep](#), [verstat?](#), [tpdr?](#), [chgrec?](#), [toc?](#), [foreword?](#), [safesum?](#)) +([ftnote](#))

Parents: [docjg](#)

Entities used in this element: [frnt](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
t2page	NUMBER	0	A toggle that allows the author to turn the second title page on if necessary.
numcols	(1 2)	#REQUIRED	Allows the author to define the page format as one or two columns for this section of the manual.

ftnote

Footnote

Description: Identifies footnotes to paragraphs and tables. The footnote appears on the same page that the corresponding footnote reference (<ftnref>) occurs. Only the footnote whose id matches the xrefid specified in the footnote reference will appear. Footnotes to text will be displayed at the bottom of the page where the footnote is referenced

Source paragraph: MIL-STD-38784A 4.3.1n, 4.2.2

Content Model: (([#PCDATA](#) | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#)) + ([randlist](#) | [deflist](#) | [seqlist](#)) + -([ftnote](#) | [ftnref](#) | [figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Included in: [body](#), [front](#)

Excluded in: [ftnote](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [list](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#REQUIRED	This allows you to identify each element and later reference it by its id value.
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

ftnref

Footnote Reference

<i>Description:</i>	Identifies a reference to a footnote. This element will cause the footnote number/letter/symbol to appear at the point in the text where used, and will cause the footnote number/letter/symbol and the footnote text to appear at the bottom of the page.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3.1n
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	abbrtitle , activity , address , applicabil , apptitle , authnot , cage , change , chap , chapno , chaptitle , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , faultcode , ftnote , func , funcitle , hazmat , ilink , insertpg , internatlstd , item , label , lepchg , leppage , line , maintlvl , mfr , mfrnad , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , persreq , phrase , pretnidno , prindex , pubdate , purpose , reference , remarks , removepg , revnum , secindex , seqno , serno , sigblock , spec , sssn , subject , subtitle , supersed , suppl , symtitle , system , tctono , term , tfnid , title , tmidno , tpdrlocation , tpdrno , typedes , typeno , underline , use , volnot , volnum
<i>Excluded in:</i>	ftnote
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
mark	(num sym alpha)	num	Indicates the type of symbol or mark used to indicate a footnote.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

func

Function Title for Job Guide Index

Description: Defines the function title in the job guide index.

Source paragraph: MIL-DTL-83495C 3.4.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [jgindextab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

function

Function

Description: Identifies the function in each chapter

Source paragraph: MIL-DTL-83495C 3.4.3.2.1

Content Model: ([title](#), [incond](#), ([task](#), [followon?](#))⁺)⁺ ([warning](#) | [caution](#) | [note](#) | [figure](#) | [table](#) | [foldouts](#))

Parents: [chapter](#), [chaptercontinue](#), [gchapter](#), [gchaptercontinue](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [para0att](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	
id	ID	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".

Attribute	Type	Default	Description
hci	NUMBER	0	
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.
security	(u c s n)	n	
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assotab	IDREFS	#IMPLIED	

funcntitle

Function Title

<i>Description:</i>	Defines the function title in the addcontents element.
<i>Source paragraph:</i>	MIL-DTL-83495C 3.4.3.1.1
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hpc hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+)
<i>Parents:</i>	addcontents
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	
sssn	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

gchapter

General Chapter

Description: Defines the optional first chapter of the job guide.

Source paragraph: MIL-DTL-83495C 3.4.3.2

Content Model: (title, para0+, function*) +(warning | caution | note | figure | table | foldouts)

Parents: body

Entities used in this element: bodyatt, chapatt, chgatt, content, db, delstat, itemid, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	
security	(u c s n)	n	
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

gchaptercontinue

General Chapter Continue

Description: Identifies a general chapter that is continued in a new volume.

Source paragraph:

Content Model: (para0*, function*) +(figure | table | foldout | objmedia)

Parents: body

Entities used in this element: bodyatt, chapatt, chgatt, content, db, delstat, inclus, itemid, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
gchapcontstart	NUMBER	#IMPLIED	Value used to start a continued chapter in a new volume.
lastpagenum	NUMBER	#IMPLIED	Allows you to continue the correct page number onto a new book/ volume.
id	ID	#IMPLIED	
security	(u c s n)	n	
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

graphic

Graphic

Description: Identifies a graphic within a figure, or a graphic within running text or tables. If used within running text, no figure number or title will be generated. Note that the HCP and ESDS symbols can be placed in running text by using the hcp and esds elements. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: (bindByld | bindByName | bindByCoords)*

Parents: abbrtitle, activity, address, applicabil, appltile, authnot, cage, change, chap, chapno, chaptile, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, faultcode, figure, foldout, ftnote, func, functile, hazmat, icon, ilink, insertpg, internatlstd, item, jgfoldoutnoba, jgfoldoutwba, label, lepchg, leppage, line, maintlvl, mfr, mfrnad, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, persreq, phrase, pretmidno, prindex, pubdate, purpose, reference, remarks, removepg, revnum, secindex, seqno, serno, sigblock, spec, sssn, subfig, subject, subtitle, supersed, suppl, symtitle, system, tctono, term, tfnid, title, tmidno, tpdrllocation, tpdarno, typedes, typeno, underline, use, volnot, volnum

Entities used in this element: chgatt, delstat, graphatt, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	
boardno	ENTITY	#REQUIRED	Allows the author to place the graphic name here.
graphsty	NMTOKEN	#IMPLIED	Graphic style
llcordra	CDATA	#IMPLIED	Lower left world coordinates (1,1). If scalefit=0 and reprowid is not specified default is lower left.
rucordra	CDATA	#IMPLIED	Upper right world coordinates (10000,10000). If scalefit=0 and reprodep is not specified default is upper right.
reprowid	NUTOKEN	#IMPLIED	Specifies the horizontal dimension of a graphic bounding box (width).
reprodep	NUTOKEN	#IMPLIED	Specifies the vertical dimension of a graphic bounding box (depth).
hscale	NUMBER	#IMPLIED	Horizontal Scaling
vscale	NUMBER	#IMPLIED	
scalefit	NUMBER	#IMPLIED	Scale to fit. No affect if hscale and vscale set to zero.
hplace	(left right center)	#IMPLIED	
vplace	(top middle bottom)	#IMPLIED	
coordst	CDATA	#IMPLIED	Specifies coordinate to start graphic.
coordend	CDATA	#IMPLIED	Specifies coordinate to end graphic.
color	NUMBER	0	Option to choose color.
icon	(yes no)	no	Specifies whether the graphic is full size or icon. Specifying icon will eliminate the textbrk surrounding the graphic.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	
security	(u c s n)	n	Identifies security level of the document

hazmat

Hazardous Material Name

Description: Identifies the hazardous material name used with a hazardous material warning icon.

Source paragraph: MIL-STD-38784A 4.3.10.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [icon](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

hci

Hardness Critical Item

<i>Description:</i>	Identifies the HCI symbol. Use of this element will cause the HCI symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCI symbol in a paragraph. The hci attribute should be used to place the HCI symbol between a paragraph/step number and text.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3.8.3.1 (MIL-STD 38784A DRAFT)
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	abbrtitle , activity , address , applicabil , applttitle , authnot , cage , change , chap , chapno , chaptitle , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , faultcode , ftnote , func , functitle , hazmat , ilink , insertpg , internatlst , item , label , lepchg , leppage , line , maintlvl , mfr , mfrnad , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , persreq , phrase , pretmidno , prindex , pubdate , purpose , reference , remarks , removepg , revnum , secindex , seqno , serno , sigblock , spec , sssn , subject , subtitle , supersed , suppl , symtitle , system , tctono , term , tfid , title , tmidno , tpdrlocation , tpdrno , typedes , typeno , underline , use , volnot , volnum
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

hcp

Hardness Critical Process Symbol

<i>Description:</i>	Identifies the HCP symbol. Use of this element will cause the HCP symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCP symbol in a paragraph. The hcp attribute should be used to place the HCP symbol between a paragraph/step number and text.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3.10.3.1
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	abbrtitle , activity , address , applicabil , applttitle , authnot , cage , change , chap , chapno , chaptitle , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , faultcode , ftnote , func , functitle , hazmat , ilink , insertpg , internatlst , item , label , lepchg , leppage , line , maintlvl , mfr , mfrnad , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , persreq , phrase , pretmidno , prindex , pubdate , purpose , reference , remarks , removepg , revnum , secindex , seqno , serno , sigblock , spec , sssn , subject , subtitle , supersed , suppl , symtitle , system , tctono , term , tfid , title , tmidno , tpdrlocation , tpdrno , typedes , typeno , underline , use , volnot , volnum
<i>Included in:</i>	step

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

icon

Hazardous Material Warning Icon

Description: Identifies the hazardous material warnings. The hazardous material warning consists of a graphic(s) (e.g fire icon, poison icon, etc.), the hazardous material name, and the sequence number which identifies the order in which the hazardous material warnings are included in the safety summary. See Appendix A for further information on hazardous material warnings.

Source paragraph: MIL-STD-38784A 4.3.10.1

Content Model: ([graphic+](#), [hazmat+](#), [seqno](#))

Parents: [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [icon](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

idinfo

Identification Information (Title Page)

Description: Identifies the title page and cover (if used) of the manual.

Source paragraph: MIL-STD-38784A 4.5.1

Content Model: (tmidno+, (chgnum, chgdate)?, chghistory, pretmidno*, volnum?, revnum?, doctype, maintlvl?, prttitle, subtitle?, (mfr+, contractno+)?, seal?, superseded?, suppl*, effdatenot?, volnot?, discl?, distrib, expcont?, destr?, copyright*, cogact?, moveddata?, authnot, downgrd?, pubdate)

Parents: front

Entities used in this element: idinf

ilink

Independet Link

Description: One of several HyTime elements. Used in a situation of indirection where a specific ID is not declared in an external document and must be declared using nameloc and nmlist elements.

Source paragraph:

Content Model: ((#PCDATA | change | tabmat | fnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: abbrtitle, activity, address, applicabil, apptitle, authnot, cage, change, chap, chapno, chaptitle, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, faultcode, ftnote, func, functitle, hazmat, ilink, insertpg, internatlst, item, label, lepchg, leppage, line, maintlvl, mfr, mfrnad, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, persreq, phrase, pretmidno, prindex, pubdate, purpose, reference, remarks, removepg, revnum, secindex, seqno, serno, sigblock, spec, ssn, subject, subtitle, superseded, suppl, symtitle, system, tctono, term, tfnid, title, tmidno, tpdrllocation, tpdno, typedes, typeno, underline, use, volnot, volnum

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
anchrole	CDATA	#REQUIRED	Defines the anchor role assumed by the independent link. Used in combination with HyTime.
linkends	IDREFS	#REQUIRED	References the linkends delcared within a nameloc element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

incond

Input Conditions

Description: Defines the input conditions in a function.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1

Content Model: (appl, reqcond, persreq, supeq, consum, safecond, clreq?, addata)

Parents: function

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	
sssn	CDATA	#IMPLIED	
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assotab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	
verrem	CDATA	#IMPLIED	
verstatus	(unver ver)	unver	

insertpg

Insert Page Column Entry

Description: Identifies an entry within the Insert Page column on the change instruction sheet.

Source paragraph: MIL-STD-38784A 4.7.3.10.2

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hpc](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [chglist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

internatlst

International Standardization Agreement Note

Description: Identifies the international standardization agreement note. The paragraph number and title, of this note will be automatically generated by the FOSI.

Source paragraph: MIL-STD-38784A 4.5.9.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [foreword](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

item

Item

Description: Identifies an item within a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: NONE

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [randlist](#), [seqlist](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

jgfoldoutnoba

Job Guide Foldout with no blank apron.

Description: Defines the foldout with no blank apron for a job guide

Source paragraph: The source paragraph is: 3.4.2.7

Content Model: ((*title*)?, ((*subfig*, *subfig*+) | ((*graphic*, *legend*?) | *tabmat*)+))

Parents: [foldouts](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [fig](#), [figatts](#), [itemid](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgstyle	(8x10 8x11 8x13.5 8x17 8x20.5 8x24 8x27.5 8x31 11x17 11x20.5 11x24 11x27.5 11x31 11x34.5 11x38 11x41.5 11x45)	#IMPLIED	Identifies available foldout pageset options.
pgwide	NUMBER	1	Specifies if the graphic fills the page or column. Set it equal to "0", it will fit in column.
orient	(port land)	port	Allows you to specify the orientation of the graphic and/or table. Options are portrait and landscape.
samepg	NUMBER	0	
place	(inline float)	float	How to place graphic
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	

jgfoldoutwba

Job Guide Foldout with a blank apron.

Description: Defines the foldout with a blank apron for a job guide

Source paragraph: MIL-DTL-83495C 3.4.2.7

Content Model: (([title](#))?, (([subfig](#), [subfig](#)+) | (([graphic](#), [legend](#)?) | [tabmat](#))+))

Parents: [foldouts](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [fig](#), [figatts](#), [itemid](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgstyle	(8x10 8x11 8x13.5 8x17 8x20.5 8x24 8x27.5 8x31 11x17 11x20.5 11x24 11x27.5 11x31 11x34.5 11x38 11x41.5 11x45)	#IMPLIED	Identifies available foldout pageset options.
pgwide	NUMBER	1	Specifies if the graphic fills the page or column. Set it equal to "0", it will fit in column.
orient	(port land)	port	Allows you to specify the orientation of the graphic and/or table. Options are portrait and landscape.
samepg	NUMBER	0	
place	(inline float)	float	How to place graphic
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assocstab	IDREFS	#IMPLIED	
security	(u c s n)	n	
pagebreak	(recto verso next off rectobb versobb)	off	

jgindex

Job Guide Index

Description: Defines the job guide index.
Source paragraph: MIL-DTL-83495C 3.4.4
Content Model: ([jgindextab](#))
Parents: [docjg](#)
Entities used in this element: [chgatt](#), [delstat](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	
verrem	CDATA	#IMPLIED	
verstatus	(unver ver)	unver	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

jgindextab

Job Guide Index Table

Description: Defines the job guide index table.

Source paragraph: MIL-DTL-83495C 3.4.4

Content Model: (system, tmidno?, chapno?, (chap | func)+)

Parents: [jgindex](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [secur](#), [status](#), [tabatts](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
tabstyle	NMTOKEN	#IMPLIED	
frame	(top bottom topbot all sides none)	all	
colsep	NUMBER	1	
rowsep	NUMBER	0	
orient	(port land1)	port	
pgwide	NUMBER	1	
cellcont	(Continued Cont)	Continued	
id	ID	#IMPLIED	
footnotes	(page end)	#IMPLIED	
leftind	CDATA	#IMPLIED	
rightind	CDATA	#IMPLIED	
leftmar	NUTOKEN	#IMPLIED	
rightmar	NUTOKEN	#IMPLIED	
topmar	NUTOKEN	#IMPLIED	
botmar	NUTOKEN	#IMPLIED	
mindepth	NUTOKEN	#IMPLIED	
pgdeep	NUMBER	0	
applicref	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	
verrem	CDATA	#IMPLIED	
verstatus	(unver ver)	unver	
label	CDATA	#IMPLIED	
sssn	CDATA	#IMPLIED	
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	

label

Description:

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [cntentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

legend

Legend

Description: A tabular listing of the index numbers/letters and their meanings.

Source paragraph: MIL-STD-38784A 4.6.17

Content Model: ([tabmat](#))

Parents: [figure](#), [foldout](#), [jgfoldoutnoba](#), [jgfoldoutwba](#), [subfig](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

lep

List of Effective Pages (LEP)

Description: Identifies the list of effective pages for the manual.

Source paragraph: MIL-STD-38784A 4.5.3

Content Model: ([lepcontents](#)) -([note](#))

Parents: [front](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
lepcount	NUMBER	0	

lepchg

LEP Change

Description:

Source paragraph: MIL-STD-38784A 4.5.3.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [lepentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

lepcontents

LEP Contents

Description: Contains the entries for the lep. The fosi automatically can generate this.

Source paragraph: MIL-STD-38784A 4.5.3

Content Model: ([lepentry+](#))

Parents: [lep](#)

Entities used in this element: [lepcontents](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	CDATA	#CONREF	This attribute should be set equal to 1. when the acronymlist is autogenerated.

lepentry

LEP Entry

Description:

Source paragraph: MIL-STD-38784A 4.5.3

Content Model: ([leppage](#), [lepchg](#))

Parents: [lepcontents](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

leppage

LEP Page

Description:

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [leprent](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

line

Line

Description: This element is used to indicate that a column or line should be forced at that point.

Source paragraph: N/A

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Included in: [doc](#), [docjg](#)

Entities used in this element: [chgatt](#), [delstat](#), [lineatt](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
prespace	CDATA	#IMPLIED	Allows the author to set amount of space before/above the line used.
postspace	CDATA	#IMPLIED	Allows the author to set amount of space before/above the line used
quad	(left center right justify)	left	Specifies quadding option for the line.
indent	CDATA	#IMPLIED	Specifies how much indentation is set on the line.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

location

Description:

Source paragraph:

Content Model: EMPTY

Included in: [doc](#), [docjg](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	
deltypes	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

lrp

List of Related Publications

Description: Identifies the paragraph used to list related publications and the associated list.

Source paragraph: MIL-STD-38784A 4.5.9.2

Content Model: ((([title](#))?, ([warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*, [subpara1](#)*)?, [lrptable](#)?)

Parents: [foreword](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [lrp](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
ltermwidth	NUTOKEN	1.63in	Allows you to define the left term width.
rtermwidth	NUTOKEN	1.9in	Allows you to set the right term width.
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

Irprentry

List of Related Publications Entry

Description: Identifies an entry in the list of related publications. When the value of the id attribute is specified via the xrefid attribute of the extref element, the title of the publication appears.

Source paragraph: MIL-STD-38784A 4.5.9.2

Content Model: (([partno](#) | ([modelno](#) | [typedes](#)))*[, tmidno](#)+, [title](#))

Parents: [lrptable](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

Irptable

List of Related Publications Table

Description: Container element for the list of related publications table.

Source paragraph: MIL-STD-38784A 4.5.9.2

Content Model: ([lrprentry](#)*)

Parents: [lrp](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the element.

maintlvl

Maintenance Level

Description: Identifies the maintenance level of the manual (e.g. organizational, intermediate, depot, etc.) on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.3.3

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hpc](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mfr

Manufacturer

Description: Identifies the manufacturer of the equipment on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.3.6

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mfrnad

Manufacturer's name and address

Description: Defines manufacturer's name and address in the consumable table

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.5

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [consumtab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

modelno

Model Number

Description: Identifies the model number of the equipment on the title page or difference data sheet.

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [lrpentry](#), [prtitle](#)

Entities used in this element: [exclus](#), [secur](#), [text](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document

modreq

Description:

Source paragraph:

Content Model: ([mrinfo?](#), [mrmod](#), [mrrespsn?](#))

Included in: [doc](#), [docjg](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	
xref	NMTOKEN	#IMPLIED	
refpos	(prexref postxref xref)	xref	
by	CDATA	#REQUIRED	
date	CDATA	#REQUIRED	
organiz	NMTOKEN	#IMPLIED	
orgcat	NMTOKEN	#IMPLIED	
cmntrcat	NMTOKEN	#IMPLIED	
priority	(1 2 3 4 5)	#IMPLIED	
category	NMTOKEN	#IMPLIED	
topic	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

moveddata

Moved Data

Description: Provides a means to identify the type of information that will appear on the T-2 page when the title page overflows.

Source paragraph: NONE

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrchgtxt

Description:

Source paragraph:

Content Model: ANY

Parents: [mrmod](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
chgloc	NUMBER	#IMPLIED	
chglen	NUMBER	#IMPLIED	
action	(insert delete replace)	replace	

mrngenmod

Description:

Source paragraph:

Content Model: ([mrpara](#) | [mrlist](#))⁺

Parents: [mrmod](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrinfo

Description:

Source paragraph:

Content Model: ANY

Parents: [modreq](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrinstr

Description:

Source paragraph:

Content Model: ([mrpara](#) | [mrlist](#))+

Parents: [mrmod](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mritem

Description:

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [mrlist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrlist

Description:

Source paragraph:

Content Model: ([mritem](#))⁺

Parents: [mrngenmod](#), [mrinstr](#), [mrreason](#), [mrrespns](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrmod

Description:

Source paragraph:

Content Model: (mrreason?, (mrngenmod|(mrinstr?, mrchgtxt)))

Parents: modreq

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrpara

Description:

Source paragraph:

Content Model: ((#PCDATA | change | tabmat | ftref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: mrngenmod, mrinstr, mrreason, mrrespns

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrreason

Description:

Source paragraph:

Content Model: ([mrpara](#) | [mrlist](#))+

Parents: [mrmod](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

mrrespns

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph:

Content Model: ([mrpara](#) | [mrlist](#))*

Parents: [modreq](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
disposn	NMTOKEN	#IMPLIED	Attribute currently not supported by the FOSI. The element and attribute are under review.
status	NMTOKEN	#IMPLIED	Attribute currently not supported by the FOSI. The element and attribute are under review.

nameloc

Name Location - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a locator for external references and contains several nmlist elements. Useful for referncing objects that do not have the traditional SGML id.

Source paragraph:

Content Model: (nmlist)*

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [appltite](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptite](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [fnote](#), [func](#), [functite](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersd](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
HyBase	NAME	#FIXED nameloc	Assigns nameloc as the HyBase attribute.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

nmlist

Name List - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a description of the location of the entity or element reference in the nameloc element. Useful for referncing objects that do not have the traditional SGML id and/or entities that reside in external documents.

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [nameloc](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
HyBase	NAME	#FIXED nmsploc	Used in conjunction with HyTime to set up independent and contextual links.
impsrc	NAME	#FIXED grovert	Used in conjunction with HyTime to set up independent and contextual links.
HyBnames	CDATA	#FIXED "locsrc docorsub namespc nametype #MAPTOKEN elements element #MAPTOKEN entities entity"	Used in conjunction with HyTime to set up independent and contextual links.
nametype	(entity element)	entity	Identifies whether the external reference is an element or entity.
docorsub	ENTITY	#IMPLIED	Defines the entity name of the external document as declared in the entity declarations at the top of the tagged instance. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement.
notspace	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
notname	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
notprop	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
direct	(direct indirect)	indirect	Used in conjunction with HyTime to set up independent and contextual links.
locsrc	CDATA	#IMPLIED	Used in conjunction with HyTime to set up independent and contextual links.
cantcst	NAME	ERROR	Used in conjunction with HyTime to set up independent and contextual links.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

nomen

Nomenclature

Description: Identifies the nomenclature of the equipment on the title page and the difference data sheet.

Source paragraph: MIL-STD-38784A 4.5.1.3.4 & 4.7.3.3.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#)+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [consumtab](#), [prtitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

none

None

Description: Allows you to opt for none instead of having the tpdrtbl.

Source paragraph:

Content Model: EMPTY

Parents: [addata](#), [clreq](#), [consum](#), [followon](#), [reqcond](#), [supeqp](#), [tpdr](#)

Included in: [safecond](#)

notapp

Not Applicable

Description: Allows you to opt for "not applicable".

Source paragraph:

Content Model: EMPTY

Parents: [addata](#), [clreq](#), [consum](#), [followon](#), [persreq](#), [reqcond](#), [supeqp](#)

Included in: [safecond](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

note

Note

Description: Identifies a NOTE in the manual.

Source paragraph: MIL-STD-38784A 4.3.10

Content Model: (para*) -(randlist | deflist | seqlist | figure | table | foldout | objmedia | warning | caution)

Parents: abbrsect, applicdef, entry, lrp, para0, ratddesc, safecond, step, step, step1, step1, step2, step2, step3, step3, step4, step4, subpara1, subpara2, subpara2, subpara3, subpara3, subpara4, subpara4, subpara5, subpara5, subpara6, subpara6, subpara7, subpara7, subpara8, subpara8, symsect, tclist, tmimprep

Included in: doc, function, gchapter, para0

Excluded in: contents, lep, title

Entities used in this element: chgatt, delstat, exclus, list, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

nsn

National Stock Number

Description: Identifies the national stock number of the equipment on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.3.4

Content Model: ((#PCDATA | change | tabmat | fnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: prtitle

Entities used in this element: chgatt, delstat, status, text, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

nsp

Description: Identifies the nsp symbol. Use of this element will cause the nsp symbol to appear at that point in the running text. The nsp attribute should be used to place the nsp symbol between a paragraph/step number and text.

Source paragraph: MIL-STD-38784A 4.3.10.21

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [fnote](#), [func](#), [funcitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretnidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [ssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

oadr

Official Authority Downgrade Review Notice

Description: Identifies the official authority downgrade review notice on the title page. This notice is used only on classified manuals.

Source paragraph: MIL-STD-38784A 4.4 & 4.5.1.10

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [downgrd](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

object

Multimedia Object

Description: Developed for use in interactive manuals to evoke multimedia applications.

Source paragraph:

Content Model: (param*)

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [apptitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [funcitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [objmedia](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subobjmed](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
objectno	ENTITY	#REQUIRED	References the object number of the application being referenced.
reprowid	NUTOKEN	#IMPLIED	Provides width of object being invoked, especially if graphic or foldout from external document.
reprodep	NUTOKEN	#IMPLIED	Provides depth of object being invoked, especially if graphic or foldout from external document.
type	CDATA	#IMPLIED	Provides details about the type of applications being referenced.
security	(u c s n)	n	Identifies security level of the document
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

objmedia

Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph:

Content Model: (title, ((subobjmed, subobjmed+) | object)) -(figure | table | foldout | objmedia)

Included in: chapter, chaptercontinue, gchaptercontinue

Excluded in: abbrtitle, acronym, acronymlist, applicabil, appltitle, caution, change, dataiden, date, dateinc, def, ecpno, emphasis, extapplicabil, figure, foldout, fnote, item, modelno, nomen, note, objmedia, partno, remarks, serno, symtitle, tabdisplay, table, tabmat, tctono, term, title, tmidno, typedes, typeno, underline, warning

Entities used in this element: bodyatt, chgatt, content, db, delstat, exclus, itemid, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCL *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assocstab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the document

oci

Observable Critical Item

Description: Identifies the OCI symbol. Use of this element will cause the OCI symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the OCI symbol in a paragraph. The oci attribute should be used to place the OCI symbol between a paragraph/step number and text.

Source paragraph: MIL-STD-38784A 4.3.8.6.1 (MIL-STD 38784A DRAFT)

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [appltile](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptile](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

ocp

Observable Critical Process

<i>Description:</i>	Identifies the OCP symbol. Use of this element will cause the OCP symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the OCP symbol in a paragraph. The ocp attribute should be used to place the OCP symbol between a paragraph/step number and text.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3.8.6.1 (MIL-STD 38784A DRAFT)
<i>Content Model:</i>	EMPTY
<i>Parents:</i>	abbrtitle , activity , address , applicabil , applttitle , authnot , cage , change , chap , chapno , chaptitle , chgdate , chgnum , chgpara , chgtxt , clink , cogact , contractno , copyright , dataiden , date , dateinc , def , destr , discl , distrib , doctype , ecpno , effdatenot , emphasis , entry , expcont , extapplicabil , faultcode , ftnote , func , functitle , hazmat , ilink , insertpg , internatlst , item , label , lepchg , leppage , line , maintlvl , mfr , mfrnad , modelno , moveddata , mritem , mrpara , nmlist , nomen , nsn , oadr , pageno , para , param , partno , persreq , phrase , pretmidno , prindex , pubdate , purpose , reference , remarks , removepg , revnum , secindex , seqno , serno , sigblock , spec , ssn , subject , subtitle , supersed , suppl , symtitle , system , tctono , term , tfid , title , tmidno , tpdrlocation , tpdrno , typedes , typeno , underline , use , volnot , volnum
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

pageno

Page Number

<i>Description:</i>	Identifies the page number associated with each table/figure that appears in the tablelist or illuslist when the list is manually tagged.
<i>Source paragraph:</i>	NONE
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+)
<i>Parents:</i>	cntentry
<i>Entities used in this element:</i>	chgatt , delstat , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

para

Paragraph

<i>Description:</i>	Identifies text within a paragraph without regard to title, heading, etc. For example, a NOTE consists of a heading and one or more paragraphs.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.9.5
<i>Content Model:</i>	(((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+ randlist deflist seqlist)+)
<i>Parents:</i>	abbrsect , addata , appl , applicdef , caution , clreq , followon , lrp , note , para0 , persreq , ratddesc , reqcond , result , safecond , specinst , step , step1 , step2 , step3 , step4 , subpara1 , subpara2 , subpara3 , subpara4 , subpara5 , subpara6 , subpara7 , subpara8 , supeqp , symsect , tctolist , tmimprep , warning , wpgentry
<i>Entities used in this element:</i>	chgatt , delstat , list , paracon , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
xrefid	IDREF	#IMPLIED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

para0

Primary Paragraph

<i>Description:</i>	Identifies a primary paragraph within the manual.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.9.5.1.1

Content Model: ((title)?, (warning | caution | note | para | step1)*, subpara1*) +(note)

Parents: foreword, foreword, gchapter, gchaptercontinue, safesum

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, para0att, parazero, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

param

Parameter

Description: Used with Object Media to provide textual information about the application being invoked.

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [object](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

partno

Part Number

Description: Identifies the part number of the equipment on the title page and on the difference data sheet.

Source paragraph: MIL-STD-38784A 4.5.1.3.4 & 4.7.3.3.1b

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [consumtab](#), [lrpentry](#), [prttitle](#), [pslist](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

persreq

Personnel Recommended

Description: Defines the minimum number of personnel required to effectively perform the maintenance.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.3

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺ | [para](#) | [notapp](#))⁺

Parents: [incond](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [status](#), [text](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
bullet	NUMBER	0	Allows the user to choose whether bullets should be displayed in the required conditions or not.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

pgbrk

Page Break

Description: Identifies where a page will begin. Page breaks can be placed at the top of each logical page to identify where the page should start.

Source paragraph: MIL-STD-38784A 4.2.1.1

Content Model: EMPTY

Included in: doc, docjg

Entities used in this element: status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
pgnum	CDATA	#IMPLIED	Page number generated by the FOSI during a recomposition. Provides data for OmniMark and DataLogics Composer in the script and change package processing.
pgnumber	CDATA	#IMPLIED	Allows the author to assign the pgnumber.
pgdesc	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
nxtpgnum	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
nxtpgdesc	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
seqnum	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
prefix	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
paraflag	NUMBER	0	Toggle wheter or not last para will split.
hyphflag	NUMBER	#IMPLIED	Toggle whether or not hyphen will be used fo rthe last word on the last line.
shrink	NUMBER	100	Used to shrink vertical space so that overflowed text will pull back to the desired page.
rectover	NUMBER	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
chglevel	CDATA	#IMPLIED	Specifies what level of change the manual is on.
security	CDATA	#IMPLIED	Identifies security level of the document
empty	NUMBER	0	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
ignore	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
chgstatus	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
prevchgstatus	CDATA	#IMPLIED	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
emergency	(0 1)	#IMPLIED	If emergency is equal to 1, it will output the emergency border to signify emergency procedures.
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.

phrase

Downgrade Phrase

Description: Identifies the text of the downgrade notice on the title page.

Source paragraph: MIL-STD-38784A 4.4

Content Model: ((#PCDATA | change | tabmat | ftref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Parents: downgrd

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

pretmidno

Description:

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [service](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD FRN)	#IMPLIED	
security	(u c s n)	n	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

prindex

Primary Index

Description: Identifies a primary alphabetical index topic in the manual.

Source paragraph: MIL-STD-38784A 4.2.9.8

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺) -(prindex)

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [appltite](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptite](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functite](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Excluded in: [prindex](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
pridnbr	CDATA	#IMPLIED	Defines a unique identification number that allows an association between items tagged as primary index topics and those tagged as secondary index topics.
display	NUMBER	1	
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

prtitle

Prime Title

Description: Identifies the title of the manual on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.3e

Content Model: (([nomen](#), ([modelno](#) | [partno](#) | [typedes](#) | [pslist](#) | [nsn](#))⁺, [serno](#)*) | [subject](#))

Parents: [chginsst](#), [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

pslist

Part/Serial Number List

Description: Identifies a listing on the title page that corresponds a particular part number with associated serial numbers. This element could also be used to correspond model numbers with serial numbers, etc.

Source paragraph: MIL-STD-38784A 4.5.1.3.4

Content Model: ([partno](#), [serno](#))+

Parents: [prttitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

pubdate

Publication Date

Description: Identifies the basic date of the manual on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.16

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hpc](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

purpose

Purpose

Description: Identifies the purpose column in the reference table.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.8

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [refertab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

randlist

Random List

Description: Identifies a random list. All items within the random list will appear unnumbered, on separate lines, in the order they were entered by the author.

Source paragraph: NONE

Content Model: ([title](#)?, [item](#)*)

Parents: [entry](#), [fnote](#), [para](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
prefix	CDATA	#IMPLIED	If prefix is used, the bullets will not appear that are generally formatted by the fosi.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

ratd

Record of Applicable Technical Directives

Description: Identifies the record of applicable technical directives paragraph and the associated table.

Source paragraph: MIL-STD-38784A 4.5.9.4

Content Model: ([ratdentry](#)*)

Parents: [ratddesc](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assotab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the document

ratddesc

Record of Applicable Technical Directives Description

Description: Defines the description of the record of applicable technical directives paragraph and the associated table.

Source paragraph: MIL-STD-38784A 4.5.9.4

Content Model: ((([title](#))?, ([warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*, [subpara1](#))*, [ratd](#)?)

Parents: [foreword](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCl *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assocstab	IDREFS	#IMPLIED	

ratdentry

Record of Applicable Technical Directives Table Entry

Description: Defines each entry of the Record of Applicable Technical Directives Table.

Source paragraph: MIL-STD-38784A 4.5.9.4

Content Model: (typeno, date?, title, ecjno?, dateinc?, remarks?)

Parents: [ratd](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

reference

Reference

Description: Defines the reference column in the Consumable Table or the Reference Table

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.5

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [consumtab](#), [refertab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

refertab

Reference Table

Description: Defines the Reference Table

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.8

Content Model: ([reference](#), [purpose](#))⁺

Parents: [addata](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

remarks

Remarks Entry

Description: Identifies an entry in the remarks column of the record of applicable technical directives.

Source paragraph: MIL-STD-38784A 4.5.9.4e

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺ -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

removepg

Remove Page Column Entry

Description: Identifies an entry within the Remove Page column on the change instruction sheet.

Source paragraph: MIL-STD-38784A 4.7.3.10.2

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [chglist](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

reqcond

Required Conditions

Description: Defines the prerequisites for tasks.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.2

Content Model: (para+ | none | notapp)

Parents: incond

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
bullet	NUMBER	0	Allows the user to choose whether bullets should be displayed in the required conditions or not.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

result

Result

Description: Defines the result in a function.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1 a

Content Model: (para, faultcode*)

Parents: step, step1, step2, step3, step4

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
person	CDATA	#IMPLIED	

revnum

Revision Number

Description: Identifies the revision number of the manual on the title page.

Source paragraph: MIL-STD-38784A 4.8

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

row

Row

Description: Identifies a row in a table.

Source paragraph: MIL-STD-38784A 4.2.7

Content Model: ([entry](#) | [entrytbl](#))⁺

Parents: [tbody](#), [tfoot](#), [thead](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators.
valign	(top bottom middle)	#IMPLIED	Defines the vertical alignment for cell contents.
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

safecond

Safety Conditions

Description: Defines pertinent safety information to be included

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.6

Content Model: (([warning*](#), [caution?](#), [note?](#)) | [para](#))+ +(none | notapp)

Parents: [incond](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
bullet	NUMBER	0	Allows the user to choose whether bullets should be displayed in the required conditions or not.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

safesum

Safety Summary

Description: Identifies the safety summary of the manual. The title is automatically generated by the FOSI.

Source paragraph: MIL-STD-38784A 4.5.10

Content Model: (para0+) +(figure | table | warning | caution)

Parents: front

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, para0att, safesum, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCl *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

seal

Seal

Description: Department of the Navy Seal, with command identifier.

Source paragraph: MIL-STD-38784A 4.5.1.5

Content Model: EMPTY

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

secindex

Description:

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([secindex](#))

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chapttitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [ftnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [sermo](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Excluded in: [secindex](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
pridnbr	CDATA	#REQUIRED	
display	NUMBER	1	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

seqlist

Sequential List

Description: Identifies a sequential list. All items within the sequential list will appear numbered, on separate lines, in the order they were entered by the author.

Source paragraph: MIL-PRF-28001

Content Model: (title?, item+)

Parents: [entry](#), [ftnote](#), [para](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
numstyle	(alphauc alphalc arabic romanuc romanlc)	arabic	Defines the type of enumeration on the sequential list.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

seqno

Sequence Number

Description: Defines the sequence number for a hazard warning.

Source paragraph: MIL-STD-38784A 4.3.10.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [icon](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

serno

Serial Number

Description: Identifies serial numbers of the equipment on the title page and the difference data sheet.

Source paragraph: MIL-STD-38784A 4.5.1.3.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [prtitle](#), [pslist](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.

Attribute	Type	Default	Description
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

sigblock

Signature Block

Description: Provides signature block.

Source paragraph: MIL-STD 38784A DRAFT

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [chginsst](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

spanspec

Span Specification

Description: Used to join two or more columns in a table. Span specifications are similar to column specifications (<colspec>) except that they describe areas of the table that can be spanned (joined) using a table entry (<entry>). For example, a three-column table may have columns named 1, 2, and 3 respectively. A span named 23 may be declared using spanspec. When spanname=23 is used on an entry, that entry would occupy the space in both columns 2 and 3.

Source paragraph: MIL-PRF-28001 8.4.5.3

Content Model: EMPTY

Parents: [entrytbl](#), [tfoot](#), [tgroup](#), [thead](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
namest	NMTOKEN	#REQUIRED	The name of the first column of the set of columns that you want to span.
nameend	NMTOKEN	#REQUIRED	The name of the last column of the set of columns that you want to span.
spanname	NMTOKEN	#IMPLIED	Defines a unique name for the span.

Attribute	Type	Default	Description
align	(left right center justify char)	center	Allows the author to align text within the cell.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

spec

Specification/PN

Description: Defines the specification number or part number column in the Consumable Table

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.5

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [consumtab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

specinst

Special Instructions

Description: Defines the special instructions in the step.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.2.1 e

Content Model: (para)

Parents: [step](#), [step1](#), [step2](#), [step3](#), [step4](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
person	CDATA	#IMPLIED	

sssn

System/Subsystem/Subject Number

Description: Defines SSSN in the TOC and Job Guide Index.

Source paragraph: MIL-DTL-83495C 3.4.3.1.1 & 3.4.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hpc](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [contentsentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

step

Step

Description: Defines the steps in the task.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.2.1

Content Model: ((warning*, caution?, note?, para, specinst*, result*, note?)) +(hcp | esds)

Parents: task, tasksp

Entities used in this element: chgatt, content, db, delstat, itemid, status, stepatt, stepcon, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	If emergency is equal to "1", it will output the emergency border to signify emergency procedures.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
person	CDATA	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to "1".
fcp	NUMBER	0	Fracture Critical Process
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to "1".
hci	NUMBER	0	Hardness Critical Item
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
clitem	NUMBER	0	
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

step1

First Level Procedural Step

Description: Identifies a first level procedural step.

Source paragraph: MIL-STD-38784A 4.2.9.5.3

Content Model: ((warning*, caution?, note?, para, specinst*, result*, note?), (step2, step2+)?)

Parents: abbrsect, applicdef, lrp, para0, ratddesc, subpara1, subpara2, subpara3, subpara4, subpara5, subpara6, subpara7, subpara8, symsect, tctolist, tmimprep

Entities used in this element: chgatt, content, db, delstat, itemid, status, step1.mdl, stepatt, stepcon, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltypes	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
person	CDATA	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
clitem	NUMBER	0	
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

step2

Second Level Procedural Step

Description: Identifies a second level procedural step.

Source paragraph: MIL-STD-38784A 4.2.9.5.3

Content Model: ((warning*, caution?, note?, para, specinst*, result*, note?), (step3, step3+)?)

Parents: step1, step1

Entities used in this element: chgatt, content, db, delstat, itemid, status, step2.mdl, stepatt, stepcon, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
person	CDATA	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.. A **FCP** symbol will appear when set equal to 1.
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
clitem	NUMBER	0	
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

step3

Third Level Procedural Step

Description: Identifies a third level procedural step.

Source paragraph: MIL-STD-38784A 4.2.9.5.3

Content Model: ((warning*, caution?, note?, para, specinst*, result*, note?), (step4, step4+)?)

Parents: step2, step2

Entities used in this element: chgatt, content, db, delstat, itemid, status, step3.mdl, stepatt, stepcon, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
person	CDATA	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
clitem	NUMBER	0	
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

step4

Fourth Level Procedural Step

Description: Identifies a fourth level procedural step.

Source paragraph: MIL-STD-38784A 4.2.9.5.3

Content Model: ((warning*, caution?, note?, para, specinst*, result*, note?))

Parents: step3, step3

Entities used in this element: chgatt, content, db, delstat, itemid, status, stepatt, stepcon, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Used to generate a revision
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference to this element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
emergency	NUMBER	0	
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
person	CDATA	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness critical Processes. A **HCP** symbol will appear when set equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
clitem	NUMBER	0	
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subfig

Subfigure

Description: Identifies a subfigure. This element is used for multisheet illustrations, each sheet being a subfigure. The FOSI will automatically generate the sheet count (e.g Sheet 1 of 10, Sheet 2, etc.)

Source paragraph: MIL-STD-38784A 4.2.4.2

Content Model: ((([graphic](#), [legend?](#))) | [tabdisplay](#))

Parents: [figure](#), [figure](#), [foldout](#), [foldout](#), [jgfoldoutnoba](#), [jgfoldoutnoba](#), [jgfoldoutwba](#), [jgfoldoutwba](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [subfig](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
orient	(port land1)	port	Defines the orientation of the figure.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
applicref	IDREFS	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

subject

Subject

Description: Identifies the prime title of the manual on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.3.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [prtitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

subjinfo

Description:

Source paragraph:

Content Model: EMPTY

Included in: [doc](#), [docjg](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
subjup	CDATA	#REQUIRED	
subjlwr	CDATA	#REQUIRED	
infoup	CDATA	#REQUIRED	
infolwr	CDATA	#REQUIRED	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

subobjmed

Description:

Source paragraph:

Content Model: (object)

Parents: [objmedia](#), [objmedia](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	
label	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	
security	(u c s n)	n	

subpara1

First Subordinate Paragraph

Description: Identifies a first subordinate paragraph.

Source paragraph: MIL-STD-38784A 4.2.9.5.1.2

Content Model: (([title](#) | [warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*, [subpara2](#)*)

Parents: [abbrsect](#), [applicdef](#), [lrp](#), [para0](#), [ratddesc](#), [symsect](#), [tctolist](#), [tmimprep](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [nparcon](#), [para0att](#), [secur](#), [status](#), [sub1att](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subpara2

Second Subordinate Paragraph

Description: Identifies a second subordinate paragraph.

Source paragraph: MIL-STD-38784A 4.2.9.5.1.2

Content Model: (warning*, caution?, note?, (title)?, para, note?, step1*, subpara3*)

Parents: subpara1

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, nparcon1, para0att, secur, status, sub2att, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.

Attribute	Type	Default	Description
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subpara3

Third Subordinate Paragraph

Description: Identifies a third subordinate paragraph.

Source paragraph: MIL-STD-38784A 4.2.9.5.1.2

Content Model: (warning*, caution?, note?, (title)?, para, note?, step1*, subpara4*)

Parents: subpara2

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, nparcon1, para0att, secur, status, sub3att, subpara3.mdl, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subpara4

Fourth Subordinate Paragraph

Description: Identifies a third subordinate paragraph.

Source paragraph: MIL-STD-38784A 4.2.9.5.1.2

Content Model: (warning*, caution?, note?, (title)?, para, note?, step1*, subpara5*)

Parents: subpara3

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, nparcon1, para0att, secur, status, subatts, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCl *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
moretocspc	NUMBER	0	

subpara5

Fifth Subordinate Paragraph

Description: Identifies a fifth subordinate paragraph.

Source paragraph: MIL-STD-38784A 4.2.9.5.1.2

Content Model: (warning*, caution?, note?, (title)?,para, note?, step1*, subpara6*)

Parents: subpara4

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, nparcon1, para0att, secur, status, subatts, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subpara6

Six Subordinate Paragraph

Description: Identifies a six subordinate paragraph.

Source paragraph: MIL-STD-38784A 4.2.9.5.1.2

Content Model: (warning*, caution?, note?, (title)?, para, note?, step1*, subpara7*)

Parents: subpara5

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, nparcon1, para0att, secur, status, subatts, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.

Attribute	Type	Default	Description
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocf	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subpara7

Seventh Subordinate Paragraph

<i>Description:</i>	Identifies a seventh subordinate paragraph.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.9.5.1.2
<i>Content Model:</i>	(warning*, caution?, note?, (title)?, para, note?, step1*, subpara8*)
<i>Parents:</i>	subpara6

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [nparcon1](#), [para0att](#), [secur](#), [status](#), [subatts](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subpara8

Eighth Subordinate Paragraph

Description: Identifies a eighth subordinate paragraph.

Source paragraph: MIL-STD-38784A 4.2.9.5.1.2

Content Model: (warning*, caution?, note?, (title)?, para, note?, step1*)

Parents: subpara7

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, nparcon1, para0att, secur, status, subatts, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCl *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

subtitle

Subtitle

<i>Description:</i>	Identifies the subtitle of the manual on the title page.
<i>Source paragraph:</i>	MIL-STD-38784A 4.5.1.3.5
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object) ⁺)
<i>Parents:</i>	idinfo
<i>Entities used in this element:</i>	chgatt , delstat , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

supeqp

Support Equipment

<i>Description:</i>	Defines the government approved support equipment.
<i>Source paragraph:</i>	MIL-DTL-83495C 3.4.3.2.1.1.4
<i>Content Model:</i>	(para ⁺ none notapp)

Parents: [incond](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
bullet	NUMBER	0	Allows the user to choose whether bullets should be displayed in the required conditions or not.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.

superseded

Supersedure Notice

Description: Identifies the supersede notice on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.6

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hpc](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [idinfo](#)

Entities used in this element: [text](#)

suppl

Supplement Notice

Description: Identifies the supplement notice on the title page.

Source paragraph: MIL-STD-38784A 4.5.1.8

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

symrow

Description:

Source paragraph:

Content Model: ([term](#), [def](#))

Parents: [symsect](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

symsect

Symbol Paragraph

Description: Identifies the paragraph used to define symbols (e.g ESDS symbol) and the associated list.

Source paragraph: MIL-STD-38784A 4.5.9 & 4.3.4

Content Model: (((title)?, (warning | caution | note | para | step1)*, subpara1*)?, (symtitle?, (symrow+ | (term, def)+)))

Parents: foreword

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, para0att, parazero, secur, status, symsect, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
rtermwidth	NUTOKEN	2.75in	Allows you to set the right term width.
ltermwidth	NUTOKEN	0.75in	Allows you to define the left term width.
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type

Attribute	Type	Default	Description
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

symtitle

Symbol Paragraph

Description: Identifies the title used to define symbols (e.g ESDS symbol) and the associated list.

Source paragraph: MIL-STD-38784A 4.5.9 & 4.3.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [symsect](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

system

System

Description: Defines the systems in the job guide index

Source paragraph: MIL-DTL-83495C 3.4.4

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [jgindextab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

tabdisplay

Description:

Source paragraph:

Content Model: ([tgroup](#)⁺) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#)) ⁺([tfoot](#) | [tnref](#) | [tfndisplay](#))

Parents: [subfig](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
label	CDATA	#IMPLIED	
frame	(top bottom topbot all sides none)	all	
colsep	NUMBER	1	
rowsep	NUMBER	0	
tbwidth	NUTOKEN	#IMPLIED	
tbdepth	NUTOKEN	#IMPLIED	
horrefpt	(left right)	left	
verrefpt	(vtop vbottom)	vtop	
coordst	CDATA	0,10000	
assocfig	IDREF	#IMPLIED	
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	
security	(u c s n)	n	

table

Table

<i>Description:</i>	Identifies a table.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.7
<i>Content Model:</i>	(title , tgroup+) -(figure table foldout objmedia) +(tfnref tfoot tndisplay tfnid)
<i>Included in:</i>	chapter , chaptercontinue , foreword , function , gchapter , gchaptercontinue , safesum
<i>Excluded in:</i>	abbrtitle , acronym , acronymlist , applicabil , apptitle , caution , change , dataiden , date , dateinc , def , ecpno , emphasis , extapplicabil , figure , foldout , ftnote , item , modelno , nomen , note , objmedia , partno , remarks , serno , symtitle , tabdisplay , table , tabmat , tctono , term , title , tmidno , typedes , typeno , underline , warning
<i>Entities used in this element:</i>	bodyatt , chgatt , content , db , delstat , exclus , itemid , secur , status , tabatts , tabl , verified , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
tabstyle	NMTOKEN	#IMPLIED	
frame	(top bottom topbot all sides none)	all	
colsep	NUMBER	1	Toggle switch to indicate if column separators are used.
rowsep	NUMBER	0	Toggle switch to indicate if row separators are used.
orient	(port land1)	port	Defines orientation of table on the page. %verified;
pgwide	NUMBER	1	Specifies if table stretches across the entire page.
cellcont	(Continued Cont)	Continued	Specifies whether cell contents can be continued.
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
footnotes	(page end)	#IMPLIED	Allows you to specify whether table footnotes appear at the end of the table or at the end of the page.
leftind	CDATA	#IMPLIED	Specifies left indent of the table in relationship to the page.
rightind	CDATA	#IMPLIED	Specifies right indent of the table in relationship to the page.
leftmar	NUTOKEN	#IMPLIED	Specifies left margin of the table.
rightmar	NUTOKEN	#IMPLIED	Specifies left margin of the table.
topmar	NUTOKEN	#IMPLIED	Specifies left margin of the table.
botmar	NUTOKEN	#IMPLIED	Specifies left margin of the table.
mindepth	NUTOKEN	#IMPLIED	
pgdeep	NUMBER	0	Allows you to specify whether that table is equal to the depth of the page.
applicref	IDREFS	#IMPLIED	Specifies all IDs of elements or data items that have an applicable reference.
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the document
continued	NUMBER	0	

tabmat

Table Material

Description:

Source paragraph:

Content Model:

Parents:

MIL-STD-38784A 4.3.9

([tgroup+](#)) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

[abbrtitle](#), [activity](#), [address](#), [applicabil](#), [appltite](#), [authnot](#), [cage](#), [change](#), [chap](#), [chapno](#), [chaptite](#), [chgdate](#), [chglist](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [figure](#), [foldout](#), [fnote](#), [func](#), [functite](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlstd](#), [item](#), [jgfoldoutnoba](#), [jgfoldoutwba](#), [label](#), [legend](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtite](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [verstat](#), [volnot](#), [volnum](#)

Entities used in this element:

[bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [exclus](#), [itemid](#), [secur](#), [status](#), [tabatts](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
tabstyle	NMTOKEN	#IMPLIED	
frame	(top bottom topbot all sides none)	all	
colsep	NUMBER	1	
rowsep	NUMBER	0	
orient	(port land1)	port	
pgwide	NUMBER	1	
cellcont	(Continued Cont)	Continued	
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
footnotes	(page end)	#IMPLIED	
leftind	CDATA	#IMPLIED	
rightind	CDATA	#IMPLIED	
leftmar	NUTOKEN	#IMPLIED	
rightmar	NUTOKEN	#IMPLIED	
topmar	NUTOKEN	#IMPLIED	

Attribute	Type	Default	Description
botmar	NUTOKEN	#IMPLIED	
mindepth	NUTOKEN	#IMPLIED	
pgdeep	NUMBER	0	
applicref	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	
verrem	CDATA	#IMPLIED	
verstatus	(unver ver)	unver	
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assocfab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the element.

task

Task

Description: Defines the task in a function.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.2

Content Model: (title, step+, tasksp?, followon?)

Parents: function

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, para0att, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	
id	ID	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	
fcf	NUMBER	0	Fracture Critical Process

Attribute	Type	Default	Description
hcp	NUMBER	0	Hardness critical Processes. A HCP symbol will appear when set equal to "1".
hci	NUMBER	0	
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.
security	(u c s n)	n	
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

tasksp

Task on the same page

Description: Defines the occurrence of two tasks on the same page.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.2.1

Content Model: (title, step+)

Parents: task

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, para0att, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	
id	ID	#IMPLIED	
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage esds parts shall be identified by the esds symbol by setting attribute equal to "1".
nsp	NUMBER	0	
fcp	NUMBER	0	Fracture Critical Process

Attribute	Type	Default	Description
hcp	NUMBER	0	Hardness critical Processes. A HCP symbol will appear when set equal to "1".
hci	NUMBER	0	
ocp	NUMBER	0	Observable Critical Process
oci	NUMBER	0	Observable Critical Item
applicref	IDREFS	#IMPLIED	
verdate	CDATA	#IMPLIED	Identifies the date of verification.
verrem	CDATA	#IMPLIED	Identifies verification remarks.
verstatus	(unver ver)	unver	Identifies verification status.
security	(u c s n)	n	
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

tbody

Table Body

Description: Identifies the body of a table (e.g. material below the boxheads).

Source paragraph: MIL-STD-38784A 4.3.9

Content Model: (row+)

Parents: [entrytbl](#), [tgroup](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
valign	(top middle bottom)	top	Defines the veritical alignment of data within a cell of the table.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tctolist

Time Compliance Technical Orders Paragraph

Description: Identifies the time compliance technical orders paragraph and the associated table.

Source paragraph: MIL-STD-38784A 4.5.9.3

Content Model: (((*title*)?, (*warning* | *caution* | *note* | *para* | *step1*)*, *subpara1**)?, *tctotbl*?)

Parents: [foreword](#)

Entities used in this element: [bodyatt](#), [chgatt](#), [content](#), [db](#), [delstat](#), [itemid](#), [para0att](#), [parazero](#), [secur](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCl *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

tctono

Time Compliance Technical Order Number

Description: Identifies an entry in the TCTO Number column in the TCTO table.

Source paragraph: MIL-STD-38784A 4.5.9.3

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [tctorow](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

tctorow

Time Compliance Technical Orders Row

Description: Identifies a row in the time compliance technical orders table.

Source paragraph: MIL-STD-38784A 4.5.9.3

Content Model: (tctono, title, date)

Parents: tctotbl

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

tctotbl

Time Compliance Technical Order Table

Description: Identifies the table that lists all TCTOs applicable to the manual. The FOSI will automatically generate the table title and the column headings (boxheads).

Source paragraph: MIL-STD-38784A 4.5.9.3

Content Model: (tctorow+)

Parents: tctolist

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	

Attribute	Type	Default	Description
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the document

term

Term

<i>Description:</i>	Identifies an entry in the term portion of a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.
<i>Source paragraph:</i>	MIL-STD-38784A 4.3.4
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia)
<i>Parents:</i>	acronym , acronymlist , acronymrow , applic , applchd , defhd , deflist , symrow , symsect
<i>Entities used in this element:</i>	chgatt , delstat , exclus , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tfndisplay

Table Footnote Display

<i>Description:</i>	This element is for displaying footnotes in a 38784 table model. Footnotes to tables will be displayed at the end of the table. This element should be placed in a span in the last row of the table.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.7.5
<i>Content Model:</i>	EMPTY
<i>Included in:</i>	tabdisplay , table
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tfnid

Table Footnote Id

Description: This element is for placing a footnote in a 38784 table model. A superscript will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: MIL-STD-38784A 4.2.7.5

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [tfoot](#)

Included in: [table](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#REQUIRED	This allows you to identify each element and later reference it by its id value.
tfntype	(num alpha sym)	num	Defines the type of symbol used to indicate a table footnote.
tfnsymbol	CDATA	#IMPLIED	Allows you to define the actual symbol to serve as a table footnote reference.
tfnval	CDATA	#IMPLIED	Defines the text value of the reference. The actual data to be generated at the bottom of the table should be placed with this attribute.
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tfnref

Table Footnote Reference

Description: This element is for referencing a footnote in a 38784 table model that was created with a table footnote id. The superscript that was generated from the table footnote id will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: MIL-STD-38784A 4.2.7.5

Content Model: EMPTY

Included in: [tabdisplay](#), [table](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#REQUIRED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tfoot

Table Foot

Description: The foot of the table.

Source paragraph: MIL-STD-38784A 4.2.7.5

Content Model: (([colspec](#)*, [spanspec](#)*, [row](#)+) | [tfnid](#)+) -([entrytbl](#))

Parents: [tgroup](#)

Included in: [tabdisplay](#), [table](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	

Attribute	Type	Default	Description
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tggroup

Table Group

Description: Identifies a table group, which consists of a table heading (boxheads) and a table body.

Source paragraph: MIL-STD-38784A 4.2.7

Content Model: (colspec*, spanspec*, (thead?, tfoot?, tbody))

Parents: [tabdisplay](#), [table](#), [tabmat](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
cols	NUMBER	#REQUIRED	Defines the number of columns within the table.
colsep	NUMBER	#IMPLIED	Allows you to include a vertical line to separate columns. A value of 1. for this attribute will generate column separators.
rowsep	NUMBER	#IMPLIED	Allows you to include a horizontal line to separate rows. A value of 1. for this attribute will generate row separators.
align	(left right center justify char)	left	Allows the author to align text within the cell.
leftind	CDATA	#IMPLIED	Defines the left indent of text within the cell.
rightind	CDATA	#IMPLIED	Defines a right indent of the text within the cell.
leftmar	NUTOKEN	#IMPLIED	Defines the left margin of the cell.
rightmar	NUTOKEN	#IMPLIED	Defines the right margin of the cell.
topmar	NUTOKEN	#IMPLIED	Defines the top margin of the cell.
botmar	NUTOKEN	#IMPLIED	Defines the bottom margin of the cell.
mindepth	NUTOKEN	#IMPLIED	Defines the minimum depth of the table.
charoff	NUTOKEN	#IMPLIED	Determines the distance the cell content should offset from the horizontal alignment character.
char	CDATA	#IMPLIED	Defines the alignment character that can be used to align values within a column.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

thead

Table Heading (Boxheads)

<i>Description:</i>	Identifies a table heading (boxheads). The table heading (boxheads) repeat when the table breaks across a column or page.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.7.3
<i>Content Model:</i>	(colspec* , spanspec* , row+) -(entrytbl)
<i>Parents:</i>	entrytbl , tgroup
<i>Entities used in this element:</i>	chgatt , delstat , status , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
valign	(top middle bottom)	bottom	Defines the vertical alignment of text within a cell.
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

title

Title

<i>Description:</i>	Identifies a title (e.g. chapter, paragraph, table, etc.). The title should be tagged exactly as it is to appear in the table of contents. Titles that are placed on tables will appear in the List of Tables, and titles that are placed on figures and figure tables will be placed in the List of Illustrations. This element is included to allow the author flexibility in composing the manual in accordance with this spec.
<i>Source paragraph:</i>	MIL-STD-38784
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia note)
<i>Parents:</i>	abbrsect , applicdef , chapter , cntentry , contentsentry , deflist , figure , foldout , function , gchapter , jgfoldoutnoba , jgfoldoutwba , lrp , lrpentry , objmedia , para0 , randlist , ratddesc , ratdentry , seqlist , subpara1 , subpara2 , subpara3 , subpara4 , subpara5 , subpara6 , subpara7 , subpara8 , symsect , table , task , tasksp , tctolist , tctorow , tmimprep , wpgentry
<i>Entities used in this element:</i>	chgatt , delstat , exclus , secur , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tmidno

Technical Manual Identification Number

<i>Description:</i>	Identifies the technical manual identification number. When used on the title page (<idinfo>), it will cause the technical manual number to appear on the title page and at the top of each page in the manual. When used in the list of related publications (<lrp>), will cause the technical manual number to be placed in the Publication Number column.
<i>Source paragraph:</i>	MIL-STD-38784A 4.2.1.5 & 4.5.9.2
<i>Content Model:</i>	((#PCDATA change tabmat ftnref xref verbatim emphasis applicabil extapplicabil graphic extref dataiden hcp hci esds nsp oci ocp fcp acronym prindex secindex nameloc clink ilink object)+) -(figure table foldout objmedia)
<i>Parents:</i>	contentsentry , idinfo , jgindextab , lrpentry
<i>Entities used in this element:</i>	chgatt , delstat , exclus , secur , service , status , text , yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
service	(AF NAVAIR NAVSEA SPAWARS ARMY MC DLA CG DOD FRN)	#IMPLIED	Defines the branch of service.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
security	(u c s n)	n	Identifies security level of the document

tmimprep

Technical Manual Improvement Report

<i>Description:</i>	Identifies the technical manual improvement report paragraph.
<i>Source paragraph:</i>	MIL-STD-38784A 4.5.9

Content Model: ((title)?, (warning | caution | note | para | step1)*, subpara1*)

Parents: foreword

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, para0att, parazero, secur, status, verified, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
emergency	NUMBER	0	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	ID	#IMPLIED	Allows author to designate a unique paragraph ID for use with external and cross references.
esds	NUMBER	0	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	NUMBER	0	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcf	NUMBER	0	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	NUMBER	0	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hcl	NUMBER	0	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	NUMBER	0	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	NUMBER	0	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	IDREFS	#IMPLIED	Allows you to assign an applicable reference
verdate	CDATA	#IMPLIED	Identifies the date the element was verified.
verrem	CDATA	#IMPLIED	Provides a place for the author to make remarks about the verification of the element.
verstatus	(unver ver)	unver	Identifies verification status of the element.
security	(u c s n)	n	Identifies security level of the element.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	

toc

Table of Contents

Description: Defines the table of contents for the job guide.

Source paragraph: MIL-DTL-83495C 3.4.3.1.1

Content Model: ([contentsentry*](#), [contents](#), [contentsentry*](#))

Parents: [front](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [verified](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
verdate	CDATA	#IMPLIED	
verrem	CDATA	#IMPLIED	
verstatus	(unver ver)	unver	
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

tpdr

Technical Publications Deficiency Report

Description: Identifies the technical publications deficiency report list.

Source paragraph: MIL-STD-38784A 4.5.9

Content Model: ([tpdrtbl](#) | [none](#))

Parents: [front](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tpdrlocation

Technical Publications Deficiency Report Location

Description: Identifies an entry in the Location column of the technical publications deficiency report list.

Source paragraph: MIL-STD-38784A 4.5.9

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [tpdrrow](#), [tpdrtbl](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tpdrno

Technical Publications Deficiency Report Number

Description: Identifies an entry in the Report Control Number column of the technical publications deficiency report list.

Source paragraph: MIL-STD-38784A 4.5.9

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [tpdrrow](#), [tpdrtbl](#)

Entities used in this element: [chgatt](#), [delstat](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tpdrrow

Description:

Source paragraph:

Content Model: (activity, tpdno, tpdlocation)

Parents: tpdrtbl

Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

tpdrtbl

Technical Publications Deficiency Report

Description: Identifies the technical publications deficiency report list.

Source paragraph: MIL-STD-38784A 4.5.9

Content Model: (tpdrrow+ | (activity, tpdno, tpdlocation)+)

Parents: tpd

Entities used in this element: bodyatt, chgatt, content, db, delstat, itemid, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
id	ID	#IMPLIED	This allows you to identify each element and later reference it by its id value.
label	CDATA	#IMPLIED	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	CDATA	#IMPLIED	System, Subsystem, or Subject Number can be assigned to this element.
indexid	CDATA	#IMPLIED	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
unit	CDATA	#IMPLIED	
module	CDATA	#IMPLIED	
lru	CDATA	#IMPLIED	
compon	CDATA	#IMPLIED	
partno	CDATA	#IMPLIED	
contype	(desc proc)	#IMPLIED	
assocfig	IDREFS	#IMPLIED	
assoctab	IDREFS	#IMPLIED	
security	(u c s n)	n	Identifies security level of the document

typedes

Type Designation

Description: Identifies a type designation on the title page and the difference data sheet.

Source paragraph: MIL-STD-38784A 4.5.1.3.4 & 4.7.3.3.1B

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [lrpentry](#), [prttitle](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

typeno

Directive Type and Number

Description: Identifies an entry in the Type/No column of the record of applicable technical directives table.

Source paragraph: MIL-STD-38784A 4.5.9.4a

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Parents: [ratdentry](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [secur](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

underline

Description:

Source paragraph:

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+) -([figure](#) | [table](#) | [foldout](#) | [objmedia](#))

Included in: [expcont](#)

Entities used in this element: [exclus](#), [text](#)

use

Use

Description: Defines the purpose and primary use of each item in the consumable table.

Source paragraph: MIL-DTL-83495C 3.4.3.2.1.1.5

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+)

Parents: [consumtab](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Insert Change Level

Attribute	Type	Default	Description
delchlvl	NMTOKEN	#IMPLIED	Used to generate change packages - Delete Change Level
status	(empty deleted reserved notapp)	#IMPLIED	Allows you to specify the status of this element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

verbatim

Verbatim Text

<i>Description:</i>	A verbatim element is used to format computer examples or similar text in a typewritten emulation mode. Formatting follows 'asis' quadding with monospaced font.
<i>Source paragraph:</i>	MIL-PFR-28001C, B.3.14
<i>Content Model:</i>	(#PCDATA)
<i>Parents:</i>	abbrtitle, activity, address, applicabil, appltitle, authnot, cage, change, chap, chapno, chaptitle, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, faultcode, ftnote, func, functitle, hazmat, ilink, insertpg, internatlst, item, label, lepchg, leppage, line, maintlvl, mfr, mfrnad, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, persreq, phrase, pretmidno, prindex, pubdate, purpose, reference, remarks, removepg, revnum, secindex, seqno, sermo, sigblock, spec, ssn, subject, subtitle, supersed, suppl, symtitle, system, tctono, term, tfnid, title, tmidno, tpdrllocation, tpdno, typedes, typeno, underline, use, volnot, volnum
<i>Entities used in this element:</i>	chgatt, delstat, secur, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
allowbrk	NUMBER	1	Defines if a break can be inserted into verbatim text.
security	(u c s n)	n	Identifies security level of the document
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

verstat

Verification Status Page

<i>Description:</i>	Identifies the verification status page in the manual. This information is automatically compiled by the FOSI. This element should not be used if a verification status page is not desired.
<i>Source paragraph:</i>	MIL-STD-38784A 4.5.4
<i>Content Model:</i>	(tabmat?)
<i>Parents:</i>	front

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
autobuild	NUMBER	1	
agency	CDATA	#IMPLIED	
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

volnot

Volume Notice

Description: Identifies the volume notice on the title page.

Source paragraph: MIL-STD-38784A 4.2.9.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

volnum

Volume Number

Description: Identifies the volume number on the title page.

Source paragraph: MIL-STD-38784A 4.2.9.1

Content Model: ((#PCDATA | [change](#) | [tabmat](#) | [fnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))⁺)

Parents: [idinfo](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [text](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

warning

Warning

Description: Identifies a WARNING in the manual. Multiple warning tags may be used only when it is desired to change the warning icon (standard or hazardous warning graphic).

Source paragraph: MIL-STD-38784A 4.3.10

Content Model: ([icon?](#), [para*](#)) [-\(randlist | deflist | seqlist | figure | table | foldout | objmedia | warning | caution\)](#)

Parents: [abbrsect](#), [applicdef](#), [entry](#), [lrp](#), [para0](#), [ratddesc](#), [safecond](#), [step](#), [step1](#), [step2](#), [step3](#), [step4](#), [subpara1](#), [subpara2](#), [subpara3](#), [subpara4](#), [subpara5](#), [subpara6](#), [subpara7](#), [subpara8](#), [symsect](#), [tctolist](#), [tmimprep](#)

Included in: [function](#), [gchapter](#), [safesum](#)

Excluded in: [caution](#), [note](#), [warning](#)

Entities used in this element: [chgatt](#), [delstat](#), [exclus](#), [list](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

warnpage

Warning Page

Description: Identifies the warning page(s) of the manual.

Source paragraph: MIL-STD-38784A 4.5.2
Content Model: (wpgentry+)
Parents: front
Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

wpgentry

Warning Page Entry

Description: Identifies an individual warning on the warning page(s).
Source paragraph: MIL-STD-38784A 4.5.2
Content Model: (title, para+)
Parents: warnpage
Entities used in this element: chgatt, delstat, status, yesorno

ATTRIBUTE LIST

Attribute	Type	Default	Description
warnbox	NUMBER	#IMPLIED	Allows you to specify the appearance and size of the warning box.
delttype	(delete real reserve NA)	#IMPLIED	Used to generate change packages - Delete Type
inschlvl	NMTOKEN	#IMPLIED	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	NMTOKEN	#IMPLIED	Used during change package process to indicate the element was deleted at the change level indicated
status	(empty deleted reserved notapp)	#IMPLIED	Used during the change package process to indicate the current status of the element.
revchg	NUMBER	0	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.
titlefont	(10pt 14pt)	14pt	Specifies the font size choices available for a warning page entry.
line	NUMBER	#IMPLIED	Specifies whether a line should appear between warning page entries.

xref

Cross-reference

Description: Identifies a cross-reference to a paragraph, figure, table, etc.

Source paragraph: MIL-STD-38784A 4.3.1

Content Model: EMPTY

Parents: [abbrtitle](#), [activity](#), [address](#), [applicabil](#), [applttitle](#), [authnot](#), [bindByCoords](#), [bindById](#), [bindByName](#), [cage](#), [change](#), [chap](#), [chapno](#), [chapttitle](#), [chgdate](#), [chgnum](#), [chgpara](#), [chgtxt](#), [clink](#), [cogact](#), [contractno](#), [copyright](#), [dataiden](#), [date](#), [dateinc](#), [def](#), [destr](#), [discl](#), [distrib](#), [doctype](#), [ecpno](#), [effdatenot](#), [emphasis](#), [entry](#), [expcont](#), [extapplicabil](#), [faultcode](#), [fnote](#), [func](#), [functitle](#), [hazmat](#), [ilink](#), [insertpg](#), [internatlst](#), [item](#), [label](#), [lepchg](#), [leppage](#), [line](#), [maintlvl](#), [mfr](#), [mfrnad](#), [modelno](#), [moveddata](#), [mritem](#), [mrpara](#), [nmlist](#), [nomen](#), [nsn](#), [oadr](#), [pageno](#), [para](#), [param](#), [partno](#), [persreq](#), [phrase](#), [pretmidno](#), [prindex](#), [pubdate](#), [purpose](#), [reference](#), [remarks](#), [removepg](#), [revnum](#), [secindex](#), [seqno](#), [serno](#), [sigblock](#), [spec](#), [sssn](#), [subject](#), [subtitle](#), [supersed](#), [suppl](#), [symtitle](#), [system](#), [tctono](#), [term](#), [tfnid](#), [title](#), [tmidno](#), [tpdrlocation](#), [tpdrno](#), [typedes](#), [typeno](#), [underline](#), [use](#), [volnot](#), [volnum](#)

Entities used in this element: [chgatt](#), [delstat](#), [status](#), [yesorno](#)

ATTRIBUTE LIST

Attribute	Type	Default	Description
xrefid	IDREF	#IMPLIED	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
displayvalue	CDATA	#IMPLIED	
HyTime	NAME	#FIXED "clink"	Used in combination with HyTime to establish contextual link.
HyNames	NAMES	#FIXED "linkend xrefid"	Used in combination with HyTime to establish contextual link.
deltype	(delete real reserve NA)	#IMPLIED	
inschlvl	NMTOKEN	#IMPLIED	
delchlvl	NMTOKEN	#IMPLIED	
status	(empty deleted reserved notapp)	#IMPLIED	
revchg	NUMBER	0	

% bodyatt

Unexpanded:

label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
%chgatt;
%db;

Expanded:

label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% bodyele

Unexpanded:

([chgchapter](#)?, ([chgchapter](#)continue | [chaptercontinue](#))?, ([chapter](#))*)

Expanded:

([chgchapter](#)?, ([chgchapter](#)continue | [chaptercontinue](#))?, ([chapter](#))*)

% cgmatts

Unexpanded:

id ID #IMPLIED
title CDATA #IMPLIED
descript CDATA #IMPLIED
visibility (visible | hidden) 'visible'
interactivity (interactive | none) 'none'
%chgatt;

Expanded:

id ID #IMPLIED
title CDATA #IMPLIED
descript CDATA #IMPLIED
visibility (visible | hidden) 'visible'
interactivity (interactive | none) 'none'
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED

delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% chap

Unexpanded:
([title](#), [function](#)+)

Expanded:
([title](#), [function](#)+)

% chapatt

Unexpanded:
id ID #IMPLIED
[%secur](#);
[%bodyatt](#);

Expanded:
id ID #IMPLIED
security (u | c | s | n) 'n'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% chgatt

Unexpanded:
deltype ([%delstat](#);) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status ([%status](#);) #IMPLIED
revchg [%yesorno](#); '0'

Expanded:
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% chgsht

Unexpanded:

chgnum, address, date, prtitle, effdatenot?, discl?, distrib, expcont?, destr?, chgpara+, chglist, sigblock?

Expanded:

chgnum, address, date, prtitle, effdatenot?, discl?, distrib, expcont?, destr?, chgpara+, chglist, sigblock?

% cntnt

Unexpanded:

(cntentry* | #PCDATA)*

Expanded:

(cntentry* | #PCDATA)*

% content

Unexpanded:

skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

Expanded:

skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% db

Unexpanded:

%itemid; %content;

Expanded:

unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% delstat

Unexpanded:

delete | real | reserve | NA

Expanded:

delete | real | reserve | NA

% doc

Unexpanded:

[docjg](#)

Expanded:

[docjg](#)

% docatt

Unexpanded:

docid CDATA #IMPLIED
docstat (revision | change | prelim | draft | formal) 'prelim'
verstatpg (ver | unver) 'unver'
index %[yesorno](#); '0'

Expanded:

docid CDATA #IMPLIED
docstat (revision | change | prelim | draft | formal) 'prelim'
verstatpg (ver | unver) 'unver'
index NUMBER '0'

% entry

Unexpanded:

(%[text](#); | %[list](#); | [warning](#) | [caution](#) | [note](#))+

Expanded:

((#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#)) + | [randlist](#) | [deflist](#) | [seqlist](#) | [warning](#) | [caution](#) | [note](#))+

% entryatt

Unexpanded:

colname NMTOKEN #IMPLIED
spanname NMTOKEN #IMPLIED
id ID #IMPLIED
morerows NUMBER '0'
colsep %[yesorno](#); #IMPLIED

rowsep %yesorno; #IMPLIED
rotate %yesorno; '0'
valign (top | middle | bottom) #IMPLIED
align (left | right | center | justify | char) #IMPLIED
charoff NUTOKEN #IMPLIED
char CDATA #IMPLIED
%chgatt;

Expanded:

colname NMTOKEN #IMPLIED
spanname NMTOKEN #IMPLIED
id ID #IMPLIED
morerows NUMBER '0'
colsep NUMBER #IMPLIED
rowsep NUMBER #IMPLIED
rotate NUMBER '0'
valign (top | middle | bottom) #IMPLIED
align (left | right | center | justify | char) #IMPLIED
charoff NUTOKEN #IMPLIED
char CDATA #IMPLIED
deltypes (delete | real | reserve | NA) #IMPLIED
inschl NMTOKEN #IMPLIED
delchl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% exclus

Unexpanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

Expanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

expcontnot

Unexpanded:

This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C. SEC 2751, <underline>et</underline> <underline>seq</underline>.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App 2401 <underline>et</underline> <underline>seq</underline>. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

Expanded:

This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C. SEC 2751, <underline>et</underline> <underline>seq</underline>.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App 2401 <underline>et</underline> <underline>seq</underline>. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

% fig

Unexpanded:

(([title](#))?, (([subfig](#), [subfig](#)+) | (([graphic](#), [legend](#)?) | [tabmat](#)))+)

Expanded:

(([title](#))?, (([subfig](#), [subfig](#)+) | (([graphic](#), [legend](#)?) | [tabmat](#)))+)

% figatts

Unexpanded:

pgwide %[yesorno](#); '1'
orient (port | land) 'port'
samepg %[yesorno](#); '0'
place (inline|float) float
id ID #IMPLIED
applicref IDREFS #IMPLIED
%[verified](#);
%[bodyatt](#);
%[secur](#);

Expanded:

pgwide NUMBER '1'
orient (port | land) 'port'
samepg NUMBER '0'
place (inline|float) float
id ID #IMPLIED
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
delttype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED
security (u | c | s | n) 'n'

% fpi

Unexpanded:

[para0](#), ([para0](#) | [applicdef](#) | [symsect](#) | [abbrsect](#) | [internatlst](#) | [lrp](#) | [tctolist](#) | [ratddesc](#) | [tmimprep](#))*

Expanded:

[para0](#), ([para0](#) | [applicdef](#) | [symsect](#) | [abbrsect](#) | [internatlst](#) | [lrp](#) | [tctolist](#) | [ratddesc](#) | [tmimprep](#))*

% frnt

Unexpanded:

[idinfo](#), [warnpage?](#), [chginsst?](#), [lep](#), [verstat?](#), [tpdr?](#), [chgrec?](#), [toc?](#), [foreword?](#), [safesum?](#)

Expanded:

[idinfo](#), [warnpage?](#), [chginssht?](#), [lep](#), [verstat?](#), [tpdr?](#), [chgrec?](#), [toc?](#), [foreword?](#), [safesum?](#)

% graphatt

Unexpanded:

id ID #IMPLIED
boardno ENTITY #REQUIRED
graphsty NMTOKEN #IMPLIED
llcordra CDATA #IMPLIED
rucordra CDATA #IMPLIED
reprowid NUTOKEN #IMPLIED
reprodep NUTOKEN #IMPLIED
hscale NUMBER #IMPLIED
vscale NUMBER #IMPLIED
scalefit %[yesorno](#); #IMPLIED
hplace (left | right | center) #IMPLIED
vplace (top | middle | bottom) #IMPLIED
coordst CDATA #IMPLIED
coordend CDATA #IMPLIED
color %[yesorno](#); '0'
icon (yes|no) 'no'
%[chgatt](#);

Expanded:

id ID #IMPLIED
boardno ENTITY #REQUIRED
graphsty NMTOKEN #IMPLIED
llcordra CDATA #IMPLIED
rucordra CDATA #IMPLIED
reprowid NUTOKEN #IMPLIED
reprodep NUTOKEN #IMPLIED
hscale NUMBER #IMPLIED
vscale NUMBER #IMPLIED
scalefit NUMBER #IMPLIED
hplace (left | right | center) #IMPLIED
vplace (top | middle | bottom) #IMPLIED
coordst CDATA #IMPLIED
coordend CDATA #IMPLIED
color NUMBER '0'
icon (yes|no) 'no'
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% icon

Unexpanded:

[graphic+](#), [hazmat+](#), [seqno](#)

Expanded:

[graphic+](#), [hazmat+](#), [seqno](#)

% idinf

Unexpanded:

[tmidno+](#), ([chgnum](#), [chgdate](#))?, [chghistory](#), [pretmidno*](#), [volnum?](#), [revnum?](#), [doctype](#), [maintlvl?](#), [prtitle](#), [subtitle?](#), ([mfr+](#), [contractno+](#))?, [seal?](#), [superseded?](#), [suppl*](#), [effdatenot?](#), [volnot?](#), [discl?](#), [distrib](#), [expcont?](#), [destr?](#), [copyright*](#), [cogact?](#), [moveddata?](#), [authnot](#), [downgrd?](#), [pubdate](#)

Expanded:

[tmidno+](#), ([chgnum](#), [chgdate](#))?, [chghistory](#), [pretmidno*](#), [volnum?](#), [revnum?](#), [doctype](#), [maintlvl?](#), [prtitle](#), [subtitle?](#), ([mfr+](#), [contractno+](#))?, [seal?](#), [superseded?](#), [suppl*](#), [effdatenot?](#), [volnot?](#), [discl?](#), [distrib](#), [expcont?](#), [destr?](#), [copyright*](#), [cogact?](#), [moveddata?](#), [authnot](#), [downgrd?](#), [pubdate](#)

% inclus

Unexpanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

Expanded:

[figure](#) | [table](#) | [foldout](#) | [objmedia](#)

% itemid

Unexpanded:

[unit](#) CDATA #IMPLIED
[module](#) CDATA #IMPLIED
[lru](#) CDATA #IMPLIED
[compon](#) CDATA #IMPLIED
[partno](#) CDATA #IMPLIED
[refdes](#) CDATA #IMPLIED

Expanded:

[unit](#) CDATA #IMPLIED
[module](#) CDATA #IMPLIED
[lru](#) CDATA #IMPLIED
[compon](#) CDATA #IMPLIED
[partno](#) CDATA #IMPLIED
[refdes](#) CDATA #IMPLIED

% lepcontents

Unexpanded:

[lepentry+](#)

Expanded:

[lepentry+](#)

% lineatt

Unexpanded:

quad (left | center | right | justify) left
indent CDATA #IMPLIED

Expanded:

quad (left | center | right | justify) left
indent CDATA #IMPLIED

% list

Unexpanded:

[randlist](#) | [deflist](#) | [seqlist](#)

Expanded:

[randlist](#) | [deflist](#) | [seqlist](#)

% lrp

Unexpanded:

(%[parazero](#);; [subpara1](#)*)?, [lrptable](#)?

Expanded:

(([title](#))?, ([warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*, [subpara1](#)*)?, [lrptable](#)?

% nparcon

Unexpanded:

([title](#) | [warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*

Expanded:

([title](#) | [warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*

% nparcon1

Unexpanded:

[warning](#)*, [caution](#)?, [note](#)?, ([title](#))?,[para](#), [note](#)?, [step1](#)*

Expanded:

[warning](#)*, [caution](#)?, [note](#)?, ([title](#))?,[para](#), [note](#)?, [step1](#)*

% para0att

Unexpanded:

```
emergency %yesorno; '0'  
id ID #IMPLIED  
esds %yesorno; '0'  
nsp %yesorno; '0'  
fcp %yesorno; '0'  
hcp %yesorno; '0'  
hci %yesorno; '0'  
ocp %yesorno; '0'  
oci %yesorno; '0'  
applicref IDREFS #IMPLIED  
%verified;  
%secur;  
%bodyatt;
```

Expanded:

```
emergency NUMBER '0'  
id ID #IMPLIED  
esds NUMBER '0'  
nsp NUMBER '0'  
fcp NUMBER '0'  
hcp NUMBER '0'  
hci NUMBER '0'  
ocp NUMBER '0'  
oci NUMBER '0'  
applicref IDREFS #IMPLIED  
verdate CDATA #IMPLIED  
verrem CDATA #IMPLIED  
verstatus (unver | ver) 'unver'  
security (u | c | s | n) 'n'  
label CDATA #IMPLIED  
sssn CDATA #IMPLIED  
indexid CDATA #IMPLIED  
deltypes (delete | real | reserve | NA) #IMPLIED  
inschlvl NMTOKEN #IMPLIED  
delchlvl NMTOKEN #IMPLIED  
status (empty | deleted | reserved | notapp) #IMPLIED  
revchg NUMBER '0'  
unit CDATA #IMPLIED  
module CDATA #IMPLIED  
lru CDATA #IMPLIED  
compon CDATA #IMPLIED  
partno CDATA #IMPLIED  
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED  
contype (desc | proc) #IMPLIED  
assocfig IDREFS #IMPLIED  
assoctab IDREFS #IMPLIED
```

% paracon

Unexpanded:

```
(%text; | %list;)+
```

Expanded:

```
((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+ | randlist | deflist | seqlist)+
```

% parazero

Unexpanded:

([title](#))?, ([warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*

Expanded:

([title](#))?, ([warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*

% pubatts

Unexpanded:

controlno CDATA '00000000'
cycle CDATA 'new'
chglevel NUMBER #IMPLIED
initlabel NUMBER #IMPLIED
initpage NUMBER '1'
docno CDATA #IMPLIED
highguid NUMBER '0'
labelstyle CDATA 'FAN'

Expanded:

controlno CDATA '00000000'
cycle CDATA 'new'
chglevel NUMBER #IMPLIED
initlabel NUMBER #IMPLIED
initpage NUMBER '1'
docno CDATA #IMPLIED
highguid NUMBER '0'
labelstyle CDATA 'FAN'

% safesum

Unexpanded:

[para0](#)+

Expanded:

[para0](#)+

% secur

Unexpanded:

security (u | c | s | n) 'n'

Expanded:

security (u | c | s | n) 'n'

% service

Unexpanded:

(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)

Expanded:

(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)

% status

Unexpanded:

empty | deleted | reserved | notapp

Expanded:

empty | deleted | reserved | notapp

% step1.mdl

Unexpanded:

(%stepcon;,, (step2, step2+)?)

Expanded:

((warning*, caution?, note?, para, specinst*, result*, note?), (step2, step2+)?)

% step2.mdl

Unexpanded:

(%stepcon;,, (step3, step3+)?)

Expanded:

((warning*, caution?, note?, para, specinst*, result*, note?), (step3, step3+)?)

% step3.mdl

Unexpanded:

(%stepcon;,, (step4, step4+)?)

Expanded:

((warning*, caution?, note?, para, specinst*, result*, note?), (step4, step4+)?)

% stepatt

Unexpanded:

```
%chgatt;  
applicref IDREFS #IMPLIED  
label CDATA #IMPLIED  
emergency %yesorno; '0'  
sssn CDATA #IMPLIED  
id ID #IMPLIED  
person CDATA #IMPLIED  
esds %yesorno; '0'  
nsp %yesorno; '0'  
fcp %yesorno; '0'  
hcp %yesorno; '0'  
hci %yesorno; '0'  
ocp %yesorno; '0'  
oci %yesorno; '0'  
clitem %yesorno; '0'  
%db;
```

Expanded:

```
delttype (delete | real | reserve | NA) #IMPLIED  
inschlvl NMTOKEN #IMPLIED  
delchlvl NMTOKEN #IMPLIED  
status (empty | deleted | reserved | notapp) #IMPLIED  
revchg NUMBER '0'  
applicref IDREFS #IMPLIED  
label CDATA #IMPLIED  
emergency NUMBER '0'  
sssn CDATA #IMPLIED  
id ID #IMPLIED  
person CDATA #IMPLIED  
esds NUMBER '0'  
nsp NUMBER '0'  
fcp NUMBER '0'  
hcp NUMBER '0'  
hci NUMBER '0'  
ocp NUMBER '0'  
oci NUMBER '0'  
clitem NUMBER '0'  
unit CDATA #IMPLIED  
module CDATA #IMPLIED  
lru CDATA #IMPLIED  
compon CDATA #IMPLIED  
partno CDATA #IMPLIED  
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED  
contype (desc | proc) #IMPLIED  
assocfig IDREFS #IMPLIED  
assoctab IDREFS #IMPLIED
```

% stepcon

Unexpanded:

```
(warning*, caution?, note?, para, specinst*, result*, note?)
```

Expanded:

```
(warning*, caution?, note?, para, specinst*, result*, note?)
```

% sub1att

Unexpanded:

%para0att;

Expanded:

emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'
security (u | c | s | n) 'n'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% sub2att

Unexpanded:

%para0att;

Expanded:

emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'
security (u | c | s | n) 'n'

label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% sub3att

Unexpanded:
%para0att;

Expanded:
emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'
security (u | c | s | n) 'n'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% subatts

Unexpanded:

%[para0att](#);

Expanded:

emergency NUMBER '0'
id ID #IMPLIED
esds NUMBER '0'
nsp NUMBER '0'
fcp NUMBER '0'
hcp NUMBER '0'
hci NUMBER '0'
ocp NUMBER '0'
oci NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'
security (u | c | s | n) 'n'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED

% subfig

Unexpanded:

([graphic](#), [legend?](#))

Expanded:

([graphic](#), [legend?](#))

% subpara3.mdl

Unexpanded:

(%[nparcon1](#);; [subpara4](#)*)

Expanded:

([warning](#)*, [caution](#)?, [note](#)?, (title)?, [para](#), [note](#)?, [step1](#)*, [subpara4](#)*)

suppnotice

Unexpanded:

A suitable reference to this supplement will be made on the title page of the basic publication.

Expanded:

A suitable reference to this supplement will be made on the title page of the basic publication.

% symsect

Unexpanded:

(%[parazero](#);, [subpara1](#)*)?, (symtitle?, (symrow+ | (term, def)+))

Expanded:

(([title](#))?, ([warning](#) | [caution](#) | [note](#) | [para](#) | [step1](#))*, [subpara1](#)*)?, (symtitle?, (symrow+ | (term, def)+))

% tabatts

Unexpanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) 'all'
colsep %[yesorno](#); '1'
rowsep %[yesorno](#); '0'
orient (port | land1) 'port'
pgwide %[yesorno](#); '1'
cellcont (Continued | Cont) 'Continued'
id ID #IMPLIED
footnotes (page | end) #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep %[yesorno](#); '0'
applicref IDREFS #IMPLIED
%[verified](#);
%[bodyatt](#);
%[secur](#);

Expanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) 'all'
colsep NUMBER '1'
rowsep NUMBER '0'
orient (port | land1) 'port'
pgwide NUMBER '1'
cellcont (Continued | Cont) 'Continued'
id ID #IMPLIED
footnotes (page | end) #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED

rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep NUMBER '0'
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
unit CDATA #IMPLIED
module CDATA #IMPLIED
lru CDATA #IMPLIED
compon CDATA #IMPLIED
partno CDATA #IMPLIED
refdes CDATA #IMPLIED skilltrk NMTOKENS #IMPLIED
contype (desc | proc) #IMPLIED
assocfig IDREFS #IMPLIED
assoctab IDREFS #IMPLIED
security (u | c | s | n) 'n'

% tabl

Unexpanded:

[title](#), [tgroup](#)+

Expanded:

[title](#), [tgroup](#)+

% text

Unexpanded:

(#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+

Expanded:

(#PCDATA | [change](#) | [tabmat](#) | [ftnref](#) | [xref](#) | [verbatim](#) | [emphasis](#) | [applicabil](#) | [extapplicabil](#) | [graphic](#) | [extref](#) | [dataiden](#) | [hcp](#) | [hci](#) | [esds](#) | [nsp](#) | [oci](#) | [ocp](#) | [fcp](#) | [acronym](#) | [prindex](#) | [secindex](#) | [nameloc](#) | [clink](#) | [ilink](#) | [object](#))+

% verified

Unexpanded:

verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'

Expanded:

verdate CDATA #IMPLIED

verrem CDATA #IMPLIED
verstatus (unver | ver) 'unver'

% yesorno

Unexpanded:
NUMBER

Expanded:
NUMBER