



OxyMax 100/200/400

D	Gebrauchsanleitung und Garantie	HU	Használ
Εľ	N Operating instructions and Guarantee	PL	Instruk
FF	Notice d'emploi et Garantie	CS	Návod k
N	L Gebruiksaanwijzing en Garantie	SK	Návod r
ES	Instrucciones de uso y Garantía	SL	Navodil
PΊ	Instruções de uso e Garantia	HR	Uputa o
IT	Istruzioni d'uso e Garanzia	RO	Instrucț
D	A Brugsanvisning og Garanti	BG	Упътва:
N		UK	Посібні
S۱	/ Bruksanvisning och Garanti	RU	Руковод
FI	Käyttöohje ja Takuu	CN	使用说

ilati útmutató és Garancia cja użytkowania i Gwarancja k použití a Záruka


na použitie a Záruka

la za uporabo in Garancija o upotrebi i Jamstvo


tiuni de folosintă și Garantie


, не за употреба и Гаранция ик з експлуатації та Гарантія

Руководство по эксплуатации и Гарантия 使用说明书 和 保用证书














Translation of the original Operating Instructions

SAFETY INFORMATION

This unit can be used by children aged 8 and above and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they are supervised or have been instructed on how to use the unit in a safe way and they understand the hazards involved.

Do not allow children to play with the unit.

Only allow children to carry out cleaning and user maintenance under supervision.

Safe operation

- Switch off all units in the aquarium or disconnect the power plugs of all units before reaching into the water.
- Never operate the unit if either the electrical cables or the housing are defective!
- Do not carry or pull the unit by its electrical cable.
- Route cables/hoses such that they are protected from damage and do not present a tripping hazard.
- Only open the unit housing or its attendant components, when this is explicitly required in the operating instructions.
- Only carry out work on the unit that is described in this manual. If problems cannot be overcome, please contact an authorised customer service point or, when in doubt, the manufacturer.
- Only use original spare parts and accessories for the unit.
- Never carry out technical modifications to the unit.
- Power connection cables cannot be replaced. If a cable is damaged, dispose of the respective unit or components.

Electrical connection

- Only connect the unit if the electrical data of the unit and the power supply coincide. The unit data is to be found on the unit type plate, on the packaging or in this manual.
- Protect the plug connections from moisture.
- Only plug the unit into a correctly fitted socket.

Symbols used in these instructions



Ј моте

Indicates information intended to give the user a better understanding.

Additional information

A Reference to a figure, e.g. Fig. A.

PRODUCT DESCRIPTION

Intended use

OxyMax 100/200/400, referred to in the following as "unit", may only be used as specified in the following:

- For aeration and supplying oxygen to an aquarium.
- Operation under observance of the technical data.

The following restrictions apply to the unit:

- Only use indoors and outside of the aquarium.
- Do not use for commercial or industrial purposes.
- Do not use in conjunction with chemicals, foodstuff, easily flammable or explosive substances.

INSTALLATION AND CONNECTION

□ A, B

Set-up the unit

- Always install the unit higher than the water level. This prevents water from possibly flowing back into the pump.
- Use the fastening lug for installation.
- Route the power connection cable such that it forms a drip loop.

When installing the unit, ensure that it

- is located outside the aquarium
- is not placed on or over the aquarium
- cannot fall into the water or move out of position.

Damage resulting from incorrect installation is not basis for a claim within the framework of the guarantee or warranty.

Connect the unit

- Keep the air hose as short as possible and lay it well protected.
- Connect the aeration stone to the air hose and position the aeration stone in the pond.
- Attach the free end of the air hose to the air outlet on the unit.

COMMISSIONING/START-UP



NOTE

Never operate an air connection by itself, i. e. without the tube and aerator connected.

Switching on: Connect the unit to the mains. The unit switches on as soon as the power connection is established.

Switching off: Disconnect the unit from the mains.

Adjusting the air quantity and bubble pattern



Air quantity: Adjust the air quantity by turning the air connection control knob.

Bubble pattern: Take the aerator out of the water and adjust the bubble pattern at the aerator using a coin. Adhere to the safety instructions!

WEAR PARTS

The following components are wear parts and are excluded from the warranty:

· Aerator, filter felt discs, membrane

REMEDY OF FAULTS

Malfunction	Cause	Remedy
The unit is not op- erating	No mains voltage	Check the mains voltage.
The unit does not	Aerator soiled	Clean or replace the aerator.
deliver any air or	Filter felt in the pump or aerator worn	Replace the filter felt.
the amount delivered is insufficient.	Air hose kinked or porous	Lay the air hose without kinks or replace.
	Membrane is defective	Replace the membrane
The unit is unusually loud	Membrane is defective	Replace the membrane

MAINTENANCE AND CLEANING

 \Box C

Replacing the filter felt in the unit

How to proceed:

- 1. Turn the unit over and replace both felt discs in the housing base.
- 2. Reassemble the unit in the reverse order.

Replacing the filter felt in the aerator

How to proceed:

- 1. Take the aerator out of the water.
- 2. Open the aerator using a coin and replace the felt disc.
- 3. Close the aerator again.

Replacing the membrane

Fitting instructions are supplied with the spare part.

DISPOSAL

Do not dispose of this unit with domestic waste! For disposal purposes, please use the return system provided. Render the unit unusable beforehand by cutting the cables.

GUARANTEE

For this OASE unit purchased by you, OASE GmbH assumes a **36 month manufacturer's** guarantee in accordance with the guarantee conditions laid down in the following. The guarantee period starts with the first purchase from an OASE specialist dealer. In other words, in the event of a resale, the guarantee period will not start again. If services are provided under the terms of this guarantee, this does not lead to extension or renewal of the guarantee period. Your legal rights as a purchaser, especially those ensuing from the warranty, persist. They are not restricted by this guarantee.

Guarantee conditions

OASE GmbH guarantees impeccable, purposerelated properties and workmanship, expert assembly and proper functionality. Subject to our discretion, the guarantee refers to free-ofcharge repair or free-of-charge supply of spare parts or of a replacement unit respectively. Should the unit type concerned no longer be manufactured, we reserve the right, at our discretion, to supply a replacement unit from our range that is closest to the type subject to complaint. Claims, the origin of which can be traced back to installation and operating faults as well as lack of care, e.g. the use of unsuitable cleaning materials or negligent maintenance, use other than that intended, damage due to accidents, falls, impact, effect of frost, cutting plugs, shortening cables, calcium deposits or improper attempts to repair the unit, are not covered by our guarantee. We hereby refer to the proper use as specified in the instructions of use that form an integral part of the guarantee. Wear parts such as bulbs etc. are exempted from the guarantee. The refund of costs for removal and installation, checks, claims for lost profit and damages are exempted from the guarantee together with further reaching claims for damages and loss of whatever nature caused by the unit or its use.

The guarantee is only valid in the country in which the unit was purchased from an OASE dealer. This guarantee is governed by German law under the exclusion of the agreement of the United Nations covering contracts governing the international sale of goods (CISG) regulations.

Guarantee claims can only be brought forward by presenting the sales receipt to us, OASE GmbH, Tecklenburger Straße 161 in D-48477 Hörstel, Germany by returning to us the unit or part of the unit subject to complaint, freight free, at your own risk, accompanied by a copy of the original purchase receipt from the OASE specialist dealer, this guarantee document and written information of the fault encountered.


OxyMax 100	vMax 100 230 V AC, 50 Hz 3.5 W 100 l/h			
OxyMax 200	230 V AC, 50 Hz	3.5 W	200 l/h	
OxyMax 400	230 V AC, 50 Hz	4 W	360 l/h	
DE	Bemessungsspannung	Leistungsaufnahme	Luftfördermenge	
EN	Rated voltage	Power consumption	Air flow rate	
FR	Tension de mesure	Puissance absorbée	Débit d'air	
NL	Dimensioneringsspanning	Vermogensopname	Luchtstroom	
ES	Tensión asignada	Consumo de potencia	Caudal de aire	
PT	Voltagem considerada	Potência absorvida	Caudal de ar	
IT	Tensione di taratura	Potenza assorbita	Quantità di aria convogliata	
DA	Nominel spænding	Effektforbrug	Luftstrøm	
NO	Merkespenning	Effektopptak	Transportert luftmengde	
sv	övre märkspänning	Effekt	Luftkapacitet	
FI	mitoitusjännite	Ottoteho	Ilmankuljetusmäärä	
HU	mért feszültség	Teljesítményfelvétel	Szállított levegő mennyisége	
PL	napięcie znamionowe	Pobór mocy	Ilość tłoczonego powietrza	
cs	domezovací napětí	Příkon	Přítok vzduchu	
SK	dimenzačné napätie	Príkon	Dopravované množstvo vzduchu	
SL	dimenzionirana napetost	Poraba moči	Pretok zraka	
HR	gornji nazivni napon	Potrošnja energije	Protok zraka	
RO	tensiunea măsurată	Putere consumată	Debit de aer	
BG	номинално напрежение	Потребявана мощност	Дебит на въздуха	
UK	розрахункова напруга	Споживання	Кількість повітря, що подається	
		електроенергії		
RU	расчетное напряжение	Потребление	Количество подаваемого	
		мощности	воздуха	
CN	设计电压	功耗	送气量	

	IP X4			<u> Z</u>	
DE	Schutz gegen das Eindringen von Spritzwasser.	Schutzklasse II, Schutzisolie-rung, die im Fehlerfall Spannung führen kann	Im Innenraum verwenden.	Nicht mit nor- malem Haus- müll entsorgen!	Lesen Sie die Gebrauchsan- leitung
EN	Protection against the ingress of splash water.	Protection class II, pro- tection insulation which could become live in the event of a fault.	For indoor use.	Do not dispose of together with household waste!	Read the ope- rating in- structions.
FR	Protection contre la pénétration de pro-jection d'eau	Classe de protection II, double isolation ris- quant de conduire une tension électrique en cas de défaut.	Pour utilisation à l'intérieur.	Ne pas recycler dans les or- dures ména- gères!	Lire la notice d'emploi.
NL	Beveiliging tegen het binnendringen van spatwater.	Beschermingsklasse II, randaarding, die bij de- fecten spanning kan ge- leiden.	In interne in- zetstuk gebrui- ken.	Niet met het normale huis- vuil afvoeren!	Lees de ge- bruiksaan- wijzing.
ES	Protección contra la entrada de agua salpicante	Clase de protección II, aislamiento de protec- ción que en caso de de- fecto pueden conducir tensión.	Para empleo in- terior.	¡No deseche el equipo en la basura domés- tica!	Lea las instruc- ciones de uso.
PT	Protecção contra respingos de água.	Classe de isolamento II, isolamento protector que em caso de defeito pode ser percorrido por tensão eléctrica	Utilizar em in- teriores.	Não deitar ao lixo doméstico!	Leia as instru- ções de utiliza- ção.

	IP X4			Z	<u> </u>
ΙΤ	Protezione contro la penetrazione di spruzzi d'acqua	Classe di protezione II, isolamento di prote- zione che in caso di di- fetto può condurre ten- sione	Utilizzare nell'inseri- mento interno	Non smaltire con normali ri- fiuti domestici!	Leggere le istruzioni d´uso!
DK	Beskyttelse mod indtrængning af vand-sprøjt.	Beskyttelses-klasse II, beskyttelses-isolering, som i tilfælde af fejl kan lede spænding.	Anvendesin- dendørs.	Må ikke bort- skaffes med det almindelige husholdningsaf- fald!	Læs brugsan- visningen.
NO	Beskyttelse mot inntrenging av vannsprut.	Beskyttelsesklasse II, dobbeltisolering som kan bli spennings- førende ved feil.	Bruknin- nendørs.	Ikke kast i alminnelig husholdnings- avfall!	Les bruksanvis- ningen.
SE	Skydd mot in- trängande stänk- vatten.	Kapslingsklass II, skyddsisolering som kan bli strömförande vid störningar	Ska använda- sinomhus.	Får inte kastas i hushållsso- porna!	Läs igenom bruksanvisnin- gen.
FI	Suoja roiskeveden sisäänpääsemisen estämiseksi	Kotelointiluokka II, häi- riötapauksissa mahdolli- sesti jännitteisten suoja- eristys.	Sisällääto- imivana käytettäväksi.	Älä hävitä lai- tetta tavallisen kotitalousjät- teen mukana!	Lue käyttöohje.

	IP X4			X	<u> </u>
HU	Permetvíz behato- lása elleni véde- lem.	II-es védelmi osztály, védőszigetelés, mely hiba esetén feszültséget vezethet	Beltéri has- ználatra.	A készüléket nem a normál háztartási szeméttel együtt kell megsem- misíteni!	Olvassa el a használati útmutatót.
PL	Zabezpieczenie przed przenika- niem rozpryskują- cej się wody.	Klasa ochrony II, izolacja ochronna, które w przy- padku usterki mogą znajdować się pod na- pięciem	Do zastosowa- nia we wnętrzu.	Nie wyrzucać wraz ze śmie- ciami domo- wymi!	Przeczytać in- strukcję użytkowania!
CZ	Ochrana proti pro- nikání odstřikující vody.	Třída ochrany II, ochranná izolace, která v případě závady může vést napětí.	Používejte uvnitř.	Nelikvidovat v normálním ko- munálním od- padu!	Přečtěte Návod k použití!
SK	Ochrana proti pre- nikaniu odstre- kujúcej vody	Trieda ochrany II, ochranná izolácia, ktorá v prípade závady môže viest napätie.	Používajte v in- teriéri.	Nelikvidovať v normálnom ko- munálnom odpade!	Prečítajte si Návod na použitie.
SI	Zaščita pred vdiranjem pršeče vode	Zaščitni razred II, zaščitna izolacija, ki v primeru napake lahko prevaja napetost	Za notranjo uporabo.	Ne zavrzite sku- paj z gospodinj- skimi odpadki!	Preberite na- vodila za uporabo!
HR	Zaštita od pro- diranja prskajuće vode	Stupanj zaštite II, zaštitna izolacija, u slučaju greške može biti pod naponom	Upotrebljavajte u zatvorenom prostoru.	Ne bacati u običan kućni ot- pad!	Pročitajte upute za upot- rebu!

	IP X4			X	<u> </u>
RO	Protecție împo- triva intrării apei de stropire.	Clasa de protecție II, izolație de protecție conducătoare de ten- siune în caz de eroare	Utilizaţi în inte- rior.	Nu aruncaţi în gunoiul menajer!	Citiţi in- strucţiunile de utilizare !
BG	Защита от нахлу- ване на вода от разпръсквана водна струя	Клас защита II, пред- пазна изолация, която в случай на нередност може да провежда напрежение	Използвайте на закрито.	Не изхвър- ляйте заедно с обикновения домакински боклук!	Прочетете упътването.
UA	Захист від бризок води.	Клас захисту II, захисна ізоляція яка у випадку аварії може проводити струм.	Використовува ти всередині приміщень.	Не викидайте з побутовим сміттям!	Читайте інструкцію.
RU	Защита от про- никновения во- дяных брызг	Класс защиты II, за- щитная изоляция, ко- торая при неисправно- сти может стать токо- ведущей	Применять только внутри помещения.	Не утилизиро- вать вместе с домашним му- сором!	Прочитайте инструкцию по использовани ю.
CN	C防止溅水渗入。	第二保护级·绝缘保护层在故障时会有电压	在室内使用。	不要与普通的 家庭 垃圾一起处 理!	请阅读使用说 明书。!



DYX0014



 ϵ

OASE GmbH · www.oase-livingwater.com