INTERNAL_TIMER SINGLE_SHOT_WAKE_UP CONTINUOUS slave: master: master: PC PC PC Worker_DAQ QTimer Worker_DAQ wake up query reply data stream Worker_DAQ Worker_DAQ slave: master: peripheral I/O device reply reply peripheral query query I/O device slaves: peripheral peripheral I/O device I/O device