RS232 Command

Function Name	Function Type	Command Data (HEX)							Additional Information		
	ON	BE EF		06 00	2A D3						
OPS Power	OFF	BE EF	03	06 00	BA D2		00 60				
	GET	BE EF			19 D3				1D 00 00 : OFF	1D 00 00 : ON	
Source	OPS	BE EF	03		FE D2 0E D2		00 20				
	HDMI VGA	BE EF	03		6E D2	01 00		01 00			
	GET	BE EF	03	06 00	CD D2	02 00			1D 00 01: PC	1D 00 02: VGA	1D 00 03:HDMI
Backlight	GET	BE EF	03	06 00	89 D2	02 00			1D 00 XX : value	10 00 02. VOIX	1B 00 00.11Bivii
	INCREMENT	BE EF	03	06 00	EF D2	04 00		00 00			
	DECREMENT			06 00	3E D3		03 20				
	SET	BE EF		06 00	89 D2	03 00	03 20	00 00	Default Value: 0x64	Range: 0x64 - 0x1E	
Volume	RESET	BE EF		06 00	58 D3		00 70		1D 00 VV		
	GET INCREMENT	BE EF	03	06 00 06 00	31 D3 57 D3		01 20	00 00	1D 00 XX : value		
	DECREMENT		03	06 00	86 D2		01 20				
	SET	BE EF	03	06 00	31 D3				Default Value: 0x10	Range: 0x1D-0x00	
Screen	ON	BE EF	03		FB D8	01 00		00 00		J. J.	
	OFF	BE EF	03	06 00	6B D9	01 00		01 00			
	GET	BE EF	03	06 00	C8 D8	02 00		00 00	1D 00 00 : OFF	1D 00 01 : ON	0.1.1/04
Auto Adjust	ON	BE EF	03	06 00		01 00		01 00		-	Only VGA
	OFF ON	BE EF	03	06 00 06 00	A2 D5 93 97	01 00	11 24	00 00		-	Only VGA
Keypad Lock	OFF	BE EF	03	06 00	03 96	01 00	11 24	00 00		+	
	GET	BE EF		06 00	30 96	02 00	11 24		1D 00 00 : OFF	1D 00 01 : ON	
Remote	OFF	BE EF	03	06 00	E7 96	01 00	16 24	01 00			
Controller Lock OSD Menu	ON	BE EF		06 00	77 97	01 00	16 24	00 00			
	GET	BE EF	03	06 00					1D 00 00 : OFF	1D 00 01 : ON	
	ON	BE EF	03	06 00	6A 63	01 00		01 00			
	OFF GET	BE EF	03	06 00 06 00	FA 62 FD D3	01 00		00 00	1D 00 XX : value		
Contrast	SET	BE EF	03	06 00	FD D3			01 XX	40" default value: 0x9E 50" default value: 0x8A	65" default value: 0x9E	Range: 0xB2- 0x4E
	INCREMENT	BE EE	03	06 00	9B D3	04.00	04 20	00 00	50 deladit value. 0x6A		UX4E
	DECREMENT		03	06 00	4A D2			00 00			
Monitor	ON	BE EF	03	06 00	19 D3			02 00			
	OFF	BE EF	03	06 00	19 D3	02 00		01 00			
	GET	BE EF	03	06 00	19 D8		00 60		1D 00 00 : OFF		
Mute	ON OFF	BE EF		06 00	D6 D2	01 00	02 20	01 00			
	GET	BE EF	03	06 00 06 00	46 D3 75 D3	01 00	02 20	00 00	1D 00 00 : OFF		
Auto Position	EXECUTE	BE EF	03	06 00	91 D0		0A 20	00 00	1D 00 00 . OFF		Only VGA
Color Temperature	INCREMENT	BE EF	03	06 00	0B F5	10 00		03 00	9300K, 6500K, 5000K, 7500K, USER		Only VOX
	DECREMENT	BE EF	03	06 00	CB F8	01 00	B0 30	13 00	9300K, 6500K, 5000K, 7500K, USER		
	GET	BE EF	03	06 00	C8 F5	02 00	B0 30	00 00	1D 00 XX : value	00=9300K, 00=6500K, 00=7500K, USER	
Clock	INCREMENT		03	06 00	19 D4	03 00		03 00			Only VGA
	DECREMENT	BE EF	03	06 00	19 D5	03 00	00 60	04 00			Only VGA
	GET	BE EF	03	06 00	19 D7	03 00	00 60		1D XX XX : value		Only VGA
Phase H-Position	INCREMENT		03	06 00	2F 83	04 00	03 21	00 00		 	Only VGA
	DECREMENT GET	BE EF	03	06 00	FE 82 49 83	05 00	03 21	00 00	1D 00 XX : value	+	Only VGA Only VGA
	INCREMENT		03	06 00			01 21	00 00	10 00 AA . Value	<u> </u>	Only VGA
	DECREMENT		03	06 00	46 83	05 00	01 21	00 00			Only VGA
	GET	BE EF		06 00	F1 82	02 00	01 21		1D XX XX : value		Only VGA
V-Position	INCREMENT			06 00	6B 83	04 00		00 00			Only VGA
	DECREMENT			06 00	BA 82	05 00		00 00			Only VGA
	GET	BE EF		06 00	0D 83	02 00			1D 00 XX : value		Only VGA
Color Get Gain R	INCREMENT			06 00	52 F4		B1 30	00 00		 	
	DECREMENT GET	BE EF	03	06 00 06 00	83 F5 34 F4	02 00	B1 30	00 00	1D XX XX : value	+	
Color Get Gain G	INCREMENT		03	06 00	16 F4	04 00		00 00	ID AA AA . Value	 	
	DECREMENT		03	06 00	C7 F5		B2 30	00 00			
	GET	BE EF	03	06 00	70 F4	02 00			1D 00 XX : value		
Color Get Gain B	INCREMENT	BE EF	03	06 00	EA F5	04 00	B3 30	00 00			
	DECREMENT			06 00	3B F4	05 00					
	GET	BE EF	03	06 00	8C F5	02 00	B3 30	00 00	1D XX XX : value		<u> </u>