



NOTES:

- 1. ASSEMBLE IN ACCORDANCE WITH IPC-A-610, CLASS 2.
- 2. USE ROHS COMPLIANT PROCESS.
- 3. PLACE EACH PCBA IN ANTI-STATIC BAG.
- 4. PROTECT IN SHIPPING CONTAINER TO PREVENT DAMAGE UNDER NORMAL TRANSPORT AND HANDLING.
- 5. CUT CORNER DENOTES PIN 1 OF COMPONENT OR COMPONENT OUTLINE.

Genesis V2 Daughter PCB
Celsee, Inc.
Sheet:
File: PREP400.kicad_pcb

Title: Assembly Drawing — SA1000139

Size: B Date: 10/31/2018 Rev: 3

KiCad E.D.A. kicad (5.0.0) Id: 1/1