Cruise Performance Lifting Surface 40 LS_026_01.csv -- LS_027_01.csv → LS 028 01.csv 35 → LS_029_01.csv -- LS_030_01.csv → LS 031 01.csv → LS 032 01.csv 30 → LS 033 01.csv --- LS 034 01.csv Lift-to-Drag Ratio (L/D) --- LS 035 01.csv 25 -**★**- LS 036 01.csv ---- LS_037_01.csv -**▼-** LS_037_02.csv --- LS_038_01.csv 20 -*- LS_039_01.csv -*- LS_040_01.csv LS 041 01.csv ..■ LS 042 01.csv 15 ..▲. LS_043_01.csv LS 043 02.csv ..▼. LS 044 01.csv 10 •••• LS_045_01.csv --*- LS_046_01.csv · **.....** LS 047 01.csv →- LS 048 01.csv 5 ---- LS 049 01.csv →- LS 050_01.csv 19.75 20.25 19.00 19.25 19.50 20.00 20.50 20.75 21.00

Operational Point (Airspeed [m/s])

→- LS 051 01.csv