MESSERSCHMITT ME-262A-1a SCHWALBE 25 1/2 IN.

A Sig [illegible] SCALE MODEL

COPYRIGHT [illegible] TOM W BELL
ALL RIGHTS RESERVED
PRINTED IN USA

DESIGNED & DRAWN BY TOM W BELL [illegible]

REV NO 2

[illegible]

COLOR SCHEME

FIND A COLOR PHOTO OF A RESTORED ME-262. PG. 90-91 OF THE BOOK "MESSERSCHMITT ME-262 - ARROW TO THE FUTURE" IS A GOOD COLOR REFERENCE.

COLORS:		FLM NO	FS NO
TOP SURFACE	BROWN	81	30097
TOP SURFACE	GREEN	83	34128
UNDER SURFACE	BLUE GRAY	76	36473
LANDING GEAR	GRAY GREEN	02	36165
COCKPIT	DARK GRAY	66	36081

■ BROWN

— - - — COLOR TRANSITION LINE

THE BLENDING OF THE TOP SIDE CAMOUFLAGE TO THE COLOR TRANSITION LINE IS A MOTTLED EFFECT. SEE PHOTOS ON HOW THIS IS DONE.

SEE HORIZONTAL STABILIZER LAYOUT AND CONSTRUCTION BELOW AND BELOW LEFT.

SUGGESTED CONSTRUCTION METHOD FOR TAPERED HORIZONTAL AND VERTICAL TAIL SURFACES.

TRAILING EDGE PIECES CUT FROM 3/32 BALSA. NOTE TAPER.

CUT LEADING EDGE FROM 3/16 X 5/16 BALSA. NOTE TAPER.

3/32 BALSA PLANKING

GEAR STRUT ANCHOR. MAKE FROM 3/16 x 1/2 BASSWOOD. DRILL 3/64 IN HOLE.

3/8 x 3/16 CROSS BRACE

1/16 SHEET TOP & BOTTOM

TRAILING EDGE, 3/32 x 1/8

MAIN SPAR AND RIBS FROM 3/16 x 1/4 BALSA. SEE PERSPECTIVE VIEW ABOVE RIGHT FOR CONSTRUCTION TECHNIQUE.

1/8 SQ LEADING EDGE

1/16 BALSA SHEET TOP AND BOTTOM.

LEADING EDGE WING SUPPORT. 1/16 BALSA.

TRIM TABS OFF AFTER WING ASS'Y.

WING RIBS, W-1 THRU W-11 MAKE FROM 1/16 BALSA

REMOVE FOR 3/32 PLANKED UPPER LEADING EDGE.

INLET - USE 1 IN. BRAD POINT DRILL TO DRILL INLET DUCT IN 1 3/8 x 1 3/8 BALSA BLOCK. CARVE TO SHAPE.

INLET CONE - TURN OR CARVE FROM 1/2 IN SQ. BALSA.

VARIABLE EXHAUST CONE TURN OR CARVE FROM 1/2 SQ BALSA.

TAIL PIPE - USE 5/8 BRAD POINT DRILL BIT TO DRILL EXHAUST PIPE IN 1 3/8 x 2 x 1 3/8 BALSA BLOCK. CARVE TO SHAPE.

MAKE 2 EA. PODS ARE IDENTICAL EXCEPT FOR ANGLE OF LEADING EDGE SUPPORT.

N-2 SHOWS SUGGESTED STRINGER LOCATIONS. NOTE THAT ALSO SOME 1/16 SHEET BALSA WILL BE REQUIRED AT THE WING-NACELLE JUNCTURE.

VERTICLE FIN AND RUDDER CONSTRUCTION IS SIMILIAR TO HORIZONTAL STABILIZER CONSTRUCTION.

LEADING EDGE 1/8 SQ BALSA

1/16 x 3/16 RIBS SAND TO TAPER

CARVE NOSE FROM 1/4 SQ X 1 IN BALSA BLOCK

CANNON BARRELS ARE MADE FROM 3/32 AND 1/8 TELESCOPING TUBING. SLIDE IN TO 3/16 TUBE WHICH HAS BEEN FITTED TO NOSE.

NOSE GEAR STRUT FROM 1/8, 3/16 AND 1/4 IN PLASTIC TUBE. MAKE FORK FROM .030 SHEET STYRENE.

WING DIHEDRAL SPAR. INSTALL PRIOR TO ATTACHING WING. MAKE FROM HARD 1/16 BALSA.

FITS OVER WING CARRY THRU CROSS MEMBER ON FUSELAGE BOX.

MAIN WING SPAR PATTERN. MAKE 2 FROM 1/16 HARD BALSA.

F-6 SHOWING SUGGESTED STRINGER LOCATIONS.

MASKING TAPE WRAP TO CENTER WIRE IN STRUT TUBE.

NOSE GEAR BENDING PATTERN. .047 MUSIC WIRE.

MAIN GEAR BENDING PATTERN. MAKE 2. .0625 MUSIC WIRE.

MAIN GEAR STRUT: 3/16 AND 1/4 IN PLASTIC TUBE.

NOTE: MAIN WHEEL BEARING IS 3/32 DIA ALUM TUBE. NOSE GEAR BEARING IS 3/32 PLASTIC TUBE.

TEMPLATE RRT 1/16 BALSA, TO SET W-1 WING RIB.

TURBINE FACE - MAKE 2 COPIES. GLUE TO FACE OF N-1 BULKHEAD BEFORE ATTACHING INLET CONE.

MG-1, MAKE 4 1/4 IN BALSA. MG-2, MAKE 4 [illegible] BALSA. NG-1, MAKE 2 3/16 BALSA. NG-2, MAKE 2 1/8 BALSA.

LOCATER MARKS FOR TURBINE FACE

GEAR DOOR ARRANGEMENT LOOKING INBOARD FROM LEFT WING. MAKE GEAR DOORS FROM SHEET STYRENE.

NOTCHER FOR STRINGERS: [illegible] BALSA OR BASSWOOD [illegible] GLUE [illegible] TO A PIECE OF 180 GRIT SANDPAPER. [illegible] THE EXCESS SANDPAPER. GLUE A [illegible] EXACTLY [illegible] FROM THE SAND PAPER TO CONTROL THE DEPTH OF CUT.

CONSTRUCTION NOTES:

1. THE CONSTRUCTION PLANS WERE DEVELOPED FROM SCALE DRAWINGS BY KENNETH S. BOKELMAN © [illegible]. THESE ARE THE ONLY ACCURATE DRAWINGS OF THE ME 262 AVAILABLE. IF YOU ARE SERIOUS ABOUT BUILDING AN ACCURATE MODEL, YOU WILL NEED HIS DRAWINGS. WRITE: SCALECRAFT, PO BOX [illegible], WHITTIER, CA [illegible]. ALSO AVAILABLE ARE DRAWINGS FOR FW-190 A8, FW-190 D9, TA-152 H, ME-109G AND K. ALSO HELPFUL IS THE BOOK "MESSERSCHMITT ME-262 ARROW TO THE FUTURE" BY WALTER J. BOYNE, AVAILABLE FROM THE NATIONAL AIR AND SPACE MUSEUM, SMITHSONIAN INSTITUTION, 7TH & INDEPENDENCE SW, WASHINGTON, DC [illegible].
2. CONSTRUCTION IS STRAIGHT FORWARD STICK AND TISSUE. BUILD WINGS OVER PLAN. BE SURE TO TILT ROOT RIB W-1 OUTWARD USING TEMPLATE RRT. FINISHED NACELLES ARE INSERTED BETWEEN W-3 AND W-4. FUSELAGE IS BOX CONSTRUCTION. BE ACCURATE! POSITION STRINGERS AT SUGGESTED LOCATIONS. USE NOTCHER, ILLUSTRATED AT RIGHT, TO CUT NOTCHES IN FUSELAGE BULKHEADS AT APPROPRIATE LOCATIONS.
3. PATTERNS FOR RIBS AND BULKHEADS ARE SHOWN AT TOP AND LOWER RIGHT OF PLAN. MAKE COPIES ON COPY MACHINE, LAY FACE DOWN ON WOOD (BE SURE GRAIN RUNS IN DESIRED DIRECTION) AND TRANSFER IMAGE BY RUBBING [illegible] WITH LACQUER THINNER DAMPENED CLOTH. USE ADEQUATE VENTILATION.