

Changing Your Router Bit

1 Unplug the router power from the orange plug peeking over the z-axis plate.



The dust foot is held in place by 4 magnets. Remove it by pulling firmly down until it disengages.



Using your 4mm wrench, loosen the two router bracket screws so that you can remove the router from the tool.




Flip the router over and, using your 17mm wrench, unscrew (counter clockwise) the collet nut while pressing the yellow button on the side of the router to lock the spindle.



Once the collet nut is loose, you should be able to easily pull the bit out of the router.



6 Choose the bit that you'd like to insert. It's best to have about 3/4" of the bit's shank inserted into the collet.



With the bit inserted, depress the yellow button and tighten the collet nut (clockwise) with your 17mm wrench.



8 Slide the router back into its bracket and tighten the two bracket bolts with your 4mm wrench



9 Remember to plug your router power cable back into the orange connector. Also check that the ON/OFF switch at the top of the router is set to "ON".



Use the commands in your quick launch app to zero your new bit before starting your next cut.



Place the vacuum foot back over your router if you've removed it.

