C172S-G1000 (Ted v1.2)

Initial

- ► Papers A.R.O.W.
- ► Control Lock off
- ► Mags. key out
- ▶ Mixture idle cutoff
- ▶ Throttle idle
- ▶ Avionics off
- ► Fuel Shutoff on
- ▶ Fuel both
- ▶ Master on ▶ Fuel - note
- ▶ Flaps down
- ▶ Lights/Pitot test ▶ Avionics on/off - fans
- ▶ Master off
- ▶ Hobbs Time note

Walkaround

- ▶ Fuel/0il dip/sample
 - ▶ Caps/Drains/Vents
 - ▶ Surfaces/Controls
 - ▶ Fxhaust/Antennas
 - ▶ Prop/Belt/Air Intake
 - ► Pitot/Static/Stall
 - ▶ Gear/Tires/Brakes
 - ▶ Ties/Baggage Door
 - ▶ Final Walkaround

Pre-Start

- ▶ Doors secure
- ▶ Belts/Seat Track
- ▶ Brakes check, set
- ▶ Circuit Brkrs. check
- ▶ Passenger brief
- ▶ Beacon on
- ► Avionics off
- ▶ Fuel both

Start

- ▶ Stby. Battery test/arm
- ▶ Engine Ind. no Xs
- ▶ Volts [E>24] [M<1.5]
- ► Amps S<0/ann on
- ▶ Prime:
 - Mixture idle cutoff
- Brakes secure
- Master on
- Throttle slight
- Aux. Pump on
- Mixture prime
- ·warm: D-3 sec
- .cold: 3-5 sec
- Aux. Pump off

- ▶ Mixture 3/4 rich
- ▶ "Prop Clear!"
- ▶ Mags. start
- ▶ Throttle 1000 RPM
- ▶ 0il Pressure 3D secs.
- ▶ Volts/Amps [>26] [>0]
- ▶ Mixture lean for taxi

Pre-Taxi

- ▶ Flaps up
- ▶ Lights as required
- ► Avionics on/set
- ► GPS DB date
- ▶ Fuel Totalizer enter ► ATIS - PFD/backup/AP(?)
- ▶ Radio test
- ▶ Transponder squawk
- ► Check TC/AI/HSI<->MC
- ► Clearance obtain
- ▶ Brakes test

Run-Up

- ▶ Brakes set
- ► Seat Belts check
- ▶ Doors/Windows secure
- ▶ Flight Controls correct
- ▶ Instruments scan
- ► Alternate Static check
- ► AP MET/HDG
- ▶ Trim takeoff
- ▶ Fuel on/both
- ► Hdq./Alt. Bugs ▶ GPS/Status Bar/Ann. Test
- ▶ MFD Range/Track Up
- ► Comm/Nav/VOR/FP
- Mixture rich
- ▶ Throttle 1800 RPM
- ► Mags 150, 50
- ▶ Engine Inst. check
- ▶ Idle Check
- ▶ Throttle 1000 RPM
- ▶ Mixture lean
- ▶ Lights as required
- ► ADSB Handheld on

Pre-Takeoff

- ▶ Abort Plan/Lost Comm.
- ▶ Fuel on/both
- ▶ Flaps 0-10°
- ▶ Mixture rich
- ► Aux. Pump off
- ▶ Pitot heat as required
- ▶ Review Airspeeds
- ▶ Time note/start

- ▶ "Lights 1 Camera 1 Action"
 - Mixture/Throttle
- ▶ Engine Inst. green
- ▶ Vr 55 kts
- Vx 62 kts₁ Vy 74 kts

Climb / Cruise

- ▶ Cruise Climb 75-85 kts
- Flaps up ► Mixture - lean >3000'
- ▶ Flow Check (♠15 min)
 - Fuel Trim
- Flaps, Engine Inst. • Mixture, Throttle
- Master 1 Mag 1 Pump

Descent

- ▶ Mixture richen slowly
- ▶ Throttle as required ▶ Flow Check

Pre-Landing

- ► ATIS/Rwys & Patterns
- ▶ "CCGUMPSF" • G: Fuel - on/both
 - M: Mixture rich
- Seat Belts secure
- F: Flaps as required
- ▶ Trim as required
- ▶ Ldg. Light on
- ▶ Approach 80-65 kts

Post-Landing

- ▶ Throttle 1000 RPM
- ▶ Mixture lean
- ▶ Flaps up
- ▶ Pitot Heat off
- ▶ Trim takeoff
- ▶ Lights as required
- ▶ Clearance obtain

Shutdown

- ▶ ELT check (121.5)
- ► Avionics off
- ▶ Lights off
- Beacon on
- ▶ Throttle 1000 RPM
- ▶ Mags. off then both
- ▶ Mixture idle cutoff
- ► Mags. key out
- ▶ Master off
- ▶ Tach Time note
- ▶ Stbv. Batterv off

Post-Flight

- ► ADSB Handheld off
- ▶ Tiedowns/Chocks
- ▶ Pitot Cover
- ▶ Fuel switch to L/R
- ▶ Gust Lock
- > Close Flight Plan
 - ► Hobbs Time note
 - ▶ Check Under Seats
 - ▶ Cabin / Baggage lock
 - ▶ Post-Flight Walkaround

Engine Failure

- ▶ Short Flow
- Fuel on/both
- Mixture full/check
- Electrical Pump on
- Alternate Air on
- Mags. check all
- ▶ Glide and Trim
- Speed: L∆ kts
- Ratio: 9, 1.48nm/1000ft
- ▶ Wind and Landing Site
- ▶ Longer Flow
 - Engine Indicators
- Short Flow Again
- ▶ No Restart
 - Fuel off
 - Mixture idle cut-off
 - Prop/Throttle off
 - Mags. off
 - Master off
- Belt and Seat check
- Unlatch Door
- Brace
- ▶ Approach 80/70/65 kts