(1,72S-61,000 (Ted v1,1)

- ► Papers A.R.O.W.
- - ▼ Control Lock off
- ► Mixture lean for taxi ► Mags. Key - out
 - ► Mixture idle cut-off

Pre-Taxi

- ▼ Throttle idle
- ▶ Avionics off
- ▶ Fuel Shutoff on
 - - ► Fuel both ► Master - on
- Fuel note
- ► Flaps down
- ► Lights/Pitot test
- Avionics on/off fans
 - ► Master off
- ► Hobbs Time note

- ► Fuel/0il dip/sample
 -) ► Caps/Drains/Vents ► Surfaces/Controls
 - Exhaust/Antennas
- Prop/Belt/Air Intake
- Pitot/Static/Stall
- ▶ Gear/Tires/Brakes ► Ties/Baggage Door
- ▶ Final Walkaround
- Pre-Start
- ▶ Belts/Seat Track ▶ Doors - secure
- ▶ Brakes check, set
- ▼ Circuit Brkrs. check

 - ✓ ► Passenger brief ► Beacon - on
- ▶ Avionics off
- ► Fuel both

- ▶ Sby. Battery test/arm
 - ► Engine Ind· no Xs
- ► Volts [E>24] [M<].5]
 - ► Amps S<0/ann on
 - ► Prime:
- Mixture all lean
- Brakes secure
- Aux. Pump on Master - on
- Throttle slight
 - Mixture prime
- .warm: 0-3 sec · cold: 3-5 sec
- ► Mixture 3/4 rich Aux. Pump - off

- ► "Prop (lear!"
- Mags. start

▶ Engine Inst. - green

▶ Vr - 55 kts

- Throttle 1000 RPM
- ► Vx L2 kts, Vy 74 kts Climb / Cruise ▶ Flaps - up Volts/Amps - [>26] [>0] 0il Pressure - 30 secs.
- Flow Check every 15 min Mixture - lean >30001

Cruise Climb - 75-85 kts

A/P - %881

► Lights - as required

Flaps - up

Avionics - on/set

GPS - DB date

- ▶ Flow Check
- Mixture richen slowly Fuel Totalizer - enter
 - Throttle as required Fuel - on/both ATIS/Altimeters x3

Radio - test

"CCGUMPSF" Transponder - squawk

Before Landing

- Check TC/AI/HSI<->MC Clearance - obtain
- Brakes test

Run-Up

- Brakes set
- Seat Belts check

Approach - 80/70/65 kts

After Landing

Lights - as required

Seat Belts - secure

Fuel - on/both Mixture - rich

- Doors/Windows
- ▶ Lights as required Flight Controls - correct
 - Instruments
- Alternate Static AP - MET/HDG

Throttle - 1000 RPM

Flaps - up

Mixture - lean Trim - takeoff

- Trim takeoff Fuel - on/both
- Hdg./Alt. Bugs

▼ (learance - obtain

Shutdowr

- GPS/Status Bar/Ann. Test MFD Range/Track Up
 - Comm/Nav/VOR/FP

Mixture - full lean

Lights - off

Mags. - off

Avionics - off

- Mixture rich
- Throttle 1800 RPM Mags. - 1,50, 50
- Engine Inst. check
 - Idle Check

Sby. Battery - off

Tach Time - note

Master - off

Close Flight Plan

- Throttle 1000 RPM Mixture - lean
- Lights as required

Fuel - switch to L/R

Post-Flight

Hobbs Time - note

Control Lock

Pre-Takeoff

- Abort Plan/Lost Comm.
- Fuel on/both Flaps - 0-10°
- Aux. Pump off Mixture - rich

Cabin / Baggage - lock

Check Under Seats

Tiedowns/Chocks

Pitot Cover

► Post-Flight Walkaround

- Pitot heat as required
 - ► Time note/start

► ADSB Handheld - on

► Full Throttle (>2300 RPM)

▶ "Lights, Camera, Action"

- Fuel on/both ▶ Short Flow
- Mixture full/check
- Electrical Pump on

- Alternate Air onMags. check allGlide and Trim
- ► Longer Flow ▶ Wind and Landing Site • Speed: 68 kts • Ratio: 9, 1.48nm/1000ft
- ▶ No Restart Engine IndicatorsShort Flow Again Fuel - off
- Mixture idle cut-offProp/Throttle off
- Mags. off
- Master offBelt and Seat checkUnlatch Door

- ▶ Approach 80/70/65 kts Brace