DA40-Gl000 (Ted Yin v0.7) ▶ ELT - check (121.5) Cold ► Avionics - off · Mixture - 3-5 sec Ground Operations · Throttle - 0.4" ▶ Electrical - off Initial ▶ "Prop Clear!" ACL Strobes - on ► Papers - A.R.O.W. ► Mags. - start ▶ Throttle - 1000 RPM ► Controls - free & correct ► Throttle - 1000 RPM ▶ Mags. - off then both ▶ Mags. - key out ▶ 0il Pressure - 15 secs. ▶ Mixture - idle cutoff ▶ Mixture - idle cutoff ▶ Electric Pump - off ▶ Mags. - key out ▶ Throttle - idle ▶ Tach Time - note ▶ Master Alt. - on ▶ Electrical - off ▶ Engine Inst. - no Xs ▶ Master - off ▶ Essential Bus - off ▶ Volts/Amps - [25-30] [>0] Post-Flight ► Avionics - off ▶ Fuel Pressure - 14-35 psi ► ADSB Handheld - off ▶ Master - on Mixture - lean (peak) ▶ Tiedowns/Chocks ▶ Fuel Pump - check Pre-Taxi ▶ Pitot Cover ▶ Fuel - note ▶ Gust Lock ▶ Flaps - up₁ then T/0 ▶ Flaps - check & set T/0 ► Close Flight Plan ▶ Lights - as required ▶ Lights/Pitot - test ▶ Hobbs Time - note ▶ Avionics - on/set ▶ Master - off ► GPS - DB date ▶ Check Under Seats ▶ Hobbs Time - note ► Canpoy/Door - lock ▶ Fuel Totalizer - enter Walkaround ▶ Post-Flight Walkaround ► ATIS - PFD/backup/AP(?) ► Canopy/Door - check Airspeeds (KIAS) ▶ Radio - test ▶ Fuel/0il - test/sample ▶ Transponder - squawk \triangleright Vr = 59 ▶ Caps/Drains/Vents ► Check - TC/AI/HSI<->MC ▶ Weights ▶ Surfaces/Controls ► Clearance - obtain • 2646/2535/2205/1874 lbs ▶ Stall Strips/Fairings ▶ Brakes - release/test ▶ Vq = 76/73/68/60 ► Exhaust/Antennas Run-Up Vy(Up) = 76/73/68/60 ▶ Prop/Air Intakes x3 Vy(T/0) = 67/66/60/54 ▶ Parking Brake - set ▶ Pitot/Static/Stall Approach Speeds ▶ Seat Belts - check ▶ Gear/Tires/Brakes • Up - 76/73/68/60 ► Canopy/Door - lock ▶ Ties/Chocks • T/O - 74/72/66/59 ▶ Door Warning - off ▶ Final Walkaround • LDG - 73/71/63/58 ▶ Flight Controls - correct Pre-Start Va ▶ Instruments - scan ▶ Rear Door - secure MÄM 40-227 ► Alternate Static - check ▶ Rudder Pedals - adjust ► AP - MET/HDG ·yes - 111 @ 2284-2646 ▶ Seat Belts ·no - 108 @ 2161-2535 ▶ Trim - T/0 ▶ Parking/Brakes - test/set ▶ Fuel Selector - fullest • below 2161/2284 - 94 ▶ Circuit Brkrs. - check

▶ Strobe (ACL) - on

▶ Avionics - off

▶ Fuel Selector - least

► Canopy - pos. 1/2

▶ Passenger - brief

Start

▶ Prime

• Mixture - idle cutoff

• Prop - high RPM

• Friction - adjust

• Master Bat. - on

• Throttle - 1.2"

Electric Pump - on

Warm

· Mixture - 1-3 sec

▶ Mixture - rich

► Comm/Nav/VOR/FP

▶ Hdg./Alt. Bugs

▶ Throttle - 2000 RPM

▶ MFD Range/Track Up

► Cycle Prop x3 - 250-500

▶ GPS/Status Bar/Ann. Test

► Mags · L/R - 175, 50.

▶ Alternate Air - check

▶ Engine Inst. - check

▶ Idle Check

▶ Throttle - 1000 RPM

▶ Mixture - lean

▶ Lights - as required

► ADSB Handheld - on

Shutdown

In-Flight Operations

Pre-Takeoff

▶ Abort Plan/Lost Comm.

► Canopy/Door - lock ▶ Fuel Selector - fullest

▶ Flaps - T/0

▶ Mixture - rich ▶ Prop - high RPM

▶ Electric Pump - on

▶ Pitot Heat - as required ▶ Review Airspeeds

▶ Time - note/start

Takeoff

▶ "Lights: Camera: Action"

• Mixture/Prop/Throttle

▶ Engine Inst. - green

▶ Vr - 59; then 67-60 KIAS ▶ Safe Altitude

Prop - 2400 RPM

• Elect. Pump - off • Lights - as required

▶ Vy (T/0)

Ь7-54 KIAS

• 68 minus l.8 per 100 lbs ▶ Throttle - full under 2646

▶ Cruise

Flaps - up

■ Vy: 7b-b0 KIAS

▶ Prop - 2400 RPM

▶ Mixture - rich

• >5000 hold const. EGT ▶ Throttle - full

▶ Engine Inst. - green

▶ Trim - as required

▶ High Altitude - pump on

Cruise

▶ Flaps - up ▶ Throttle - 21-24"

▶ Prop - 1800-2400 RPM

▶ Mixture

• Higher Power - richen

• Economy: max EGT & <=75%

·Power: 1∩N°F/55°C lower

▶ Flow Check (♠15 min)

• Trim₁ Fuel

• Mixture, Prop, Throttle • Flaps - Engine Inst.

■ Pump₁ Mag•₁ Master

► CHT: 150-400°F

▶ 0il: 165-220°F

▶ Mixture - richen slowly

▶ Prop - 1800-2400 RPM ▶ Throttle - as required

▶ High Altitude - pump on ▶ Flow Check

► CHT Cool Down • <= 50°F/22.8°C pm

Pre-Landing

► ATIS/Rwys & Patterns ■ "CCGUMPSF"

• G: Fuel Selector

· downwind/fullest • M: Mixture - rich

• P: Elect. Pump - on • P: Prop - high RPM

• Seat Belts - secure • F: Flaps - as required

· T/O <108 KIAS · LDG <91 KIAS

▶ Trim - as required ▶ Lights - as required ▶ Approach - 73-58 KIAS

Go Around

► Vy - 67-54 KIAS

▶ Flaps - T/0 ► Safe Altitude

 Prop - 2400 RPM • Elect. Pump - off

• Cruise Climb

Post-Landing

▶ Throttle - 1000 RPM ▶ Mixture - lean

▶ Flaps - up

▶ Elect. Pump - off

▶ Pitot Heat - off

► Trim - T/0

▶ Lights - as required ► Clearance - obtain

CO Contamination

► Cabin Heat - off

▶ Ventilation - open

► Emergency Windows - open

▶ Forward Canopy

 partially open • DO NOT lock/unlock rear

door during flight

Engine Failure

▶ Short Flow

• Fuel Selector - fullest

• Mixture - full/check

• Elect. Pump - on • Alternate Air - on

• Mags. - check all ▶ Glide and Trim

• Speed: 7L-LO KIAS • Windmill: 1:8.87

1.45nm/lkft Stationary: 1:10.3.

1.7nm/lkft ▶ Wind and Landing Site

▶ Longer Flow • Engine Inst.

• Short Flow Again ▶ Windmill Restart

Airspeed >= 70 KIAS • Mags• - both • Mixture - lean then

slowly richen ▶ Stationary Restart

 Airspeed >= 80 KIAS • Electrical - off

Avionics - off Master - on

Mags. - start

▶ No Restart

• Fuel Selector - off • Mixture - idle cutoff

• Mags. - off • Master - off

• Belt and Seat - check

 Unlatch Door Brace

C172S-G1000 (Ted v1.2)

Initial

- ► Papers A.R.O.W.
- ► Control Lock off
- ► Mags. key out
- ▶ Mixture idle cutoff
- ▶ Throttle idle
- ▶ Avionics off
- ► Fuel Shutoff on
- ▶ Fuel both
- ▶ Master on
- ▶ Fuel note
- ▶ Flaps down
- ▶ Lights/Pitot test
- ▶ Avionics on/off fans
- ▶ Master off ▶ Hobbs Time - note

Walkaround

- ▶ Fuel/0il dip/sample
- ▶ Caps/Drains/Vents
- ▶ Surfaces/Controls
- ▶ Exhaust/Antennas
- ▶ Prop/Belt/Air Intake
- ► Pitot/Static/Stall
- ▶ Gear/Tires/Brakes ▶ Ties/Baggage Door
- ▶ Final Walkaround

Pre-Start

- ▶ Doors secure
- ▶ Belts/Seat Track
- ▶ Brakes check, set
- ▶ Circuit Brkrs. check ▶ Passenger - brief
- ▶ Beacon on
- ► Avionics off
- ▶ Fuel both

Start

- ▶ Stby. Battery test/arm
- ▶ Engine Ind. no Xs
- ▶ Volts [E>24] [M<1.5]
- ► Amps S<0/ann on
- ▶ Prime:
 - Mixture idle cutoff
- Brakes secure
- Master on
- Throttle slight
- Aux. Pump on
- Mixture prime
- ·warm: D-3 sec
- · cold: 3-5 sec
- Aux. Pump off

- ▶ Mixture 3/4 rich
- ▶ "Prop Clear!"
- ▶ Mags. start
- ▶ Throttle 1000 RPM
- ▶ 0il Pressure 3D secs.
- ▶ Volts/Amps [>26] [>0] ▶ Mixture - lean for taxi

Pre-Taxi

▶ Flaps - up

► GPS - DB date

- ▶ Lights as required
- ► Avionics on/set
- ▶ Fuel Totalizer enter
- ► ATIS PFD/backup/AP(?)
- ▶ Radio test
- ▶ Transponder squawk
- ► Check TC/AI/HSI<->MC
- ► Clearance obtain
- ▶ Brakes test

Run-Up

- ▶ Brakes set
- ► Seat Belts check
- ▶ Doors/Windows secure
- ▶ Flight Controls correct
- ▶ Instruments scan
- ► Alternate Static check
- ► AP MET/HDG ▶ Trim - takeoff
- ▶ Fuel on/both
- ► Hdq./Alt. Bugs
- ▶ GPS/Status Bar/Ann. Test
- ▶ MFD Range/Track Up ► Comm/Nav/VOR/FP
- Mixture rich
- ▶ Throttle 1800 RPM
- ► Mags 150, 50
- ▶ Engine Inst. check
- ▶ Idle Check
- ▶ Throttle 1000 RPM
- ▶ Mixture lean
- ▶ Lights as required
- ► ADSB Handheld on

Pre-Takeoff

- ▶ Abort Plan/Lost Comm.
- ▶ Fuel on/both
- ▶ Flaps 0-10°
- ▶ Mixture rich
- ► Aux. Pump off
- ▶ Pitot heat as required
- ▶ Review Airspeeds
- ▶ Time note/start

- ▶ "Lights 1 Camera 1 Action"
 - Mixture/Throttle
- ▶ Engine Inst. green
- ▶ Vr 55 kts
- Vx 62 kts₁ Vy 74 kts

Climb / Cruise

- ▶ Cruise Climb 75-85 kts
- Flaps up ► Mixture - lean >3000'
- ▶ Flow Check (♠15 min)
- Fuel Trim
- Flaps, Engine Inst. • Mixture, Throttle
- Master 1 Mag 1 Pump

Descent

- ▶ Mixture richen slowly
- ▶ Throttle as required ▶ Flow Check

Pre-Landing

- ► ATIS/Rwys & Patterns
- ▶ "CCGUMPSF" • G: Fuel - on/both
 - M: Mixture rich
 - Seat Belts secure
- F: Flaps as required
- ▶ Trim as required
- ▶ Ldg. Light on

Post-Landing

▶ Throttle - 1000 RPM

▶ Approach - 80-65 kts

- ▶ Mixture lean
- ▶ Flaps up
- ▶ Pitot Heat off
- ▶ Trim takeoff
- ▶ Lights as required

▶ Clearance - obtain Shutdown

- ▶ ELT check (121.5)
- ► Avionics off
- ▶ Lights off
- Beacon on
- ▶ Throttle 1000 RPM ▶ Mags. - off then both
- ▶ Mixture idle cutoff
- ► Mags. key out
- ▶ Master off
- ▶ Tach Time note
- ▶ Stbv. Batterv off

Post-Flight

- ► ADSB Handheld off
- ▶ Tiedowns/Chocks
- ▶ Pitot Cover
- ▶ Fuel switch to L/R
- ▶ Gust Lock
- ► Close Flight Plan ▶ Hobbs Time - note
 - ▶ Check Under Seats

 - ▶ Cabin / Baggage lock ▶ Post-Flight Walkaround

Engine Failure

- ▶ Short Flow
- Fuel on/both
- Mixture full/check
- Electrical Pump on
- Alternate Air on
- Mags. check all
- ▶ Glide and Trim
- Speed: LA kts
- Ratio: 9, 1.48nm/1000ft
- ▶ Wind and Landing Site
- ▶ Longer Flow
 - Engine Indicators
- Short Flow Again
- ▶ No Restart
 - Fuel off
 - Mixture idle cut-off
 - Prop/Throttle off
 - Mags. off
 - Master off
- Belt and Seat check
- Unlatch Door
- Brace
- ▶ Approach 80/70/65 kts