DA40-Gl000 (Ted Yin v0.7) ▶ ELT - check (121.5) Cold ▶ Avionics - off · Mixture - 3-5 sec Ground Operations · Throttle - 0.4" ▶ Electrical - off Initial ▶ "Prop Clear!" ACL Strobes - on ► Papers - A.R.O.W. ► Mags. - start ▶ Throttle - 1000 RPM ► Controls - free & correct ► Throttle - 1000 RPM ▶ Mags. - off then both ▶ Mags. - key out ▶ 0il Pressure - 15 secs. ▶ Mixture - idle cutoff ▶ Mixture - idle cutoff ▶ Electric Pump - off ▶ Mags. - key out ▶ Throttle - idle ▶ Tach Time - note ▶ Master Alt. - on ▶ Electrical - off ▶ Engine Inst. - no Xs ▶ Master - off ▶ Essential Bus - off ▶ Volts/Amps - [25-30] [>0] Post-Flight ► Avionics - off ▶ Fuel Pressure - 14-35 psi ► ADSB Handheld - off ▶ Master - on Mixture - lean (peak) ▶ Tiedowns/Chocks ▶ Fuel Pump - check Pre-Taxi ▶ Pitot Cover ▶ Fuel - note ▶ Gust Lock ▶ Flaps - up₁ then T/0 ▶ Flaps - check & set T/0 ► Close Flight Plan ▶ Lights - as required ▶ Lights/Pitot - test ▶ Hobbs Time - note ▶ Avionics - on/set ▶ Master - off ► GPS - DB date ▶ Check Under Seats ▶ Hobbs Time - note ► Canpoy/Door - lock ▶ Fuel Totalizer - enter Walkaround ▶ Post-Flight Walkaround ► ATIS - PFD/backup/AP(?) ► Canopy/Door - check Airspeeds (KIAS) ▶ Radio - test ▶ Fuel/0il - test/sample ▶ Transponder - squawk \triangleright Vr = 59 ▶ Caps/Drains/Vents ► Check - TC/AI/HSI<->MC ▶ Weights ▶ Surfaces/Controls ► Clearance - obtain • 2646/2535/2205/1874 lbs ▶ Stall Strips/Fairings ▶ Brakes - release/test ▶ Vq = 76/73/68/60 ► Exhaust/Antennas Run-Up Vy(Up) = 76/73/68/60 ▶ Prop/Air Intakes x3 Vy(T/0) = 67/66/60/54 ▶ Parking Brake - set ▶ Pitot/Static/Stall Approach Speeds ▶ Seat Belts - check ▶ Gear/Tires/Brakes • Up - 76/73/68/60 ► Canopy/Door - lock ▶ Ties/Chocks • T/O - 74/72/66/59 ▶ Door Warning - off ▶ Final Walkaround • LDG - 73/71/63/58 ▶ Flight Controls - correct Pre-Start Va ▶ Instruments - scan ▶ Rear Door - secure MÄM 40-227 ► Alternate Static - check ▶ Rudder Pedals - adjust ► AP - MET/HDG ·yes - 111 @ 2284-2646 ▶ Seat Belts ·no - 108 @ 2161-2535 ▶ Trim - T/0 ▶ Parking/Brakes - test/set ▶ Fuel Selector - fullest • below 2161/2284 - 94 ▶ Circuit Brkrs. - check

▶ Strobe (ACL) - on

▶ Avionics - off

▶ Fuel Selector - least

► Canopy - pos. 1/2

▶ Passenger - brief

Start

▶ Prime

• Mixture - idle cutoff

• Prop - high RPM

• Friction - adjust

• Master Bat. - on

• Throttle - 1.2"

Electric Pump - on

Warm

· Mixture - 1-3 sec

▶ Mixture - rich

► Comm/Nav/VOR/FP

▶ Hdg./Alt. Bugs

▶ Throttle - 2000 RPM

▶ MFD Range/Track Up

► Cycle Prop x3 - 250-500

▶ GPS/Status Bar/Ann. Test

► Mags · L/R - 175, 50.

▶ Alternate Air - check

▶ Engine Inst. - check

▶ Idle Check

▶ Throttle - 1000 RPM

▶ Mixture - lean

▶ Lights - as required

► ADSB Handheld - on

Shutdown

In-Flight Operations

Pre-Takeoff

- ▶ Abort Plan/Lost Comm.
- ► Canopy/Door lock
- ▶ Fuel Selector fullest
- ▶ Flaps T/0
- ▶ Mixture rich
- ▶ Prop high RPM
- ▶ Electric Pump on
- ▶ Pitot Heat as required ▶ Review Airspeeds
- ▶ Time note/start

Takeoff

- ▶ "Lights: Camera: Action"
- Mixture/Prop/Throttle
- ▶ Engine Inst. green
- ▶ Vr 59; then 67-60 KIAS
- ► Safe Altitude • Prop - 2400 RPM
- Elect. Pump off
- Lights as required

► T/0

- Vy = 67-54 KIAS
- ·68 minus 1.8 per 100 lbs under 2646
- ▶ Cruise
- Flaps up • Vy = 76-60 KIAS
- ▶ Mixture rich
- >5000 hold const. EGT
- ▶ Prop 2488 RPM
- ▶ Throttle full
- ▶ Engine Inst. green
- ▶ Trim as required
- ▶ High Altitude pump on
 - Cruise

- ▶ Flaps up ▶ Throttle - 21-24"
- ▶ Prop 1800-2400 RPM
- ▶ Mixture
- Higher Power richen
- Economy: max EGT & <=75%
- · Power: 100°F/55°C lower ▶ High Altitude - pump on
- ▶ Flow Check (♠15 min)
- Trim₁ Fuel
- Mixture, Prop, Throttle
- Flaps, Engine Inst.
- Pump₁ Mag•₁ Master ► CHT: 150-400°F

▶ 0il: 165-220°F

- ▶ Mixture richen slowly
- ▶ Prop 1800-2400 RPM ▶ Throttle - as required
- ▶ High Altitude pump on
- ▶ Flow Check
- ► CHT Cool Down

■ "CCGUMPSF"

<= 50°F(22.8°C) per min.</p>

Pre-Landing

- ▶ ATIS/Rwys & Patterns
 - G: Fuel Selector
 - · downwind/fullest
 - M: Mixture rich
- P: Elect. Pump on
- P: Prop high RPM
- Seat Belts secure • F: Flaps - as required
- · T/O <108 KIAS
- · LDG <91 KIAS
- ▶ Trim as required ▶ Lights - as required
- ► Approach 73-58 KIAS

Go Around

- ▶ Throttle full
- ► Vy 67-54 KIAS
- ▶ Flaps T/0 ▶ Safe Altitude
 - Prop 2400 RPM
 - Elect. Pump off
 - Cruise Climb

Post-Landing

- ▶ Throttle 1000 RPM
- Mixture lean
- ▶ Flaps up
- ▶ Elect. Pump off
- ▶ Pitot Heat off
- ► Trim T/0
- ▶ Lights as required
- ▶ Clearance obtain

CO Contamination

- ► Cabin Heat off
- ▶ Ventilation open
- ▶ Emergency Windows open ▶ Forward Canopy
 - partially open
 - DO NOT lock/unlock rear
 - door during flight

Engine Failure

- ▶ Short Flow
- Fuel Selector fullest
- Mixture full/check
- Elect. Pump on
- Alternate Air on Mags. - check all
- ▶ Glide and Trim
 - Speed: 7L-LO KIAS
 - Windmill: 1:8.8.
 - 1.45nm/lkft
 - Stationary: 1:10.3 1.7nm/lkft
- ▶ Wind and Landing Site
- ▶ Longer Flow • Engine Inst.
- Short Flow Again
- ▶ Windmill Restart
- Airspeed >= 70 KIAS Mags. - both
- Mixture lean then slowly richen
- ▶ Stationary Restart
 - Airspeed >= 80 KIAS
 - Electrical off
 - Avionics off
 - Master on
 - Mags. start
- ▶ No Restart
 - Fuel Selector off
 - Mixture idle cutoff • Mags - off
 - Master off
 - Belt and Seat check
 - Unlatch Door
 - Brace

C172S-G1000 (Ted v1.2)

Initial

- ► Papers A.R.O.W.
- ► Control Lock off
- ► Mags. key out
- ▶ Mixture idle cutoff
- ▶ Throttle idle
- ▶ Avionics off
- ► Fuel Shutoff on
- ▶ Fuel both
- ▶ Master on
- ▶ Fuel note
- ▶ Flaps down
- ▶ Lights/Pitot test
- ▶ Avionics on/off fans
- ▶ Master off ▶ Hobbs Time - note

Walkaround

- ▶ Fuel/0il dip/sample
- ▶ Caps/Drains/Vents
- ▶ Surfaces/Controls
- ▶ Fxhaust/Antennas
- ▶ Prop/Belt/Air Intake
- ► Pitot/Static/Stall
- ▶ Gear/Tires/Brakes ▶ Ties/Baggage Door
- ▶ Final Walkaround

Pre-Start

- ▶ Doors secure
- ▶ Belts/Seat Track
- ▶ Brakes check, set
- ▶ Circuit Brkrs. check ▶ Passenger - brief
- ▶ Beacon on
- ► Avionics off
- ▶ Fuel both

Start

- ▶ Stby. Battery test/arm
- ▶ Engine Ind. no Xs
- ▶ Volts [E>24] [M<1.5]
- ► Amps S<0/ann on
- ▶ Prime:
 - Mixture idle cutoff
- Brakes secure
- Master on
- Throttle slight
- Aux. Pump on
- Mixture prime
- ·warm: D-3 sec
- · cold: 3-5 sec
- Aux. Pump off

- ▶ Mixture 3/4 rich
- ▶ "Prop Clear!"
- ▶ Mags. start
- ▶ Throttle 1000 RPM
- ▶ 0il Pressure 3D secs.
- ▶ Volts/Amps [>26] [>0] ▶ Mixture - lean for taxi

Pre-Taxi

▶ Flaps - up

► GPS - DB date

- ▶ Lights as required
- ► Avionics on/set
- ▶ Fuel Totalizer enter
- ► ATIS PFD/backup/AP(?)
- ▶ Radio test
- ▶ Transponder squawk
- ► Check TC/AI/HSI<->MC
- ► Clearance obtain
- ▶ Brakes test

Run-Up

- ▶ Brakes set
- ► Seat Belts check
- ▶ Doors/Windows secure
- ▶ Flight Controls correct
- ▶ Instruments scan
- ► Alternate Static check
- ► AP MET/HDG ▶ Trim - takeoff
- ▶ Fuel on/both
- ► Hdq./Alt. Bugs
- ▶ GPS/Status Bar/Ann. Test
- ▶ MFD Range/Track Up ► Comm/Nav/VOR/FP
- Mixture rich
- ▶ Throttle 1800 RPM
- ► Mags 150, 50
- ▶ Engine Inst. check
- ▶ Idle Check
- ▶ Throttle 1000 RPM
- ▶ Mixture lean
- ▶ Lights as required
- ► ADSB Handheld on

Pre-Takeoff

- ▶ Abort Plan/Lost Comm.
- ▶ Fuel on/both
- ▶ Flaps 0-10°
- ▶ Mixture rich
- ► Aux. Pump off
- ▶ Pitot heat as required
- ▶ Review Airspeeds
- ▶ Time note/start

- ▶ "Lights 1 Camera 1 Action"
 - Mixture/Throttle
- ▶ Engine Inst. green
- ▶ Vr 55 kts
- Vx 62 kts₁ Vy 74 kts

Climb / Cruise

- ▶ Cruise Climb 75-85 kts
- Flaps up ► Mixture - lean >3000'
- ▶ Flow Check (♠15 min)
- Fuel Trim
- Flaps, Engine Inst. • Mixture, Throttle
- Master 1 Mag 1 Pump

Descent

- ▶ Mixture richen slowly
- ▶ Throttle as required ▶ Flow Check

Pre-Landing

- ► ATIS/Rwys & Patterns
- ▶ "CCGUMPSF" • G: Fuel - on/both
 - M: Mixture rich
 - Seat Belts secure
- F: Flaps as required
- ▶ Trim as required
- ▶ Ldg. Light on

Post-Landing

▶ Throttle - 1000 RPM

▶ Approach - 80-65 kts

- ▶ Mixture lean
- ▶ Flaps up
- ▶ Pitot Heat off
- ▶ Trim takeoff
- ▶ Lights as required

▶ Clearance - obtain Shutdown

- ▶ ELT check (121.5)
- ► Avionics off
- ▶ Lights off
- Beacon on
- ▶ Throttle 1000 RPM ▶ Mags. - off then both
- ▶ Mixture idle cutoff
- ► Mags. key out
- ▶ Master off
- ▶ Tach Time note
- ▶ Stbv. Batterv off

Post-Flight

- ► ADSB Handheld off
- ▶ Tiedowns/Chocks
- ▶ Pitot Cover
- ▶ Fuel switch to L/R
- ▶ Gust Lock
- ► Close Flight Plan ▶ Hobbs Time - note
 - ▶ Check Under Seats

 - ▶ Cabin / Baggage lock ▶ Post-Flight Walkaround

Engine Failure

- ▶ Short Flow
- Fuel on/both
- Mixture full/check
- Electrical Pump on
- Alternate Air on
- Mags. check all
- ▶ Glide and Trim
- Speed: LA kts
- Ratio: 9, 1.48nm/1000ft
- ▶ Wind and Landing Site
- ▶ Longer Flow
 - Engine Indicators
- Short Flow Again
- ▶ No Restart
 - Fuel off
 - Mixture idle cut-off
 - Prop/Throttle off
 - Mags. off
 - Master off
- Belt and Seat check
- Unlatch Door
- Brace
- ▶ Approach 80/70/65 kts